Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Gizoon B0FCYDNSMW

Gizoon 5-Drawer Dresser Instruction Manual

Model: B0FCYDNSMW

1. Introduction

Thank you for choosing the Gizoon 5-Drawer Dresser. This manual provides essential information for the safe assembly, operation, and maintenance of your new furniture. Please read these instructions carefully before beginning assembly and retain them for future reference.

This dresser is designed for storage in bedrooms, living rooms, hallways, or offices, offering ample space for clothing, accessories, and other items. It features a durable wood construction with a sleek black finish and an anti-tip device for enhanced safety.

2. Safety Information

WARNING: Failure to follow these safety instructions may result in injury or property damage.

- Always assemble the dresser on a soft, clean surface to prevent scratches.
- Ensure all parts and hardware are present before beginning assembly.
- Do not overtighten screws, as this may damage the wood.
- Always use the provided anti-tip device to secure the dresser to a wall. This is crucial to prevent tipping, especially in homes with children or pets.
- Do not allow children to climb on or play with the dresser.
- Distribute weight evenly across drawers to maintain stability.
- Keep small parts away from children during assembly.



Image showing the anti-tip device installation, a critical safety feature.

3. Parts List

Before assembly, verify that all components listed below are included in your package. If any parts are missing or damaged, please contact customer support.

Hardware Components

Image showing various screws, dowels, and drawer slides labeled for assembly.

Wooden Panels



Image displaying the various wooden panels that make up the dresser structure and drawers.

Note: The exact quantity and type of hardware may vary slightly. Refer to the included assembly diagram for precise counts.

4. Assembly Instructions

Assembly typically requires 1-2 people and takes approximately 1-2 hours, though time may vary based on experience. A screwdriver is included; an electric screwdriver (not included) can expedite the process. Ensure adequate workspace and take inventory of all components before starting. Wearing gloves is recommended to prevent injury.

4.1. Step-by-Step Assembly Guide

1. **Prepare Drawer Slides:** Attach the drawer slides (G1) to the side panels (1 and 2) using screws (M). Ensure they are securely fastened.
2. **Assemble Base Frame:** Connect the bottom panel (2) to the side panels (1) using dowels (C) and screws (A).
3. **Install Support Bars:** Attach the support bars (4 and 7) to the base frame using screws (A) and cam locks (B).
4. **Attach Back Panel:** Secure the back panel (6) to the assembled frame.
5. **Assemble Drawer Boxes:** For each drawer, attach the side panels (17, 18) to the front (14) and back (19) panels using screws (A) and dowels (C). Secure the bottom panel (20) with screws (F).
6. **Install Drawer Handles:** Attach the handles (N) to the drawer fronts (14) using the provided screws.
7. **Insert Drawers:** Carefully slide the assembled drawers into the dresser frame.
8. **Attach Anti-Tip Device:** Secure the anti-tip device (H) to the top rear of the dresser and to a wall stud using the provided screws.

Your browser does not support the video tag.

Video demonstrating the assembly process for a Gizoon 5-Drawer Dresser. This video provides a visual guide to help with each step of construction.

Your browser does not support the video tag.

Video illustrating the assembly of a VVFLU 6-Drawer Dresser, which shares similar construction principles. This can serve as an additional visual aid for assembly.

5. Operating Instructions

5.1. Drawer Usage

- To open a drawer, gently pull the handle outwards.
- To close a drawer, push it inwards until it is fully seated.
- Avoid slamming drawers to prevent damage to the slides and frame.
- Do not overload drawers. Distribute items evenly to ensure smooth operation and prevent strain on the drawer slides.



Image showing an open drawer with items inside, demonstrating the storage capacity.

6. Maintenance

6.1. Cleaning

- Wipe surfaces with a soft, damp cloth.
- Avoid using harsh chemicals or abrasive cleaners, as these can damage the finish.
- Dry immediately with a clean cloth to prevent water marks.

6.2. General Care

- Periodically check all screws and fasteners to ensure they are tight. Retighten if necessary.
- Keep the dresser away from direct sunlight and extreme temperature changes to prevent warping or fading.
- If the dresser is moved, ensure the anti-tip device is re-secured in the new location.

7. Troubleshooting

Problem	Possible Cause	Solution
Drawers do not slide smoothly.	Misaligned drawer slides or overloaded drawer.	Check alignment of drawer slides and ensure they are properly installed. Reduce the weight in the drawer.
Dresser feels wobbly.	Loose fasteners or uneven floor.	Tighten all screws and bolts. Place shims under the dresser legs if the floor is uneven. Ensure the anti-tip device is securely installed.
Missing parts during assembly.	Packaging error.	Contact Gizoon customer support with your product model and a list of missing parts.

8. Specifications

- **Brand:** Gizoon
- **Model:** 5-Drawer Dresser (B0FCYDNSMW)
- **Color:** Black
- **Material:** Engineered Wood
- **Product Dimensions:** 27.56"D x 15.75"W x 43.31"H
- **Item Weight:** 60.2 Pounds
- **Number of Drawers:** 5
- **Assembly Required:** Yes
- **Anti-Tip Device:** Included



Image illustrating the dimensions of the dresser, including drawer interior measurements.

9. Warranty and Support

For warranty information, missing parts, or any assembly questions, please contact Gizoon customer support directly. Refer to your purchase documentation for specific contact details or visit the official Gizoon website.

Online Support: Visit the Gizoon Store on Amazon

© 2025 Gizoon. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FCYDNSMW

More documents and user manuals: **https://manuals.plus/**