

[Manuals.plus](#) /

› [Poedagar](#) /

› Poedagar 629 Sport Chronograph Quartz Watch User Manual

Poedagar 629

Poedagar 629 Sport Chronograph Quartz Watch User Manual

Model: 629

1. INTRODUCTION

Thank you for choosing the Poedagar 629 Sport Chronograph Quartz Watch. This manual provides essential information for the proper setup, operation, and maintenance of your timepiece. Please read it carefully to ensure optimal performance and longevity of your watch.



Image 1.1: Poedagar 629 Sport Chronograph Quartz Watch on a wrist, showcasing its design.

2. PRODUCT FEATURES

- **Precision Quartz Movement:** Ensures accurate and reliable timekeeping.
- **3ATM Water Resistance:** Suitable for everyday splashes, rain, and short swims. Not recommended for diving or hot water activities.
- **Durable Stainless Steel Band:** A 20mm stainless steel strap with a secure bracelet clasp for comfort and longevity.
- **Luminous Hands & Markers:** Glow-in-the-dark hands and markers for visibility in low-light conditions.
- **Chronograph Functions:** Includes minute timing, second timing, and a 24-hour display.
- **Date Display:** Features an auto date function.
- **Elegant Round Dial Design:** A 42mm stainless steel case with a classic round dial.

3. SETUP AND INITIAL ADJUSTMENT

3.1 Setting Time and Date

Your Poedagar 629 watch features a crown and two push-buttons for adjustments. Refer to the diagram below for button identification.



Image 3.1: Watch controls for time, date, and chronograph functions.

1. **To Set the Time:** Gently pull the crown (middle button) out to the furthest position. Rotate the crown to move the hour and minute hands to the correct time. Push the crown back in to its original position to start the watch.
2. **To Set the Date:** Pull the crown out to the first click position. Rotate the crown to adjust the date. Push the crown back in to its original position when the correct date is set. *Avoid setting the date between 9 PM and 3 AM, as this may interfere with the automatic date change mechanism.*

3.2 Adjusting the Bracelet

The stainless steel bracelet can be adjusted to fit your wrist. This typically involves removing or adding links. It is recommended to have this adjustment performed by a professional watchmaker or jeweler to prevent damage to the bracelet or clasp.

4. OPERATING THE CHRONOGRAPH AND SPECIAL FEATURES

4.1 Using the Chronograph

The chronograph function allows for precise timing of events. Refer to Image 3.1 for button locations.

1. **Start/Pause Timing:** Press the top push-button to start the chronograph. Press it again to pause the timing.
2. **Reset Timing:** While the chronograph is paused, press the bottom push-button to reset all chronograph hands to their zero positions.

4.2 Luminous Hands and Markers

The watch features luminous material on its hands and hour markers. This material absorbs light during the day and emits a glow in dark conditions, allowing for readability at night. The intensity and duration of the glow depend on the exposure to light.




Image 4.1: Luminous hands and markers visible in low light.

4.3 Water Resistance

Your Poedagar 629 watch is rated for 3ATM (30 meters) water resistance. This means it is designed to withstand:

- Splashing water
- Rain
- Washing hands
- Short swims (e.g., surface swimming)

Important Precautions:

- Do **NOT** operate the crown or push-buttons when the watch is wet or submerged.
- Do **NOT** expose the watch to hot water, steam, or extreme temperature changes (e.g., hot showers, saunas, hot tubs), as this can compromise the water seals.
- Ensure the crown is fully pushed in before any contact with water.



Image 4.2: Water resistance capabilities of the Poedagar 629 watch.

5. MAINTENANCE

5.1 Cleaning Your Watch

To maintain the appearance of your watch:

- Wipe the case and bracelet regularly with a soft, dry cloth.
- For stainless steel parts, a slightly damp cloth can be used, followed by a dry cloth.
- Avoid using chemical cleaners, solvents, or abrasive materials, as these can damage the watch's finish.

5.2 Battery Information

The Poedagar 629 watch is powered by a quartz movement, which uses a battery. The battery life typically ranges from 2 to 3 years, depending on usage. When the battery runs out, the watch will stop. It is recommended to have the battery replaced by a qualified watch technician to ensure the water resistance seal is properly maintained.

6. TROUBLESHOOTING

If you encounter any issues with your watch, please refer to the following common troubleshooting steps:

- **Watch Not Running:** Check if the crown is fully pushed in. If the watch still does not run, the battery may need replacement.
- **Date Not Changing:** Ensure the time is set correctly, especially the AM/PM cycle. The date typically changes around midnight. If the date is stuck, try manually advancing it using the crown (first click position).
- **Chronograph Not Resetting to Zero:** If the chronograph hands do not reset to the 12 o'clock position, consult a professional watch repair service.
- **Water Inside the Watch:** If you notice condensation or water inside the watch, immediately take it to a professional watch repair service to prevent further damage.

7. SPECIFICATIONS

Feature	Specification
Model Name	POEDAGAR 629
Movement Type	Quartz
Display Type	Analog
Case Material	Stainless Steel
Case Diameter	42 mm
Case Thickness	12 mm
Band Material	Stainless Steel
Band Width	25 mm
Crystal Material	Mineral Glass
Water Resistance Depth	30 Metres (3ATM)
Special Features	Chronograph, Glow In The Dark, Scratch-Resistant, Bezel Markings
Clasp Type	Buckle
Item Weight	100 Grams

Feature	Specification
---------	---------------

8. WARRANTY AND SUPPORT

8.1 Warranty Information

This Poedagar watch comes with a manufacturer's warranty. Please retain your purchase receipt as proof of purchase. For specific warranty terms and conditions, refer to the documentation provided with your watch at the time of purchase.

8.2 Customer Support

For any questions, service, or support regarding your Poedagar 629 watch, please contact the importer/packer:

Vasmyst
11/268 Civil Lines
Kanpur - 208001
UP, India

When contacting support, please have your watch model number (629) and purchase details readily available.