

Ziitty X6

Ziitty Fabric Shaver X6 Instruction Manual

1. INTRODUCTION

This manual provides detailed instructions for the safe and effective use of your Ziitty Fabric Shaver X6. Please read all instructions carefully before operating the device and retain this manual for future reference. The Ziitty Fabric Shaver is designed to remove lint, pills, and fuzz from various fabrics, restoring their appearance.

2. PRODUCT OVERVIEW

The Ziitty Fabric Shaver X6 is a portable, rechargeable device equipped with advanced features for efficient fabric care.

- **LCD Screen:** Displays current battery level and speed settings.
- **3-Phase Speed Settings:** Adjustable speeds suitable for different fabric types.
- **6-Blade Cutting Head:** Powerful motor and sharp blades for effective lint removal.
- **Metal Mesh:** Features 3 sizes of holes to capture various lint sizes, protecting fabric from damage.
- **Lint Collection Box:** Gathers removed lint for easy disposal.
- **Type-C Rechargeable:** Fast charging and long-lasting battery life.
- **Safety Lock Function:** Device stops automatically when the lid is open or loose.

A hand holds a black Ziitty Fabric Shaver X6 over a piece of brown fabric. The device has a small LCD screen and a power button. A blue light is visible from the shaver head. The background is a light pinkish-white.

Ziitty

FABRIC SHAVER

Make All Your Garment Look Like New !



5W Powerful Motor



6-Blade Cutting Head



1500 mAh Battery



Gear Adjustment

Figure 1: Ziitty Fabric Shaver X6 highlighting its LCD display, 1500mAh built-in battery, 1.5-hour charging time, and one-week battery life.

3. SETUP

Upon receiving your Ziitty Fabric Shaver X6, please verify the contents of the package:

- 1 x Lint Remover (Model X6)
- 3 x Replacement Blades (one pre-installed)
- 1 x Type-C Charging Cable
- 1 x Cleaning Brush
- 1 x Instruction Manual

Before first use, fully charge the device using the provided Type-C charging cable.

4. CHARGING

The Ziitty Fabric Shaver X6 features a Type-C rechargeable design for convenience and efficiency.

- Connect the Type-C charging cable to the charging port on the device.
- Plug the USB end of the cable into a compatible power source (e.g., USB adapter, computer USB port).
- The LCD display will indicate the charging status and battery level.
- A full charge typically takes approximately 1.5 hours and provides up to one week of battery life, depending on usage.

5. OPERATING INSTRUCTIONS

Follow these steps for effective lint and pill removal:

1. **Prepare the Garment:** Lay the garment flat on a hard, smooth surface before lint removal to ensure even contact and prevent damage.
2. **Power On:** Press the power button on the device. The LCD display will illuminate, showing the current battery quantity and speed setting.
3. **Adjust Speed:** Press the power button again to cycle through the 3-speed settings. Select a speed appropriate for your fabric type. Lower speeds are suitable for delicate fabrics, while higher speeds are for tougher materials or stubborn pills.

4. **Begin Shaving:** Gently glide the shaver head over the fabric surface, applying light pressure. Move the device in circular motions or back and forth over the affected areas.
5. **Monitor Progress:** Observe the fabric as you work. For very fine or deeply embedded lint, multiple passes or a higher speed setting may be required.
6. **Power Off:** Once finished, press and hold the power button to turn off the device.



Figure 2: Visual demonstration of fabric pilling before and after using the Ziitty Fabric Shaver.

5.1 Suitable Fabrics

The 3-speed lint remover is suitable for various fabrics, including:

- Sweaters
- Sofas
- Blankets
- Curtains
- Winter Coats
- Scarves
- Gloves
- Stuffed Animals
- Bedding and Sheets

COMPACT AND LIGHTWEIGHT

Easy Grip and Go!

Figure 3: The Ziitty Fabric Shaver is versatile for use on a wide range of textiles.

5.2 Instructional Videos

Video 1: Demonstrates the effectiveness of the lint remover on various fabrics.

Video 2: Shows how to revive clothes and effortlessly remove pills.

Video 3: Guide on refreshing clothes quickly by removing pills.

6. MAINTENANCE AND CLEANING

Regular maintenance ensures optimal performance and longevity of your fabric shaver.

1. **Empty Lint Collection Box:** The device features a transparent lint collection box. Regularly slide it open and empty the accumulated lint.
2. **Clean Blades:** Use the provided small cleaning brush to remove any lint or debris caught around the 6-blade cutting head.
3. **Replace Blades:** The package includes 3 replacement blades. To replace, carefully twist off the metal mesh cover, remove the old blade, and install a new one. Ensure the new blade is securely in place before reattaching the cover.
4. **Wipe Exterior:** Clean the exterior of the device with a soft, dry cloth. Do not use water or harsh chemicals.




Figure 4: The Ziitty Fabric Shaver comes with a cleaning brush and replacement blades for easy maintenance.

7. TROUBLESHOOTING

If you encounter issues with your Ziitty Fabric Shaver, consider the following:

- **Device Not Turning On:** Ensure the device is fully charged. Connect it to the Type-C charging cable and allow it to charge for at least 1.5 hours.
- **Ineffective Lint Removal:**
 - Check if the lint collection box is full and empty it if necessary.
 - Clean the blades and metal mesh with the provided brush to remove any obstructions.
 - Ensure the metal mesh cover is securely closed; the safety lock prevents operation if it's loose.
 - For stubborn pills, try switching to a higher speed setting.
 - Ensure the garment is laid flat and taut for optimal contact with the shaver head.
- **Device Stops During Use:** This may be due to the safety lock function. Check if the metal mesh cover is open or loose and secure it properly.

8. SPECIFICATIONS

Brand	Ziitty
Model Number	X6
Material	Stainless Steel (Blades), Plastic (Handle)
Color	Light Black
Operation Mode	Automatic
Item Weight	9.6 ounces
Package Dimensions	5.79 x 3.66 x 2.32 inches
UPC	722549919444

9. SAFETY INFORMATION

To ensure safe operation and prevent injury or damage, please adhere to the following safety guidelines:

- Keep the device out of reach of children.
- Do not use the fabric shaver directly on skin.
- Ensure the metal mesh cover is securely closed before operating the device. The safety lock prevents the blades from spinning if the cover is not properly attached.
- Do not use damaged blades or mesh covers. Replace them immediately if damaged.
- Avoid charging the device in extreme temperatures (below 5°C or above 35°C) or near direct sunlight, heating appliances, or incandescent lamps, as this may lead to deformation or fire.
- When cleaning, dilute neutral detergent with water first, then dip a cloth in it before wiping the dirt. Do not use banana water or gasoline, which may cause damage to plastic parts, fire, or electric shock.

10. WARRANTY AND SUPPORT

For any product-related inquiries, technical support, or warranty information, please refer to the contact details provided with your purchase or visit the official Ziitty brand store.

Note: Always lay the garment flat before lint removal. For very fine, scattered "lint fuzz" or "nascent lint pills" that cling tightly to the fabric surface and have not yet fully risen, they are embedded deep within the fibers and may require multiple passes for complete removal. If stubborn residue persists, switch to a higher-speed setting for more effective cleaning.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

