

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [LIFETIME](#) /

› [Lifetime 91382 Big Stuff Adventure Clubhouse Double Slide Instruction Manual](#)

LIFETIME 91382

Lifetime 91382 Big Stuff Adventure Clubhouse Double Slide

Model: 91382 | Brand: LIFETIME

INTRODUCTION

This manual provides essential information for the safe assembly, operation, and maintenance of your Lifetime 91382 Big Stuff Adventure Clubhouse Double Slide. Please read all instructions carefully before beginning assembly and retain this manual for future reference.

SAFETY INFORMATION

The safety of children is paramount. Adult supervision is required at all times when children are using the playground equipment. Ensure the play area is clear of obstacles and has adequate safety surfacing. This product is designed for residential use only. Always inspect the equipment before each use for any loose parts, damage, or wear.

- Ensure all bolts and fasteners are securely tightened.
- Do not allow children to wear loose clothing or jewelry that could get caught on the equipment.
- Maintain a safe distance from other children and moving parts.
- Do not use the equipment in wet conditions or extreme weather.
- Ensure the ground beneath the equipment is level and free of debris.

SETUP AND ASSEMBLY

Assembly of the Lifetime 91382 Big Stuff Adventure Clubhouse Double Slide is required. Refer to the detailed assembly instructions provided in the product packaging for step-by-step guidance. This playset is designed to be free-standing and does not require cement for installation, provided it is placed on a level surface.



Figure 1: Fully assembled Lifetime 91382 Big Stuff Adventure Clubhouse Double Slide.



Figure 2: Alternate view highlighting the climbing wall and swing set components.

Dimensions

Understanding the dimensions is crucial for proper placement and ensuring adequate safety clearance around the playset.




Figure 3: Top-down view with overall length dimension.




Figure 4: Side view with width and height dimensions.

OPERATING INSTRUCTIONS

The Lifetime 91382 Big Stuff Adventure Clubhouse offers multiple play features. Ensure children understand how to use each component safely and appropriately for their age and skill level.

Double Wavy Slides

The playset features two 9-foot wavy slides. Children should slide feet first, one at a time, and ensure the landing area is clear before descending.



Figure 5: Children using the double wavy slides.

Climbing Wall

The integrated climbing wall provides an alternative ascent to the clubhouse platform. Children should use handholds and footholds securely and maintain three points of contact when climbing.



Figure 6: Child utilizing the climbing wall.

Swings and Trapeze Bar

The playset includes two belt swings and a trapeze bar. Ensure children swing in a controlled manner, avoiding excessive height or twisting. The spider swing allows multiple children to swing together.



Figure 7: Child on the mini go-round swing.

Clubhouse Features

The clubhouse features a ship's wheel and binoculars for imaginative play. These accessories are designed for interactive engagement on the platform.



Figure 8: Child engaging in imaginative play on the clubhouse platform.

Product Overview Video

Watch this video for a visual overview of the Lifetime 91382 Big Stuff Adventure Clubhouse and its various features in use.

Your browser does not support the video tag.

Video 1: Overview of the Lifetime 91382 Playground Big Stuff Adventure Clubhouse, demonstrating its features and play elements.

MAINTENANCE

The Lifetime 91382 Big Stuff Adventure Clubhouse is constructed from High Density Polyethylene and is designed for low maintenance, requiring no staining or painting. Regular inspection and cleaning will ensure its longevity and safety.

- **Regular Inspection:** Periodically check all nuts, bolts, and other fasteners for tightness. Tighten as necessary.
- **Cleaning:** Clean plastic surfaces with mild soap and water. Avoid abrasive cleaners that could damage

the material.

- **Wear and Tear:** Inspect all components, especially moving parts like swings and chains, for signs of wear, rust, or damage. Replace worn or damaged parts immediately.
- **Grounding:** Ensure the playset remains stable and level on its intended surface.

TROUBLESHOOTING

If you encounter any issues with your Lifetime 91382 playset, consider the following common troubleshooting steps:

- **Playset Instability:** Check that the playset is on a level surface. Verify all frame connections and bolts are securely tightened.
- **Squeaking Swings:** Apply a small amount of lubricant to the swing hangers or chain connections.
- **Damaged Parts:** If any part is broken or severely worn, discontinue use immediately and contact customer support for replacement parts. Do not attempt to repair damaged structural components yourself.

SPECIFICATIONS

Feature	Detail
Model Number	91382
Brand	LIFETIME
Material	High Density Polyethylene
Color	Jay Blue
Product Dimensions (L x W x H)	180"L x 168"W x 132"H
Maximum Weight Recommendation	1000 Pounds
Required Assembly	Yes
GTIN/UPC	081483837550

WARRANTY INFORMATION

The Lifetime 91382 Big Stuff Adventure Clubhouse Double Slide comes with a 5-year manufacturer's warranty. Please refer to the warranty card included with your product for specific terms, conditions, and registration details. Keep your proof of purchase for warranty claims.

SUPPORT

For further assistance, replacement parts, or any questions not covered in this manual, please contact LIFETIME customer support. Contact information can typically be found on the manufacturer's website or on the product packaging.

LIFETIME Customer Support: Please visit the official LIFETIME website or refer to your product packaging for current contact details.

© 2023 LIFETIME. All rights reserved.