



Manuals.plus /

- › Reaks /
- › Reaks Electric Heated Throw Blanket User Manual (Grey, 50x60 inches)


Reaks B0FD2YVWRN

Reaks Electric Heated Throw Blanket User Manual

Model: B0FD2YVWRN | Brand: Reaks

INTRODUCTION

Welcome to your new Reaks Electric Heated Throw Blanket. This manual provides essential information for safe and effective use, setup, operation, and maintenance of your blanket. This blanket features silky soft flannel and sherpa fabrics, 5 heat levels, and a 3-hour auto-off function for your comfort and safety.



A user enjoying the Reaks Electric Heated Throw Blanket on a couch, demonstrating its comfortable use.

IMPORTANT SAFETY INFORMATION

Read all instructions carefully before using this electric heated throw blanket. Failure to follow these instructions may result in fire, electric shock, or injury.

Safety Certifications

This Reaks heated throw blanket is ETL and FCC safety certified, meeting rigorous safety standards for your peace of mind.


Overheat Protection

The blanket is equipped with a 3-hour auto-off feature to prevent overheating and ensure safe operation, automatically turning off after this period.

General Safety Precautions

- Do not use with infants, children, incapacitated individuals, or persons insensitive to heat.
- Do not use with pets.
- Do not use if wet.

- Do not use with pointed objects.
- Do not use if the power cord or controller is damaged.
- Always unplug the blanket when not in use.



This diagram illustrates the multi-layered construction of the blanket, including the soft flannel surface, heating wire fixing layer, advanced heating wire, and extra comfort sherpa back, all designed for safety and warmth. ETL and FCC certifications are prominently displayed.

SETUP

Before first use, ensure the blanket and controller are free from damage.

Connecting the Controller

1. Locate the connector on the blanket.
2. Align the controller's plug with the blanket's connector.
3. Push firmly until the plug is securely inserted.
4. Plug the power cord into a standard electrical outlet.

ENJOY THE WARMTH WITH YOUR LOVED ONES



This image demonstrates how to securely connect the detachable controller to the electric blanket. The controller features a simple plug-in design for easy attachment and removal.

OPERATING INSTRUCTIONS

Power On/Off

Press the power button on the controller to turn the blanket on or off.

Adjusting Heat Levels

The blanket offers 5 precise heating levels, ranging from 86°F to 113°F. Use the '+' and '-' buttons on the controller to cycle through the heat settings.

- Level 1: Gentle warmth (86°F)
- Level 5: Maximum heat (113°F)

Automatic Shut-Off

For safety and energy conservation, the blanket will automatically turn off after 3 hours of continuous use. To restart, simply press the power button again.

ONE BUTTON CONTROL

86°F  113°F


3
HOURS
Auto Off


5 HEATING
LEVELS



Anti-Accidental
Touch



Lightweight



Lower Failure
Rate



Easy for
All Ages

This image highlights the intuitive controller with a single power button and indicators for 5 heat levels. It also shows the 3-hour auto-off function, designed for user convenience and safety.

MAINTENANCE

Washing Instructions

The Reaks Electric Heated Throw Blanket is machine washable. Follow these steps carefully to ensure longevity and proper function:

1. Always disconnect the controller and power cord from the blanket before washing.
2. Pre-soak the blanket for 15 minutes in cold water with mild soap.
3. Machine wash on a gentle or delicate cycle with cold water. Do not bleach.
4. Rinse thoroughly.
5. Tumble dry on low heat or air dry. Ensure the blanket is completely dry before reconnecting the controller or storing.

Storage

When not in use, store the blanket in a cool, dry place. Avoid folding tightly or placing heavy objects on it, which could damage the heating wires.



This image shows the electric blanket being washed in a machine, illustrating its easy-care design. A callout highlights the 'Upgraded Connector' for secure fit and easy plug/unplug before washing.

TROUBLESHOOTING

If your Reaks Electric Heated Throw Blanket is not functioning as expected, please check the following:

- Ensure the power cord is securely plugged into both the blanket and the wall outlet.
- Verify that the wall outlet is functional by plugging in another appliance.
- If the blanket has automatically shut off, press the power button to restart it.
- If issues persist, please refer to the Warranty & Support section for assistance.

SPECIFICATIONS

Feature	Detail
Material	Sherpa, Flannel
Color	Grey
Brand	Reaks
Special Feature	Corded, Machine Washable, Skin Friendly
Style	Modern
Blanket Form	Throw Blanket
Age Range (Description)	Adult
Product Dimensions	60"L x 50"W
Theme	Striped
Pattern	Striped
Recommended Uses For Product	Napping, Reading, Travel
Seasons	Fall, Spring, Winter
Fill Material	Polyester
Product Care Instructions	Machine Wash
Size	Throw 50"×60"
Unit Count	1.0 Count
Number of Items	1
Included Components	1 Electric Blanket (50" x 60"), 1 Controller
Fabric Warmth Description	Lightweight
Manufacturer	Zhejiang Goodwill Textile Co., LTD
Item Weight	3.16 pounds
ASIN	B0FD2YVWRN
Date First Available	June 13, 2025

WARRANTY & SUPPORT

Reaks is committed to your satisfaction. If you encounter any issues or are not fully satisfied with your electric heated throw blanket, please contact our dedicated support team.

Contact information can typically be found on the product packaging or the official Reaks website. We are here to help resolve your concerns quickly.

