

Murago Outdoor Patio Swing Chair B0FD2Z789F

Murago Outdoor Patio Swing Chair Instruction Manual

Model: B0FD2Z789F

1. INTRODUCTION

Thank you for choosing the Murago Outdoor Patio Swing Chair. This manual provides essential information for the safe assembly, operation, and maintenance of your new swing chair. Please read all instructions carefully before beginning assembly or use.

The Murago Outdoor Patio Swing Chair features an adjustable canopy, a heavy-duty alloy steel frame, and weather-resistant cushions designed for comfort and durability in various outdoor settings.

2. SAFETY INSTRUCTIONS

- Read and understand all instructions before assembly and use.
- Keep children and pets away from the assembly area to prevent injury.
- Ensure all bolts, nuts, and fasteners are securely tightened before each use. Loose fittings can cause instability.
- Do not exceed the maximum weight capacity of 500 lbs (approximately 3 adult persons). Distribute weight evenly.
- Place the swing chair on a flat, stable, and level surface to prevent tipping.
- Do not use the swing chair in strong winds, heavy rain, or other extreme weather conditions.
- Regularly inspect the swing chair for any signs of wear, damage, or loose components. Discontinue use if damage is found and contact customer service.
- Avoid standing on the swing chair or using it as a ladder.

3. PACKAGE CONTENTS

Before assembly, ensure all parts are present and undamaged. If any parts are missing or damaged, do not

proceed with assembly and contact customer service.

- Swing chair frame components
- Seat and backrest fabric/cushions
- Adjustable canopy fabric and frame
- Hardware kit (bolts, nuts, washers)
- Assembly tool
- Instruction manual

4. ASSEMBLY INSTRUCTIONS

Assembly typically takes approximately 1 hour. Follow the fully illustrated, step-by-step instructions provided in the package. An assembly tool is included.

1. **Unpack and Identify Parts:** Carefully remove all components from the packaging. Lay them out and compare them against the parts list in your included manual to ensure everything is present.
2. **Assemble the Main Frame:** Begin by connecting the base and upright support bars. Ensure all connections are finger-tightened initially.
3. **Attach the Seat Frame:** Secure the seat frame to the main support structure.
4. **Install the Seat and Backrest:** Attach the seat and backrest cushions or fabric to the seat frame.
5. **Assemble and Attach the Canopy Frame:** Construct the canopy frame and then attach it to the top of the main swing frame.
6. **Install the Canopy Fabric:** Drape and secure the adjustable canopy fabric over its frame.
7. **Final Tightening:** Once all components are in place, systematically tighten all bolts and fasteners using the provided tool. Do not overtighten to avoid damaging the metal.



Figure 4.1: This diagram illustrates the overall dimensions of the swing chair, including height, width, and depth, as well as seat and canopy measurements. Refer to these dimensions for placement and space requirements.

Rugged Reliability



Better materials make better products



Stainless Steel Springs



2x Powder Coated



Oversized Foot Pads

Figure 4.2: Key construction elements include stainless steel springs for smooth gliding, a double powder-coated frame for enhanced rust prevention, and oversized foot pads for improved stability on various surfaces. Ensure these components are correctly assembled.

5. OPERATING INSTRUCTIONS

The Murago Outdoor Patio Swing Chair is designed for relaxing with a smooth, quiet, and effortless gliding motion.

- **Using the Swing:** Sit gently on the seat and initiate a gentle back-and-forth motion. Avoid excessive force or sudden movements.
- **Adjusting the Canopy:** The multi-adjustable canopy can be tilted to minimize sun exposure or provide shelter from light rain. Adjust the canopy angle by loosening the knobs on the side supports, positioning the canopy to your desired angle (up to 60 degrees), and then tightening the knobs securely.

Adjustable Canopy W/Sunshade Angle



Figure 5.1: The canopy can be adjusted up to 60 degrees to provide optimal shade and protection from sun or light rain. It is made from waterproof and UV-resistant material.

A Family Happy Moments



Load Capacity



Seats up to 3

Figure 5.2: The swing chair is designed to comfortably accommodate up to three adults, with a maximum load capacity of 500 pounds. Ensure weight is distributed evenly across the seat.

6. MAINTENANCE

Proper maintenance will extend the life and appearance of your swing chair.

- **Cleaning the Frame:** The alloy steel frame features a proprietary 2-step powder coating for rust prevention. Clean the frame with a soft cloth and mild soap and water. Rinse thoroughly and dry completely to prevent water spots.
- **Cleaning Cushions and Canopy:** The thick cushions and adjustable canopy are weather-resistant and treated for enhanced UV life. Clean them with a soft brush or cloth, mild soap, and water. Allow to air dry completely before storage or continued use.
- **Regular Inspection:** Periodically check all bolts and fasteners to ensure they remain tight. Inspect the frame, springs, cushions, and canopy for any signs of wear, tears, or damage.
- **Winter Storage:** During off-seasons or prolonged periods of non-use, it is recommended to store the swing chair in a dry, protected area to prolong its lifespan.

Thick All-Weather Cushions



Comfort



All-weather



Anti-tear Fabric




Figure 6.1: The swing features thick, weather-resistant cushions made from anti-tear fabric, providing comfort and durability in various outdoor conditions. Regular cleaning helps maintain their quality.

7. TROUBLESHOOTING

- **Squeaking during operation:** Check all frame connections and bolts. Tighten any loose fasteners. Applying a silicone-based lubricant to moving parts (springs, pivot points) may help.
- **Swing feels unstable:** Ensure the swing chair is placed on a completely flat and level surface. Re-check and tighten all assembly bolts.
- **Canopy does not stay in position:** Ensure the adjustment knobs on the canopy supports are fully tightened after positioning.
- **Difficulty with assembly:** Review the assembly instructions carefully. Ensure all parts are oriented correctly. If issues persist, contact customer service for assistance.

8. SPECIFICATIONS

- **Brand:** Murago
- **Model:** Outdoor Patio Swing Chair (B0FD2Z789F)
- **Color:** Black

- **Material:** Alloy Steel (Frame), Weather-resistant fabric (Cushions, Canopy)
- **Product Dimensions (D x W x H):** 19" x 68.5" x 60"
- **Frame Finish:** Powder Coated (2-step process)
- **Maximum Seating Capacity:** 3 persons
- **Weight Capacity:** 500 lbs
- **Assembly Required:** Yes

9. WARRANTY AND SUPPORT

Murago is committed to providing quality products and customer satisfaction. While specific warranty details are not included in this manual, please refer to your purchase documentation or contact the seller for information regarding warranty coverage.

For any questions, missing parts, assembly assistance, or troubleshooting not covered in this manual, please contact Murago customer service. Our responsive team is available to help resolve any issues you may encounter.

Customer Service Contact: Please refer to the contact information provided with your purchase or visit the official Murago website.