

[manuals.plus](#) /› [FASTWD](#) /› [FASTWD Android 15 Tablet 11-inch User Manual \(Model M986\)](#)

## FASTWD M986

# FASTWD Android 15 Tablet 11-inch User Manual

Model: M986

Brand: FASTWD

## 1. INTRODUCTION

This manual provides essential information for the safe and efficient operation of your FASTWD Android 15 Tablet 11-inch. Please read this manual thoroughly before using the device and retain it for future reference. This tablet features an 11-inch 2K display, Android 15 operating system, Octa-Core processor, 36GB RAM, 256GB ROM (expandable up to 1TB), 4G LTE, and 5G WiFi connectivity.

## 2. SAFETY INFORMATION

- Do not expose the tablet to extreme temperatures, direct sunlight, or high humidity.
- Avoid dropping or subjecting the tablet to strong impacts.
- Use only approved chargers and accessories to prevent damage and ensure safety.
- Keep the tablet away from water and other liquids.
- Do not attempt to disassemble or repair the tablet yourself. Contact customer support for assistance.
- Dispose of the battery and device according to local regulations.

## 3. PACKAGE CONTENTS

Upon opening your FASTWD Android 15 Tablet package, please verify that all the following items are included:

- FASTWD Tablet
- Bluetooth Keyboard
- Mouse
- Protective Case
- Stylus Pen
- Type-C Cable
- Charger

- User Manual



Image: The FASTWD Android 15 Tablet displayed with its full set of accessories, including the keyboard, mouse, protective case, stylus, and charging components.

## 4. DEVICE OVERVIEW

The FASTWD Android 15 Tablet features a sleek metal body with an 11-inch 2K INCell display. It is designed for both productivity and entertainment.

### 4.1 Physical Features

- **Display:** 11-inch 2K UHD INCell display with 120Hz refresh rate.
- **Cameras:** 8MP front camera, 13MP rear camera with LED flash.
- **Ports:** USB Type-C port for charging and data transfer.
- **Card Slot:** Dual SIM card slot, also supports MicroSD card expansion up to 1TB.
- **Speakers:** Four amplitude speakers for enhanced audio.

Image: A visual representation of the FASTWD tablet's slim design, 11-inch screen, and Type-C charging port.

## 5. SETUP

### 5.1 Initial Power On

1. Press and hold the Power button located on the side of the tablet until the FASTWD logo appears.
2. Follow the on-screen prompts to select your language, region, and connect to a Wi-Fi network.
3. Sign in with your Google account or create a new one to access the Google Play Store and other services.

### 5.2 SIM Card and MicroSD Card Installation

Your tablet supports dual SIM cards for 4G LTE connectivity and a MicroSD card for expanded storage.

1. Locate the SIM/MicroSD card tray on the side of the tablet.
2. Use the provided SIM ejector tool to gently push into the small hole next to the tray until it pops out.
3. Place your Nano-SIM card(s) and/or MicroSD card into the designated slots on the tray. Ensure they are correctly oriented.
4. Carefully reinsert the tray into the tablet until it clicks into place.



Image: A detailed view of the tablet's SIM card tray, showing slots for two SIM cards and one MicroSD card.

## 6. OPERATING INSTRUCTIONS

The FASTWD tablet runs on Android 15, offering an intuitive and customizable user experience.

### 6.1 Basic Navigation

- **Swipe Up:** Access the app drawer.
- **Swipe Down:** Open the notification panel and quick settings.
- **Tap:** Select items or open applications.
- **Long Press:** Access contextual menus or move icons.
- **Pinch-to-Zoom:** Adjust zoom level in apps like browser or gallery.

### 6.2 Android 15 Features

Android 15 introduces several enhancements for privacy, security, and user experience:

- **Improved Privacy Controls:** Granular permissions for apps, allowing you to authorize access more precisely.
- **AI Optimization:** Intelligent AI features for improved performance and battery life.
- **Gesture Navigation:** New touch control gestures for a more fluid interaction.
- **Global Dark Mode:** System-wide dark theme for reduced eye strain and power consumption.
- **Face Recognition Unlock:** Securely unlock your tablet using facial recognition.
- **Parental Controls:** Manage screen time and app access for children.
- **Split Screen:** Use two applications simultaneously side-by-side.



Image: A visual guide to key Android 15 features such as easy app pairing, storage management, quick Bluetooth connection, face recognition unlock, double-tap to wake, and parental control settings.

## 7. CONNECTIVITY

Your FASTWD tablet offers versatile connectivity options for internet access and peripheral devices.

## 7.1 Wi-Fi Connection

1. Go to **Settings > Network & internet > Wi-Fi**.
2. Toggle Wi-Fi **On**.
3. Select your desired network from the list and enter the password if prompted.
4. The tablet supports dual-band 2.4G/5G Wi-Fi for stable and fast connections.

## 7.2 4G LTE Mobile Data

With a compatible SIM card installed, you can access 4G LTE mobile data.

1. Ensure your SIM card is correctly installed (refer to Section 5.2).
2. Go to **Settings > Network & internet > Mobile network**.
3. Enable **Mobile data** and configure APN settings if required by your carrier.

## 7.3 Bluetooth Pairing

Connect Bluetooth accessories like the included keyboard and mouse.

1. Go to **Settings > Connected devices > Bluetooth**.
2. Toggle Bluetooth **On**.
3. Put your Bluetooth accessory into pairing mode.
4. Select the accessory from the list of available devices and follow any on-screen prompts to complete pairing.




Image: The FASTWD tablet connected to its keyboard and mouse, illustrating its 2.4G+5G WiFi, Bluetooth 5.0, and 4G LTE SIM support for comprehensive connectivity.

## 8. CAMERA

The tablet is equipped with an 8MP front camera and a 13MP rear camera for photos and video calls.

1. Open the **Camera** application.
2. Tap the shutter button to take a photo.
3. Switch between front and rear cameras using the camera toggle icon.
4. AI post-processing technology enhances photo quality, making images more realistic.

**Android 15 Tablet**



Screenshot detection  
  Multi-tasking window  
 Lock screen custom elements  
  AI Smart Detection

**FASTWD 11-inch tablet**




Maximum Screen Size  
**11 inches**  
  **FHD 2000\*1200 FHD resolution**  
 **16:10 Screen Ratio**  
 **Wear-resistant and sweat-resistant**  
**Wide Viewing Angle Incell Display**

**Sleek, Lightweight Metal Body**



Metal body  
**Straight Edge**  
  Display Bezel  
**7.8 mm**  
  Slim and portable  
**568g**

**Worry-free charging**



Large battery  
**9580mAh**  
  Convenient charging  
**Type-C**

Image: A detailed view of the tablet's rear camera, highlighting its 13MP sensor and AI Camera branding.

## 9. BATTERY MANAGEMENT

The tablet features a 9580mAh battery for extended usage and supports 12W fast charging.

### 9.1 Charging the Tablet

1. Connect the Type-C cable to the tablet's charging port.
2. Plug the other end of the cable into the provided charger, and then into a power outlet.
3. The battery icon on the screen will indicate charging status.

### 9.2 Battery Optimization

- Adjust screen brightness to a comfortable level.

- Close unused applications running in the background.
- Enable battery saver mode in **Settings > Battery**.
- Disable Wi-Fi, Bluetooth, or GPS when not in use.

Image: The FASTWD tablet connected to a Type-C charger, illustrating its 9580 mAh battery and 12W fast charging capability.

## 10. STORAGE

The tablet comes with 256GB of internal storage (ROM) and supports expansion up to 1TB via a MicroSD card.

### 10.1 Managing Storage

- To check storage usage, go to **Settings > Storage**.
- You can free up space by uninstalling unused apps, deleting old files, or moving media to a MicroSD card.

### 10.2 RAM Management

The tablet features 36GB RAM (12GB LPDDR4 + 24GB expandable virtual memory) for smooth multitasking.

- The system automatically manages RAM for optimal performance.
- You can activate additional virtual RAM in the settings if needed for demanding applications.



Image: An illustration highlighting the tablet's 36GB RAM (12+24GB), 256GB ROM, and 1TB MicroSD expansion capabilities, alongside its Octa-core processor.

## 11. MAINTENANCE

### 11.1 Cleaning

- Use a soft, lint-free cloth to clean the screen and body of the tablet.
- Do not use harsh chemicals or abrasive materials.

## 11.2 Software Updates

- Regularly check for system updates in **Settings > System > System update** to ensure optimal performance and security.

## 12. TROUBLESHOOTING

If you encounter issues with your tablet, refer to the following common solutions:

Problem	Solution
Tablet does not power on	Ensure the battery is charged. Connect the charger and wait a few minutes before attempting to power on again. If unresponsive, perform a forced restart by holding the Power button for 10-15 seconds.
Applications crash or freeze	Close background applications. Clear the cache of the problematic app (Settings > Apps > [App Name] > Storage & cache > Clear cache). Restart the tablet.
Poor Wi-Fi connection	Ensure you are within range of the Wi-Fi router. Restart your router and the tablet. Forget the network and reconnect.
SIM card not detected	Ensure the SIM card is correctly inserted into the tray. Restart the tablet. Verify the SIM card is active with your mobile carrier.
Battery drains quickly	Reduce screen brightness. Disable unused connectivity features (Wi-Fi, Bluetooth, GPS). Close background apps. Check for apps consuming excessive battery in Settings > Battery.

## 13. SPECIFICATIONS

Detailed technical specifications for the FASTWD Android 15 Tablet 11-inch (Model M986):

Feature	Specification
Brand	FASTWD
Model Name	FASTWD Android 15 Tablet 11 Pulgadas
Operating System	Android 15
Processor Speed	2 GHz Octa-Core
RAM	36 GB (12GB LPDDR4 + 24GB expandable)
Internal Storage (ROM)	256 GB

Feature	Specification
Expandable Storage	Up to 1 TB via MicroSD card
Screen Size	11 Pulgadas (Inches)
Screen Resolution	2560 x 1440 pixels (2K UHD INCell)
Refresh Rate	120 Hz
Rear Camera	13 MP
Front Camera	8 MP
Battery Capacity	9580 mAh
Battery Life (average)	8 Hours (video playback)
Charging	12W Fast Charging, Type-C Interface
Connectivity	4G LTE (Cellular), 5G Wi-Fi (802.11ac), Bluetooth 5.0
Dimensions	29.7 x 19.6 x 4 cm
Weight	1.36 kg
Special Features	Gaming Tablet, Face Recognition, Parental Control, GPS (Beidou, Galileo, Glonass, GPS)

## 14. WARRANTY AND SUPPORT

FASTWD offers two years of premium after-sales service and long-term technical support for your tablet.

- Warranty Period:** 2 years from the date of purchase.
- Technical Support:** For any issues or inquiries, please contact the FASTWD after-sales team through your Amazon purchase platform.
- Our support team aims to respond within 24 hours.

© 2025 FASTWD. All rights reserved.

## Related Documents - M986

 Please read the manual before using the product.	<b><a href="#">FASTWD Tablet User Manual</a></b> Comprehensive user manual for the FASTWD Tablet, covering setup, features, troubleshooting, and warranty information. Learn how to get started, navigate the home screen, manage settings, connect to networks, and troubleshoot common issues.
---	---

<p><b>English</b></p> <p><b>Important Information</b></p> <ol style="list-style-type: none"> <li>1. Clean the screen to be protected.</li> <li>2. Align the screen protector with the screen.</li> <li>3. Place the screen protector on the screen. If there are any bubbles, use the adhesive tape to remove them.</li> <li>4. If there are any bubbles left, use the adhesive tape to remove them.</li> <li>5. If there is a crease, turn the film in the crease 90° and then the film.</li> <li>6. If there is a crease, turn the film in the crease 90° and then the film.</li> </ol> <p><b>Deutsch</b></p> <p><b>Wichtiges</b></p> <ol style="list-style-type: none"> <li>1. Reinigen Sie die zu schützende Bildschirmeoberfläche.</li> <li>2. Positionieren Sie die Bildschirmschutzfolie exakt auf dem Bildschirm.</li> <li>3. Legen Sie die Bildschirmschutzfolie auf den Bildschirm. Sollten auf der Folie Blasen entstehen, entfernen Sie diese mit Klebefolie.</li> <li>4. Sollten auf der Folie noch Blasen verbleiben, entfernen Sie diese mit Klebefolie.</li> <li>5. Sollten auf der Folie eine Falte entstehen, drehen Sie die Folie in der Falte 90° und drehen Sie die Folie wieder zurück.</li> <li>6. Sollten auf der Folie eine Falte entstehen, drehen Sie die Folie in der Falte 90° und drehen Sie die Folie wieder zurück.</li> </ol> <p><b>Italiano</b></p> <ol style="list-style-type: none"> <li>1. Pulire la superficie dello schermo da proteggere.</li> <li>2. Allineare la pellicola protettiva dello schermo con lo schermo.</li> <li>3. Posizionare la pellicola protettiva sullo schermo. Se ci sono bolle, rimuoverele con la nastro adesivo.</li> <li>4. Se ci sono bolle rimanenti, rimuoverele con il nastro adesivo.</li> <li>5. Se c'è una piega, ruotare la pellicola 90° intorno alla piega e quindi la pellicola.</li> <li>6. Se c'è una piega, ruotare la pellicola 90° intorno alla piega e quindi la pellicola.</li> </ol>	<p><b>How to Install a Tablet Screen Protector: Step-by-Step Guide</b></p> <p>Concise guide on installing a screen protector on your tablet, covering cleaning, alignment, and bubble removal. Suitable for TOSCIDO, YUMKEM, HEASUR, and other compatible tablets.</p>
	<p><b>KOMPAN Riesen-Dinoschaukel (Giant Dinosaur Swing) M986 - Product Overview</b></p> <p>Explore the KOMPAN Riesen-Dinoschaukel (Giant Dinosaur Swing) M986, a robust and engaging playground swing for children aged 6 and above. This document details its dimensions, features, safety certifications, material specifications, installation requirements, warranty, and environmental impact.</p>
	<p><b>KOMPAN Columpio Dino Gigante (M986) - Información del Producto</b></p> <p>Información detallada sobre el Columpio Dino Gigante (M986) de KOMPAN, un columpio de nido grande diseñado para el juego social y activo, que promueve el equilibrio, la coordinación y las habilidades sociales en los niños. Incluye especificaciones, materiales y datos de sostenibilidad.</p>