



[Manuals.plus](#) /

› [Byobyc](#) /

› Byobyc T7 Wireless Earbuds User Manual

Byobyc T7

Byobyc T7 Wireless Earbuds User Manual

MODEL: T7

Introduction

Thank you for choosing the Byobyc T7 Wireless Earbuds. This manual provides detailed instructions on how to set up, operate, and maintain your new earbuds to ensure optimal performance and longevity. Please read this manual thoroughly before using the product.



The Byobyc T7 Wireless Earbuds with their innovative charging case featuring an LED display.

What's in the Box

Your Byobyc T7 Wireless Earbuds package includes the following items:

- Owner's Manual
- T7 Wireless Earbuds (2 units)
- Type-C Cable (1 unit)
- Wireless Charging Case (1 unit)
- S, M, L Eartips (one set each)

All-Inclusive Accessories Pack



All accessories included with your Byobyc T7 Wireless Earbuds.

Setup

1. Charging the Earbuds and Case

Before first use, fully charge the earbuds and the charging case. Connect the provided Type-C cable to the charging port on the case and a USB power source. The LCD display on the case will show the charging status and battery levels.

- **Earbud Battery:** Each earbud has a 40mAh battery.
- **Case Battery:** The charging case has a 320mAh battery.
- **Playtime:** Up to 5 hours of single-ear playback on a full charge. The charging case provides multiple charges for extended total battery life.

Super-long Battery Life

5 Hrs Single-ear Playback



Illustration of the battery capacity for the earbuds and charging case.

2. Bluetooth Pairing

1. Open the charging case. The earbuds will automatically enter pairing mode.
2. On your device (smartphone, tablet, laptop), enable Bluetooth.
3. Search for available Bluetooth devices and select "T7" from the list.
4. Once connected, the earbuds will indicate successful pairing, and the LED display lights on both earbuds will illuminate.

The earbuds feature Bluetooth 5.4 for faster and more stable signal transmission, ensuring low latency and a connection range of up to 10 meters (33 feet).

Advanced Bluetooth 5.4

Faster and More Stable Transfer



The Byobyc T7 Earbuds utilize advanced Bluetooth 5.4 technology for a stable connection.

3. Proper Fit

For optimal sound quality and comfort, choose the eartips that best fit your ears. The package includes S, M, and L sizes. Gently insert the earbuds into your ear canal and twist slightly to secure them.

Operating Instructions

1. Smart Touch Control

The T7 earbuds are equipped with sensitive multi-functional touch zones on both the left and right earbuds, allowing for flexible control without needing to access your phone.

Action	Control
Play/Pause Music	Single tap on either earbud

Action	Control
Next Song	Double tap on the right earbud
Previous Song	Double tap on the left earbud
Volume Up	Triple tap on the right earbud
Volume Down	Triple tap on the left earbud
Answer/End Call	Single tap on either earbud
Reject Call	Press and hold on either earbud for 2 seconds
Activate Voice Assistant (Siri/Google Assistant)	Press and hold on either earbud for 3 seconds
Power On/Off	Press and hold for 5 seconds (or place in case)



Visual guide to the touch controls on the Byobyc T7 Earbuds.

2. Multifunctional LCD Touch Screen

The charging case features an intelligent LCD touchscreen that provides access to various functions and information:

- **Power Level Display:** Shows the precise power level of both the charging case and the individual wireless earbuds.
- **Language Selection:** Choose from a variety of languages for the display interface.
- **Brightness Adjustment:** Adjust the screen brightness to your preference.
- **Clock Function:** Set and view the current time directly on the screen.
- **Screen Saver/Wallpaper:** Customize the display with different screen savers or wallpapers.
- **Music Modes/Equalizer:** Select various sound effects such as Jazz, Bass, Studio, Club, and Vocal to enhance your listening experience.



Overview of the intelligent LCD touchscreen display on the charging case.

3. Mobile Phone and Headset Synchronization

After connecting the headset to your phone's Bluetooth, the music playback page can be synchronized to the headset screen. This allows you to pause, play, and change music directly through the headset screen, which is convenient when

your mobile phone is not easily accessible, such as during a workout or run.

Maintenance

- **Cleaning:** Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth. Do not use harsh chemicals or abrasive materials.
- **Water Resistance:** The earbuds are IP7 water-resistant, meaning they can withstand splashes, sweat, and rain. Do not submerge them in water. Ensure the charging port is dry before charging.
- **Storage:** When not in use, store the earbuds in their charging case to protect them and keep them charged. Store in a cool, dry place away from extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge the device regularly, even if not in use for extended periods.

Troubleshooting

Problem	Possible Solution
Earbuds not pairing	Ensure earbuds are charged. Turn off and on Bluetooth on your device. Forget "T7" from your device's Bluetooth list and re-pair.
No sound from one earbud	Place both earbuds back in the charging case, close the lid, wait a few seconds, then open and try again. Check device's audio output settings.
Charging case not charging	Ensure the Type-C cable is securely connected to both the case and the power source. Try a different cable or power adapter.
Touch controls not responding	Ensure your fingers are clean and dry. Restart the earbuds by placing them in the case and taking them out.
Poor sound quality	Ensure earbuds are properly seated in your ears. Try different sized eartips. Clean any debris from the earbud speakers. Move closer to your connected device to avoid interference.

Specifications

Feature	Detail
Model Name	T7
Connectivity Technology	Wireless (Bluetooth)
Bluetooth Version	5.4
Bluetooth Range	Up to 15 meters (approx. 49 feet)
Control Method	Touch
Earbud Battery Capacity	40mAh (each)
Charging Case Battery Capacity	320mAh
Single-ear Playback Time	Up to 5 hours
Material	Plastic

Feature	Detail
Water Resistance Rating	IP7
Noise Control	Environmental Noise Cancellation
Item Weight	0.12 Kilograms (4.2 ounces)
Dimensions (Package)	5.87 x 4.13 x 1.93 inches

Compact & Delicate Design



Detailed dimensions of the Byobyc T7 Earbuds and charging case.

Byobyc products are designed with quality and reliability in mind. For any questions, technical support, or warranty claims, please contact Byobyc customer service through the retailer's platform or the official Byobyc website. Please retain your proof of purchase for warranty purposes.

© 2025 Byobyc. All rights reserved.