



Manuals.plus /

- › 4 EVER WINNER /
- › 4 EVER WINNER 55-inch Coffee Bar Cabinet (Model MDC4) Instruction Manual

4 EVER WINNER MDC4

4 EVER WINNER 55-inch Coffee Bar Cabinet (Model MDC4) Instruction Manual

Comprehensive guide for assembly, operation, and maintenance.

INTRODUCTION

Thank you for choosing the 4 EVER WINNER 55-inch Coffee Bar Cabinet (Model MDC4). This versatile furniture piece is designed to provide ample storage and a stylish addition to your kitchen, dining room, or living room. This manual contains important information regarding the safe assembly, proper use, and maintenance of your new cabinet. Please read all instructions carefully before beginning assembly and retain this manual for future reference.

SAFETY INFORMATION

- Always assemble the cabinet on a soft, clean surface to prevent scratches.
- Ensure all parts are securely fastened before use. Do not overtighten screws.
- Keep small parts and packaging materials away from children and pets.
- Do not stand on the cabinet or allow children to climb on it.
- Distribute weight evenly across shelves and drawers to prevent tipping.
- If any parts are missing or damaged, contact customer support immediately.

PACKAGE CONTENTS

Your package includes all necessary components and hardware for assembly. Please verify that all parts are present and undamaged before proceeding. A detailed parts list will be provided in the separate assembly instructions included with your product.



Figure 1: Assembled 4 EVER WINNER 55-inch Coffee Bar Cabinet in a dining room setting.

ASSEMBLY INSTRUCTIONS

Assembly of the 4 EVER WINNER Coffee Bar Cabinet is required. Detailed, step-by-step instructions and all necessary hardware are included in your product packaging. It is recommended to have two people for assembly to ensure stability and ease of construction.

1. Unpack all components and lay them out on a clean, soft surface.
2. Identify each part using the provided parts list.
3. Follow the numerical sequence in the assembly manual to connect the panels and install hardware.
4. Ensure all screws and fasteners are tightened securely, but do not overtighten.
5. Install the drawers and doors according to the instructions. Note that the doors can be assembled in two display ways (Figure 2).
6. Once assembled, carefully move the cabinet to its desired location.



Figure 2: Illustration of two possible door assembly configurations for the cabinet.

OPERATING INSTRUCTIONS

The 4 EVER WINNER Coffee Bar Cabinet is designed for versatile storage and display. Its features include:

- **Spacious Tabletop:** Utilize the top surface for coffee machines, decorative items, or serving.
- **Sliding Drawers:** Three smooth-gliding drawers provide concealed storage for smaller items like cutlery, napkins, or accessories.
- **Glass Doors:** Two central doors feature clear glass panels, ideal for displaying dinnerware, glassware, or decorative pieces while keeping them protected.
- **Farmhouse Barn Doors:** The two outer doors feature a stylish barn door design, offering discreet storage for various items.
- **Adjustable Shelves:** The interior shelves behind the doors are adjustable, allowing you to customize the storage space to accommodate items of different heights.



Figure 3: View of the spacious tabletop and open drawers, illustrating storage capacity.

DIY Assembly

Two display ways of the doors



Figure 4: Detailed view highlighting the farmhouse barn door, glass cabinet door, and adjustable interior shelves.

MAINTENANCE AND CARE

To ensure the longevity and appearance of your 4 EVER WINNER Coffee Bar Cabinet, follow these care guidelines:

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners, which can damage the finish. The smooth table surface allows for easy removal of surface dirt.
- **Spills:** Clean spills immediately to prevent staining, especially on the tabletop.
- **Hardware:** Periodically check all screws and fasteners to ensure they remain tight. Retighten if necessary.
- **Sunlight:** Avoid prolonged exposure to direct sunlight to prevent fading or discoloration.
- **Moisture:** Protect the cabinet from excessive moisture and humidity.

TROUBLESHOOTING

If you encounter any issues during assembly or use, please refer to the following common solutions:

- **Parts Missing or Damaged:** If you find any parts are missing or damaged upon opening the package, do not proceed with assembly. Contact customer support for replacement parts.
- **Assembly Difficulties:** Ensure you are following the assembly instructions precisely. Sometimes, parts may appear similar but have subtle differences. Double-check part numbers and orientations. If pre-drilled holes do not align, gently adjust the pieces or contact support.
- **Drawers or Doors Not Closing Properly:** Check that all hardware (hinges, drawer slides) are installed correctly and tightened. Ensure the cabinet is on a level surface.
- **Cabinet Wobbles:** Verify that all connections are secure and tightened. Ensure the cabinet is placed on a flat, even floor.

SPECIFICATIONS

PRODUCT SPECIFICATIONS




Figure 5: Visual representation of the cabinet's dimensions and weight capacities.

Feature	Detail
Brand	4 EVER WINNER
Model Name	MDC4
Color	White
Product Dimensions	15.7"D x 55.1"W x 35.4"H
Item Weight	111 Pounds
Material	Engineered Wood (MDF Board)
Special Features	Adjustable Shelf, Heavy Duty
Mounting Type	Floor Mount
Room Type	Dining Room (also suitable for Kitchen, Living Room)
Number of Shelves	3
Assembly Required	Yes

WARRANTY AND SUPPORT

For warranty information, replacement parts, or technical assistance, please refer to the contact details provided in your product packaging or visit the official 4 EVER WINNER website. Please have your model number (MDC4) and purchase information ready when contacting support.

You can also visit the 4 EVER WINNER Store on Amazon for more product information and support resources.

