

[Manuals.plus](#) /

› [VINGLI](#) /

› VINGLI Freestanding Utility Sink Laundry Tub User Manual

VINGLI plastic utility sink

VINGLI Freestanding Utility Sink Laundry Tub User Manual

Model: plastic utility sink

Brand: VINGLI

1. INTRODUCTION

Thank you for choosing the VINGLI Freestanding Utility Sink Laundry Tub. This manual provides essential information for the safe and efficient assembly, operation, and maintenance of your new utility sink. Please read these instructions carefully before installation and retain them for future reference.





An angled view of the assembled VINGLI freestanding utility sink in black, featuring the integrated faucet and a visible drain pipe.

2. PRODUCT OVERVIEW

The VINGLI Utility Sink is designed for versatile use in various environments, including laundry rooms, garages, basements, and outdoor areas. Its durable construction and thoughtful features make it suitable for a wide range of tasks, from washing clothes to bathing small pets.

Key Features:

- **Durable Material:** Constructed from environmentally friendly PP material, ensuring health, safety, and non-toxicity.
- **Stainless Steel Faucet:** Equipped with a high-quality stainless steel faucet, compatible with

both hot and cold water inlets.

- **Efficient Drainage:** Features a slightly sunken sink bottom for faster drainage and a pop-up drainer with stopper.
- **Adjustable Levelers:** Sturdy iron legs include adjustable levelers for stability on uneven surfaces.
- **Optional Accessories:** Includes options for a pop-up button to control the drain or a soap dispenser.



A banner image highlighting the VINGLI Utility Sink / Laundry Tub as a wonderful improvement for house renovations, emphasizing its spacious, sturdy, and storage features.



A close-up image highlighting the stainless steel faucet with indicators for hot and cold water inlets, and a detail of the 3/8 inch ID connection.



POP-UP BUTTON OR SOAP DISPENSER

1

Control the drain by pressing the button

2

Install the soap dispenser as you wish

An illustration showing two options for the sink's top: a pop-up button to control the drain and an alternative installation for a soap dispenser.

3. SETUP AND ASSEMBLY

The VINGLI Utility Sink is designed for straightforward assembly. Follow these general steps for installation. Refer to the included assembly diagram for detailed instructions specific to your package.

Assembly Steps:

1. **Unpack Components:** Carefully remove all parts from the packaging and verify against the parts list.
2. **Assemble Legs:** Attach the iron legs to the sink basin using the provided hardware. Ensure all connections are secure.
3. **Install Faucet:** Mount the stainless steel faucet onto the designated hole on the sink basin. Connect the hot and cold water supply lines to the faucet and your water supply. Ensure all connections are tightened to prevent leaks.
4. **Install Drain System:** Insert the drainer into the sink's drain hole. Connect the flexible drain pipe to the drainer and route it to your wastewater connection. Ensure a watertight seal.

5. **Adjust Levelers:** Once assembled, place the sink in its desired location. Adjust the levelers on the bottom of the legs to ensure the sink is stable and level on the floor.
6. **Optional Accessories:** Install the pop-up button or soap dispenser as desired into the auxiliary hole.

Important: Before connecting to water supply, ensure all plumbing connections are secure to prevent leaks. It is recommended to test for leaks after initial setup.



A banner image displaying key components: hot & cold water supply lines, a drainer for rapid water passage, an easy-assembly drain pipe, and adjustable levelers.

4. OPERATION

Operating your VINGLI Utility Sink is straightforward. Familiarize yourself with the faucet and drain functions.

Using the Faucet:

- The faucet is designed for both hot and cold water. Turn the handle to adjust water temperature and flow.
- Ensure water supply lines are fully open for optimal performance.

Using the Drain:

- The sink features a pop-up drainer. To close the drain and fill the sink, press the pop-up button (if installed) or manually insert the stopper.
- To open the drain and allow water to flow out, press the pop-up button again or remove the stopper.

FREE-STANDING WASH STATION



An overhead view of the utility sink being used as a free-standing wash station, with hands washing fruit under the faucet, emphasizing its utility, spaciousness, and durability.



A small dog (Corgi) being bathed in the utility sink, demonstrating its suitability for pet washing.

5. MAINTENANCE

Regular cleaning and maintenance will ensure the longevity and optimal performance of your VINGLI Utility Sink.

Cleaning the Sink Basin:

- Clean the PP material sink basin with mild soap and water.
- Avoid abrasive cleaners, harsh chemicals, or scouring pads, as these can damage the surface.
- Rinse thoroughly with clean water and wipe dry with a soft cloth to prevent water spots.

Faucet Care:

- Wipe the stainless steel faucet with a soft, damp cloth.
- For stubborn water spots, use a vinegar-based cleaner or a specialized stainless steel cleaner, then rinse and dry.

Drain Maintenance:

- Periodically remove the drain stopper and clean any debris from the drainer to ensure proper water flow.
- Check the drain pipe connections for any signs of leaks or blockages.



A banner image illustrating user-friendly designs: an easy-clean sink body, a quick-drain device, and iron legs with adjustable levelers.

6. TROUBLESHOOTING

If you encounter issues with your VINGLI Utility Sink, refer to the common problems and solutions below.

Problem	Possible Cause	Solution
Water Leakage	Loose connections at faucet or drain pipe. Missing or damaged O-rings/gaskets.	Check and tighten all water supply and drain connections. Inspect O-rings and gaskets; replace if damaged.
Slow Drainage	Drainer clogged with debris. Drain pipe partially blocked.	Remove drain stopper and clean any hair or debris from the drainer. Check the drain pipe for obstructions.
Sink is Unstable/Wobbly	Leg levelers not properly adjusted. Uneven floor surface.	Adjust the levelers on each leg until the sink is stable. Use shims if necessary for extremely uneven floors.
Low Water Pressure	Water supply valves not fully open. Faucet aerator clogged.	Ensure hot and cold water supply valves are fully open. Unscrew and clean the faucet aerator.

If the problem persists after attempting these solutions, please contact VINGLI customer support for assistance.

7. SPECIFICATIONS

Detailed specifications for the VINGLI Freestanding Utility Sink Laundry Tub (19.7"W x 18.9"D x 33"H Black model).

Attribute	Detail
Brand	VINGLI
Model Number	plastic utility sink

Attribute	Detail
Color	Black
Material	Plastic (PP)
Style	19.7"W x 18.9"D x 33"H
Product Dimensions (Overall)	19.7"D x 18.9"W x 33"H (approximate)
Installation Type	Freestanding
Drain Type	Lift and Turn (Pop-up)
Hole Count	1 (for faucet) + auxiliary hole for pop-up button/soap dispenser
Max Load Capacity	110 lbs (approximate)



A diagram showing the key dimensions of the utility sink (19.7in W, 18.9in D, 33.07in H, 12.01in basin depth, 13.78in faucet height) and its maximum load capacity of 110 lbs.

8. WARRANTY AND SUPPORT

VINGLI is committed to providing high-quality products. While specific warranty details may vary, please retain your proof of purchase for any warranty claims.

Customer Support:

For technical assistance, missing parts, or any questions regarding your VINGLI Utility Sink, please contact VINGLI customer support through the retailer's platform or the official VINGLI website.

Provide your product model number and purchase details for faster service.

We value your satisfaction and are here to help.

© 2025 VINGLI. All rights reserved.