

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [YESHOMY](#) /

› [YESHOMY YH-EC23-0165-WMNEW Coffee Bar and Accent Cabinet Instruction Manual](#)

YESHOMY YH-EC23-0165-WMNEW

YESHOMY YH-EC23-0165-WMNEW Coffee Bar and Accent Cabinet Instruction Manual

Model: YH-EC23-0165-WMNEW

INTRODUCTION

Thank you for choosing the YESHOMY Coffee Bar and Accent Cabinet. This versatile furniture piece is designed to enhance your living space with its farmhouse style and practical storage solutions. This manual provides detailed instructions for assembly, usage, maintenance, and troubleshooting to ensure a smooth experience and long-lasting enjoyment of your cabinet.



Image: Front view of the YESHOMY Coffee Bar and Accent Cabinet, showcasing its rustic brown top and white barn doors.

SAFETY INFORMATION

Please read and understand all safety instructions before assembly and use. Failure to follow these instructions may result in injury or product damage.

- Keep all small parts and packaging materials away from children and pets.
- Assemble the cabinet on a soft, clean surface to prevent scratches.
- Ensure all connections are securely tightened before use. Periodically check and re-tighten fasteners as needed.
- Do not overload the cabinet shelves or drawer. Refer to specifications for weight limits.

- Use the included anti-tip kit to secure the cabinet to a wall, especially if children are present. This prevents accidental tipping.
- Do not stand or climb on the cabinet.

PACKAGE CONTENTS

Before beginning assembly, verify that all components and hardware are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Cabinet panels (top, bottom, sides, back, shelves, drawer components, doors)
- Hardware pack (screws, dowels, cam locks, drawer slides, hinges, handles, anti-tip kit)
- Assembly Manual (this document)

ASSEMBLY INSTRUCTIONS (SETUP)

Assembly is required for this product. Please follow these steps carefully. It is recommended to have two people for assembly.

Tools Required:

- Phillips Head Screwdriver
- Hammer (optional, for dowels)

General Assembly Steps:

1. **Unpack and Identify Parts:** Lay out all panels and hardware. Match them with the parts list in the included manual.
2. **Assemble the Main Frame:** Attach side panels to the bottom panel using dowels and cam locks. Ensure cam locks are fully tightened.
3. **Install Back Panel:** Carefully align and attach the back panel. Note that the back panel may consist of two thinner pieces joined by tape; handle with care.
4. **Attach Top Panel:** Secure the top panel to the assembled frame.
5. **Assemble Drawer:** Follow the specific instructions for the drawer. Pay close attention to the drawer slides.
6. **Install Drawer Slides:** The drawer slides come in two parts. To separate them, pull the slide all the way out. Locate the small black plastic lever (often resembling a zip tie) and press it down (or up, depending on the slide) while pulling to release the inner part. Attach the outer part to the cabinet frame and the inner part to the drawer sides. When attaching the inner part to the drawer, use the first forward hole to screw in first to ensure proper alignment.
7. **Attach Doors:** Install hinges to the doors and then to the cabinet frame. Do not fully tighten door screws until alignment is checked.
8. **Install Handles:** Attach handles to the drawer and doors.
9. **Install Adjustable Shelves:** Place shelf pins at desired heights and insert shelves.
10. **Secure with Anti-Tip Kit:** Attach the anti-tip kit to the cabinet and then to a wall stud to prevent tipping.

Important Assembly Tips:

- **Drawer Slides:** If the drawer does not close flush or seems misaligned, re-check the installation of the drawer slides. Ensure both sides are at the same height and the inner slide is correctly engaged with the outer slide. The black plastic release lever is key to separating the slide components.
- **Door Alignment:** For proper door alignment, loosely attach the hinges first. Adjust the doors until they are level and have even gaps, then fully tighten the hinge screws.
- **Stability:** Ensure all screws and fasteners are tightened. If the cabinet feels wobbly, double-check all connections.



Image: The cabinet with its doors open, revealing two levels of storage and adjustable shelves.



Image: The cabinet's top drawer pulled open, showing storage space for smaller items.

USAGE AND FEATURES (OPERATING)

The YESHOMY Coffee Bar and Accent Cabinet offers versatile storage and display options for various rooms.

- **Multi-functional Design:** This cabinet can serve as a coffee bar, kitchen cabinet, entryway cabinet, living room cabinet, or dining room cabinet. Its wide desktop provides ample space for appliances or decorative items.
- **Adjustable Shelving:** The lower cabinet features two levels of storage with three height-adjustable dividers. This allows you to customize the internal space to accommodate items of various sizes. Shelves can also be removed entirely for larger objects.
- **Convenient Drawer:** A spacious top drawer provides enclosed storage for smaller items, keeping your space tidy.
- **Farmhouse Aesthetic:** The rustic brown top and white barn-door style cabinet doors complement a variety of interior designs.



Image: The cabinet functioning as a coffee bar in a kitchen setting, with a coffee machine and mugs on top.



Image: The cabinet placed in a living room, serving as an accent piece with decorative items on its surface.

CARE AND MAINTENANCE

Proper care will help maintain the appearance and longevity of your cabinet.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners, as these can damage the finish.
- **Spills:** Clean up spills immediately to prevent staining or water damage.
- **Sunlight:** Avoid prolonged exposure to direct sunlight, which can cause fading or discoloration.
- **Heat:** Do not place hot items directly on the surface. Use coasters or protective pads.
- **Fasteners:** Periodically check all screws and connections to ensure they remain tight. Re-tighten as necessary.

TROUBLESHOOTING

If you encounter any issues with your cabinet, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Cabinet is wobbly after assembly.	Loose fasteners; uneven floor.	Ensure all screws and cam locks are fully tightened. If on an uneven floor, use furniture levelers or shims under the legs.
Drawer does not close completely or is misaligned.	Drawer slides incorrectly installed or not fully engaged.	Review assembly steps for drawer slides. Ensure the inner and outer slide components are correctly separated and re-engaged. Verify that the inner slide is attached to the drawer using the correct mounting holes for flush closure.
Cabinet doors are uneven or do not close properly.	Hinges are not properly adjusted or tightened.	Loosen hinge screws slightly, adjust door position for even gaps, then re-tighten screws. Most hinges allow for minor adjustments.
Missing parts or damaged components.	Packaging error or shipping damage.	Do not proceed with assembly. Contact YESHOMY customer support immediately for replacement parts.

SPECIFICATIONS

Detailed specifications for the YESHOMY Coffee Bar and Accent Cabinet.

- **Model Name:** Coffee Bar and Accent Cabinet
- **Model Number:** YH-EC23-0165-WMNEW
- **Brand:** YESHOMY
- **Color:** Rustic Brown & White
- **Product Dimensions (D x W x H):** 15.75" x 31.5" x 33.46"
- **Item Weight:** 71.3 Pounds
- **Material:** Wood (Frame Material: Wood, Top Material Type: Wood)
- **Number of Shelves:** 2 (adjustable)
- **Special Feature:** Removable Shelf
- **Mounting Type:** Floor Mount
- **Installation Type:** Freestanding
- **Assembly Required:** Yes

PRODUCT DIMENSION

Removable partitions

KG 1 50LBS



Image: A diagram illustrating the precise dimensions of the YESHOMY Coffee Bar and Accent Cabinet, including depth, width, and height.

WARRANTY AND SUPPORT

For warranty information or customer support, please refer to the documentation included with your purchase or visit the official YESHOMY website. If you have questions regarding assembly, missing parts, or product defects, please contact YESHOMY customer service directly. Please have your model number (YH-EC23-0165-WMNEW) and purchase details ready when contacting support.

Related Documents - YH-EC23-0165-WMNEW



[Yuwell BreathCare PAP User Manual](#)

User manual for the Yuwell BreathCare PAP Positive Airway Pressure Units, covering indications, contraindications, warnings, precautions, setup, operation, maintenance, troubleshooting, and technical specifications.