

[Manuals.plus](#) /

› [YESHOMY](#) /

› YESHOMY White Wood 6-Drawer Dresser Instruction Manual

YESHOMY White Wood Dresser

YESHOMY White Wood 6-Drawer Dresser Instruction Manual

Brand: YESHOMY | Model: White Wood Dresser

INTRODUCTION

This manual provides essential information for the assembly, operation, and maintenance of your new YESHOMY White Wood 6-Drawer Dresser. Please read these instructions carefully before beginning assembly and retain this manual for future reference.

WHAT'S IN THE BOX

Verify that all components are present before beginning assembly. If any parts are missing or damaged, please contact customer support.

- YESHOMY White Wood 6-Drawer Dresser components
- Assembly tool kit
- Instruction manual

SPECIFICATIONS



Figure 1: Product Dimensions and Load Capacity

Attribute	Detail
Overall Dimensions (D x W x H)	15.1" x 58" x 26.5"
Drawer Dimensions (D x W x H)	11.8" x 26.7" x 7.1" (each)
Item Weight	91 Pounds
Material Type	Engineered Wood
Finish Type	Painted (White)
Number of Drawers	6
Mounting Type	Floor Mount
Maximum Load Bearing	200 lbs (top surface)

SETUP AND ASSEMBLY

The YESHOMY dresser is designed for straightforward assembly. Follow the included detailed instructions and use the provided tool kit. It is recommended to have two people for assembly to ensure stability and ease of handling larger components.

1. Unpack all components and verify against the parts list in the separate instruction manual.
2. Assemble the main frame of the dresser according to the step-by-step diagrams.
3. Install the drawer slides onto the dresser frame.
4. Assemble each of the six drawers individually.
5. Insert the assembled drawers into the slides on the dresser frame.
6. Attach the anti-tip hardware to the back of the dresser and secure it to a wall stud to prevent accidental tipping.



Figure 2: Drawer Construction and Base Stability

OPERATING INSTRUCTIONS

The YESHOMY 6-Drawer Dresser is designed for efficient storage and organization in various rooms.

- **Drawer Use:** Gently pull and push drawers using the metal handles. The smooth slide rails ensure quiet operation.
- **Storage Capacity:** Each drawer provides ample space for clothing, accessories, linens, or other household items. Organize items neatly to maximize space.
- **Versatile Placement:** This dresser can function as a storage cabinet in a bedroom, a TV stand in a living room (suitable for TVs up to 55 inches), or an organizer in a hallway.



Figure 3: Multi-Scene Use of the Dresser



Figure 4: Dresser as a TV Stand (up to 55" TV)

MAINTENANCE

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that may damage the painted finish.
- **Dusting:** Regularly dust the dresser with a dry, soft cloth to prevent buildup.
- **Spills:** Clean spills immediately to prevent staining or damage to the wood.
- **Hardware:** Periodically check and tighten all screws and fasteners to ensure the dresser remains stable.
- **Sunlight Exposure:** Avoid prolonged exposure to direct sunlight to prevent fading or discoloration of the finish.

TROUBLESHOOTING

- **Drawers not sliding smoothly:** Check that the drawer slides are properly aligned and free of obstructions. Ensure all screws on the slides are tightened.
- **Dresser feels unstable:** Verify that the anti-tip hardware is correctly installed and secured to a wall stud. Ensure all assembly fasteners are tight.
- **Gaps between drawers:** This can sometimes occur if the frame is not perfectly square during assembly. Re-check frame assembly steps and ensure all connections are firm.

WARRANTY AND SUPPORT

For warranty information or customer support, please refer to the contact details provided with your purchase documentation or visit the official YESHOMY website. Keep your proof of purchase for any warranty claims.

