

Gosnap Go Snap Camera 4K Thumb Action Camera User Manual

MODEL: 1

1. Introduction

Thank you for choosing the Gosnap Go Snap Camera. This compact and versatile 4K thumb action camera is designed for capturing high-quality video and photos in various environments. Its small size, 360° rotating clip, and magnetic mount make it ideal for hands-free recording of your adventures, whether on a pet, helmet, or backpack. This manual provides essential information for setting up, operating, and maintaining your camera.

2. Package Contents

Please verify that all items listed below are included in your package:

- Gosnap Go Snap Camera (4K, White)
- Waterproof Case
- 360° Rotating Spring Clip
- Magnetic Mount
- Pet Collar Kit
- Type-C Charging Cable
- Other Accessories (as shown in image)



Image 2.1: The Gosnap Go Snap Camera and its complete set of accessories, including the camera unit, waterproof case, various mounts, and charging cable.

3. Product Features

- **Compact and Lightweight:** At just 64.5mm in length and 35.7g (1.25 oz), this thumb-sized camera is highly portable.
- **High-Resolution Recording:** Captures stunning 4K (3840*2160) video at 30 frames per second, ensuring clear and detailed footage.
- **Versatile Mounting Options:** Features a 360° rotating spring clip and a built-in magnetic mount for attachment to various surfaces and clothing.
- **Waterproof Capability:** The included waterproof case allows for underwater recording up to 131 feet (40 meters).
- **Extended Battery Life:** Equipped with an 800mAh battery, providing up to 150 minutes of 1080P recording or 90 minutes of 4K recording. Supports recording while charging.
- **Wide-Angle Lens:** A 170° wide-angle lens captures a broad field of view, ensuring you don't miss any details.



Image 3.1: Visual representation of the camera's compact dimensions (64.5mm length, 28mm width, 20mm thickness), the magnetic lanyard accessory, and the internal magnetic suction feature for easy mounting.

Portable Back Clip

Clip Wherever You Want

Portable Back Clip Design, Clip to Clothing Pockets, Folders, School Bag Straps, Waist, Etc. Easy to Carry




Image 3.2: The camera's portable back clip design, illustrating its 360-degree rotation capability for flexible attachment to clothing, bags, or other surfaces.

Built-In Magnetic Suction Shooting Is so Easy

The Machine Has Built-In Magnetic Suction,
Which Can Be Installed at Any Angle You Want



Image 3.3: A visual representation of the camera's built-in magnetic suction, allowing for easy and secure attachment to metallic surfaces at various angles.

4. Setup

4.1 Charging the Camera

Before first use, fully charge the camera. Connect the provided Type-C charging cable to the camera's Type-C interface and the other end to a 5V/2A power adapter (not included). The charging time is approximately 120 minutes.



Image 4.1: The Gosnap camera connected via its Type-C port, demonstrating its ability to record video while simultaneously charging, ensuring continuous operation during extended activities.

4.2 Inserting a Memory Card

The camera supports up to 256GB memory cards. Locate the memory card slot on the camera and gently insert a compatible microSD card until it clicks into place. Ensure the camera is powered off before inserting or removing the card.

4.3 Mounting the Camera

Utilize the 360° rotating spring clip or the magnetic mount to attach the camera. The spring clip is ideal for collars, backpack straps, or clothing pockets. The magnetic mount allows for quick attachment to metallic surfaces. The included pet collar kit provides a secure way to attach the camera to your pet's collar.



Image 4.2: A person wearing the Gosnap camera around their neck using the magnetic lanyard, demonstrating a convenient and hands-free way to carry and operate the device.

5. Operating Instructions

5.1 Power On/Off

To power on the camera, press and hold the power button until the indicator light illuminates. To power off, press and hold the power button again until the indicator light turns off.

5.2 Recording Video

Once powered on, press the record button to start video recording. The indicator light will change to indicate recording is in progress. Press the record button again to stop recording. Videos are saved to the inserted memory card.

4k High-Definition Recording Photos and Videos Are Clear and Visible

(4k Resolution Is Equivalent to
1080p Magnified 4 Times, And Still Clear)



Image 5.1: A visual comparison demonstrating the clarity and detail provided by 4K high-definition recording, showing how it offers significantly more detail than lower resolutions like 1080p or 720p.

5.3 Connecting to a Computer

To transfer files, connect the camera to your computer using the Type-C cable. The camera will appear as a removable disk, allowing you to access and copy your video and photo files.

6. Maintenance

6.1 Cleaning

Wipe the camera body with a soft, dry cloth. For the lens, use a specialized lens cleaning cloth. Avoid using harsh chemicals or abrasive materials.

6.2 Storage

Store the camera in a cool, dry place, away from direct sunlight and extreme temperatures. The recommended storage temperature is -10°C to 60°C (14°F to 140°F). Remove the memory card if storing for extended periods.

6.3 Waterproof Case Care

After using the waterproof case in water, rinse it with fresh water and allow it to air dry. Ensure the seals are clean and free of debris before each use to maintain its waterproof integrity.

7. Troubleshooting

- **Camera not turning on:** Ensure the battery is charged. Connect to a power source and try again.
- **Recording issues (e.g., choppy video):** Check if the memory card is properly inserted and has sufficient free space. Use a high-speed memory card (Class 10 or higher recommended for 4K).
- **Camera not recognized by computer:** Try a different USB port or cable. Ensure the camera is powered on when connected.
- **Short battery life:** Ensure the camera is fully charged before use. Recording in 4K resolution consumes more power.

8. Specifications

Feature	Specification
Product Name	Go Snap Camera
Video Resolution	3840*2160 (4K)
Video Format	Mp4
Storage Temperature	-10-60 Degrees Celsius
Interface Type	Type-C Interface
Charging Voltage	5V/2A
Charging Time	120 Minutes
Product Size	64.5*28*20mm
Max Storage Support	256GB
Item Weight	0.035 ounces (approx. 1g)
Lens Type	Macro
Optical Zoom	1x

9. Warranty and Support

For any questions or assistance, please contact our customer service via email. We are committed to providing you with the best quality service and will respond within 24 hours. Your satisfaction is our priority.

Please retain your proof of purchase for any warranty claims. Specific warranty details may vary; refer to your purchase documentation for more information.

