

## HANLINYUE E2CONTROL

# HANLINYUE E2CONTROL Bluetooth Page Turner Remote Control User Manual

Model: E2CONTROL | Brand: HANLINYUE

[Instructions](#)   [Maintenance](#)   [Setup](#)   [Operating](#)   [Troubleshooting](#)   [Specifications](#)   [Warranty & Support](#)

## 1. SETUP

---

Follow these steps to set up your HANLINYUE E2CONTROL remote control:

- Power On:** Locate the power switch on the side of the remote and slide it to the ON position. The indicator light will illuminate.
- Pairing Mode:** The remote will automatically enter Bluetooth pairing mode.
- Enable Bluetooth on Device:** On your smartphone, tablet, or e-reader, go to your device's Bluetooth settings and ensure Bluetooth is enabled.
- Connect:** Search for available devices and select "E2CONTROL" from the list to pair. The indicator light on the remote will stop blinking once connected.
- iOS/iPadOS Specific Setting:** For iPhone and iPad devices, you must enable the "Zoom" feature in Accessibility settings for the page-turning function to work correctly. Go to **Settings > Accessibility > Zoom** and turn it ON.

# Easy to use




Image: Visual guide for connecting the E2CONTROL remote control to a mobile device via Bluetooth.

## 2. OPERATING INSTRUCTIONS

---

The E2CONTROL remote offers multiple functions for various applications:

### 2.1 Page Turning (eBooks & Short Videos)

- Use the **Up Arrow** button to scroll up or turn to the previous page.
- Use the **Down Arrow** button to scroll down or turn to the next page.
- Compatible with most e-reading applications and short video platforms like TikTok and YouTube.

# Good for Your Arm/Wrist/Neck

Creates a more comfortable reading experience for Kindle lovers who have limited hand movement.



Image: User operating the remote to navigate content on a tablet, demonstrating page-turning functionality.

## 2.2 Music Control

- The remote can control music playback on apps like Spotify, Apple Music, and YouTube Music.
- Specific button functions may vary slightly by application, but generally:
- The **Center Button** (often a circular arrow) typically functions as Play/Pause.
- The **Up/Down Arrow** buttons may control track skipping or volume, depending on the app's configuration.

## 2.3 Camera Shutter

- Use the remote as a wireless camera shutter for your iPhone or Android device.
- Open your device's native camera app.
- Press any button on the remote (typically the center button or an arrow button) to trigger the camera shutter for photos or to start/stop video recording.
- Effective range up to 33 feet (10 meters).

## Hands Free From Camera and Video Recording



Image: Demonstrates using the remote to control a smartphone camera for hands-free photo and video capture.

### 2.4 Font Size Adjustment (eBooks)

- When reading eBooks, the remote can assist in adjusting font size.
- The Up/Down arrow buttons may be configured within certain e-reader apps to increase or decrease font size, providing a more comfortable reading experience.

## 3. MAINTENANCE

---

### 3.1 Charging the Device

- The E2CONTROL remote features an ultra-long standby time.
- A full charge takes approximately 1.5 hours.
- Once fully charged, the device can offer up to 25 days of standby time.
- Connect the remote to a standard USB charging port using the provided charging cable. The indicator light will show charging status.



Image: Details on the remote's battery life and charging duration.

### 3.2 General Care

- Keep the device dry and away from extreme temperatures.
- Clean with a soft, dry cloth. Do not use harsh chemicals or abrasive materials.
- Avoid dropping the device or subjecting it to strong impacts.

## 4. TROUBLESHOOTING

---

If you encounter issues with your E2CONTROL remote, please refer to the following common solutions:

- **Device Not Pairing:**
  - Ensure the remote is charged and powered on.
  - Verify Bluetooth is enabled on your host device (phone, tablet).
  - Move the remote closer to your device.
  - Forget the device in your Bluetooth settings and attempt to re-pair.
- **Page Turning Not Working on iPhone/iPad:**
  - Confirm that the "Zoom" feature is enabled in your device's Accessibility settings (**Settings > Accessibility > Zoom > ON**). This is a critical step for iOS/iPadOS compatibility.
- **Incompatibility with Kindle Devices:**
  - Please note that this remote page turner is designed for use with the Kindle APP on compatible smartphones and tablets, but it is **not compatible with Kindle e-reader devices** (e.g., Kindle 7th/8th Generation, Amazon Fire HD 10th/11th generation). It supports capacitive screen devices only.
- **Buttons Not Responding:**
  - Check battery level and recharge if necessary.
  - Ensure the remote is within the 33-foot (10-meter) operating range of your device.

- Restart both the remote and your connected device.

## 5. SPECIFICATIONS

---

<b>Model Number</b>	E2CONTROL
<b>Brand</b>	HANLINYUE
<b>Package Dimensions</b>	4.37 x 1.18 x 0.6 inches
<b>Item Weight</b>	1 ounces
<b>Battery Life</b>	Up to 25 days standby
<b>Charging Time</b>	Approx. 1.5 hours for full charge
<b>Connectivity</b>	Bluetooth
<b>Operating Range</b>	Up to 33 feet (10 meters)
<b>Compatible Devices</b>	iPhone, iPad (with Zoom accessibility enabled), Android smartphones and tablets, e-readers with capacitive touchscreens (e.g., Kindle APP, Kobo APP).
<b>Incompatible Devices</b>	Kindle 7th/8th Generation, Amazon Fire HD 10th/11th generation, and other non-capacitive screen e-reader devices.

## 6. WARRANTY & SUPPORT

---

This product is manufactured by Hanlin Yue (Shenzhen) Technology Co., Ltd.

For any product inquiries, technical support, or warranty claims, please contact your retailer or the manufacturer directly. Please refer to your purchase documentation for specific warranty terms and contact information.