

## BestMassage B0FD79SFCV

# BestMassage Recliner Chair with 2-Point Massage Function

MODEL: B0FD79SFCV

## INTRODUCTION

---

Thank you for choosing the BestMassage Recliner Chair. This manual provides essential information for the safe and efficient use of your new recliner. Please read it thoroughly before assembly and operation, and retain it for future reference.

## SAFETY INFORMATION

---

- Do not exceed the maximum weight capacity of 275 pounds. Ensure the chair is stable and properly assembled before use.
- Keep children and pets away from the moving parts of the recliner.
- Avoid placing the chair near heat sources or in direct sunlight to prevent material damage.
- Do not stand on the footrest or armrests.

## PARTS LIST

---

Before assembly, ensure all components are present. Refer to the assembly video for visual guidance on identifying parts.

- Backrest
- Base (Seat with armrests)
- Legs (4 pieces)
- Massage Remote Control
- Power Adapter

## SETUP

---

Assembly of the BestMassage Recliner Chair is designed to be effortless and requires no tools. Follow these steps:

1. Unpack all components from the box.
2. Connect the backrest to the base by sliding it into the designated slots until it clicks securely into place.
3. Screw in the four legs to the bottom of the chair base.
4. Connect the power adapter for the massage function.

The entire assembly process can be completed in approximately 2 minutes.



*Figure 1: Visual guide for recliner chair assembly.*



Figure 2: Product dimensions for placement planning.

## OPERATING INSTRUCTIONS

### Reclining Function

The recliner features an adjustable push-back mechanism and a footrest for optimal comfort. To recline, simply lean back against the backrest and push gently. The chair offers 3 reclining positions, allowing you to find your preferred angle for reading, watching TV, or napping.

# Three Relaxation Modes

You can enjoy your favorite sitting positions on this adjustable reclining chair



Figure 3: Three relaxation modes of the recliner chair.

## Massage Function

Your recliner is equipped with a 2-point vibration massage function targeting the lumbar area, offering 8 customizable modes. Use the wired remote control to operate the massage features.

- **Power Button:** Press to turn the massage function ON/OFF.
- **Mode Selection:** Use the arrow buttons to cycle through the 8 available massage modes.
- **Intensity Adjustment:** Use the '+' and '-' buttons to increase or decrease the massage intensity.
- **Timer:** Set the massage duration for 15 or 30 minutes using the timer button. The unit will automatically shut off after the selected time.

# CARE FOR YOUR LUMBAR



2 Points  
Lumbar Massage



Massage Intensity  
Adjustable



8 Massage  
Modes



Timer  
Function



Figure 4: Massage remote control for customized relaxation.

Video 1: Demonstration of the massage remote control and its functions.

## MAINTENANCE

To ensure the longevity and appearance of your recliner chair, follow these simple maintenance guidelines:

- **Cleaning:** Wipe clean with a damp cloth. Avoid harsh chemicals or abrasive cleaners, as they may damage the leather material.
- **Spills:** For spills, blot immediately with a clean, dry cloth. Do not rub.
- **Inspection:** Periodically check all connections and fasteners to ensure they are tight. Tighten if necessary.

# Elasticity and Soft Touch



WATERPROOF



SKINFRIENDLY



SCRATCH RESISTANCE



Comfortably  
Padded Backrest



High Density  
Thicker Sponge



Waterproof and  
Easily Cleaned

Figure 5: The recliner's material is designed for easy cleaning.

## TROUBLESHOOTING

If you encounter any issues with your recliner, refer to the following common problems and solutions:

- **Chair does not recline:** Ensure the backrest is fully engaged with the base. Apply firm, even pressure when pushing back.
- **Massage function not working:** Check that the power adapter is securely plugged into both the chair and a working electrical outlet. Ensure the remote control is connected and powered on.
- **Unstable chair:** Verify that all four legs are securely screwed into the base and that the backrest is properly attached.

## SPECIFICATIONS

<b>Brand</b>	BestMassage
<b>Model Number</b>	B0FD79SFCV
<b>Color</b>	Leather Dark Brown

<b>Material</b>	Leather (Upholstery), Foam (Fill)
<b>Product Dimensions</b>	33"D x 27"W x 39"H
<b>Item Weight</b>	55 pounds
<b>Maximum Weight Recommendation</b>	275 Pounds
<b>Reclining Position Count</b>	3
<b>Special Feature</b>	Lumbar Support, Adjustable Push Back, Footrest & Padded Seat, 2-Point Vibration Massage (8 Modes)
<b>Assembly</b>	Tool-free, approximately 2 minutes

## WARRANTY AND SUPPORT

---

Specific warranty details and direct support contact information are not provided in the product data. Please refer to your purchase documentation or contact the retailer for warranty claims and customer support inquiries.