



Manuals.plus /

› Tatub /

› Tatub 24" Folding TV Tray Table Instruction Manual

Tatub TV Tray Table

Tatub 24" Folding TV Tray Table Instruction Manual

MODEL: TV TRAY TABLE

Introduction

This manual provides instructions for the assembly, operation, and maintenance of your Tatub 24" Folding TV Tray Table. Designed for versatility and convenience, this C-shaped end table features a cup holder and phone holder, making it suitable for various uses in living rooms, bedrooms, or offices. Please read these instructions carefully before use to ensure safe and proper operation.

Safety Information

- Always assemble the table according to the instructions provided.
- Be cautious of sharp edges during assembly and handling.
- Do not load more than 50 pounds (22.6 kg) onto the table to prevent tip-over risks and damage.
- Ensure the table is stable on a flat surface before placing items on it.
- Keep children and pets away from the table during assembly.

Package Contents

Please verify that all components are present before beginning assembly. If any parts are missing or damaged, contact customer support.

- Tabletop (Engineered Wood)
- Metal Frame Components
- Cup Holder
- Phone Holder
- Adjustable Feet
- Assembly Hardware (screws, bolts, etc.)

Specifications

Brand	Tatub
Model Number	TV Tray Table
Dimensions (L x W x H)	23.6 x 14.6 x 27.6 inches (60 x 37 x 70 cm)
Weight	15.22 pounds (6.9 kg)
Material	Engineered Wood, Metal
Special Features	Cup Holder, Foldable, Phone Holder, Adjustable Feet
Color	Classic Brown
Maximum Load Capacity	50 pounds (22.6 kg)



Figure 1: Product dimensions of the Tatub Folding TV Tray Table.

Setup and Assembly

The Tatub TV Tray Table requires minimal assembly. Follow these steps to set up your table:

1. **Unfold the Frame:** Gently pull the two main vertical supports of the table frame apart until they are fully extended.
2. **Secure the Top Panel:** Locate the small levers or locking mechanisms on the underside of the tabletop where it connects to the vertical supports. Press these levers and slide the tabletop down until it clicks securely into place. Ensure both sides are locked.
3. **Secure the Bottom Panel:** Similarly, locate the locking mechanisms for the bottom horizontal support. Press them and slide the bottom panel into its extended position until it clicks and locks.
4. **Attach Cup and Phone Holders:** If not pre-attached, slide the cup holder and phone holder onto the designated slots on the side of the tabletop.
5. **Adjust Feet:** The table features adjustable feet to ensure stability on uneven surfaces. Rotate the feet clockwise or counter-clockwise to level the table.



Figure 2: Adjustable feet for stability on uneven floors.

Folding and Unfolding Demonstration

Video 1: This video demonstrates the simple process of folding and unfolding the Tatub TV Tray Table for easy storage and setup.

Operating Instructions

Your Tatub TV Tray Table is designed for versatile use. Here are some common applications:

- **As a Sofa-Side Table:** Slide the C-shaped base under your couch or bed to bring the tabletop closer to you for easy access to items.
- **Using the Cup Holder:** Place your beverage securely in the integrated cup holder to prevent spills. The holder is designed to accommodate various cup sizes.

- **Using the Phone Holder:** Position your smartphone in the dedicated slot for hands-free viewing while working or relaxing.
- **Laptop Desk:** Use the spacious tabletop to hold your laptop, notebook, or other work materials.
- **Dining Tray:** Enjoy meals comfortably from your couch or bed.



Figure 3: Table in use as a sofa-side companion.



Figure 4: Detail of the versatile cup holder.

Maintenance

To ensure the longevity and appearance of your Tatub TV Tray Table, follow these maintenance guidelines:

- **Cleaning:** Wipe the tabletop and metal frame with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, which can damage the finish.
- **Spills:** Clean up spills immediately to prevent staining, especially on the engineered wood surface.
- **Inspection:** Periodically check all screws and connections to ensure they are tight. Retighten if necessary.
- **Storage:** When not in use, fold the table for compact storage to protect it from damage and save

space.



Figure 5: The table folds compactly for easy storage.

Troubleshooting

If you encounter any issues with your Tatub TV Tray Table, refer to the following common solutions:

- **Table is Wobbly:**
 - Ensure all locking mechanisms for the tabletop and bottom panel are fully engaged.
 - Adjust the leveling feet on the bottom of the frame to stabilize the table on uneven surfaces.
 - Check that all assembly screws are tightened securely.
- **Difficulty Folding/Unfolding:**

- Ensure the locking levers are fully pressed before attempting to slide the panels.
- Do not force the mechanism; if it feels stuck, re-check the levers and ensure no obstructions are present.
- **Cup Holder/Phone Holder Not Secure:**
 - Ensure the holders are fully slid into their designated slots.

If the issue persists, please contact Tatub customer support for further assistance.

Warranty and Support

Tatub products are designed for quality and durability. For specific warranty information regarding your TV Tray Table, please refer to the warranty card included with your purchase or visit the official Tatub website. For customer support, including inquiries about parts, assembly, or troubleshooting, please contact Tatub directly through their official channels.

Contact Information: Please refer to the packaging or Tatub's official website for the most current customer service contact details.