

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Gosvor](#) /
- › [Gosvor Pivot Cordless Robotic Pool Cleaner Instruction Manual](#)

## Gosvor Pivot

# Gosvor Pivot Cordless Robotic Pool Cleaner

## INSTRUCTION MANUAL

### 1. Product Overview

The Gosvor Pivot is a state-of-the-art cordless robotic pool cleaner designed for inground pools up to 1,100 Sq.ft. It offers comprehensive cleaning of floors, slopes, and walls, ensuring a pristine swimming environment. Equipped with an advanced dual-motor system and powerful suction, it efficiently removes dirt and debris. Its lightweight design and self-parking feature enhance user convenience.



Figure 1: Front view of the Gosvor Pivot Robotic Pool Cleaner.

## 2. Important Safety Instructions

Please read all instructions carefully before operating the Gosvor Pivot. Failure to follow these instructions may result in property damage, serious injury, or death.

- Always disconnect the cleaner from the charger before performing any maintenance or cleaning.
- Do not operate the cleaner if the power cord or charger is damaged.
- Ensure the charging port is dry before connecting the charger.
- Keep hands, hair, and loose clothing away from moving parts.
- This appliance is not intended for use by persons with reduced physical, sensory, or mental capabilities unless supervised.
- Only use the charger supplied by the manufacturer.
- Do not use the cleaner to pick up flammable or combustible liquids.
- Store the cleaner in a cool, dry place when not in use.

### 3. Package Contents

Verify that all items are present in the package:

- Gosvor Pivot Robotic Pool Cleaner Unit
- Power Adapter/Charger
- User Manual

### 4. Getting Started

#### 4.1 Charging the Battery

Before first use, fully charge the cleaner's battery. A full charge typically takes approximately 3 hours.

1. Ensure the cleaner is dry and clean.
2. Locate the charging port on the cleaner.
3. Connect the power adapter to the charging port, then plug the adapter into a standard electrical outlet.
4. The indicator light on the cleaner will show charging status (refer to cleaner's specific light indicators for details).
5. Once fully charged, disconnect the charger.



Figure 2: The Gosvor Pivot connected to its charger, illustrating the fast charging capability.

#### 4.2 Initial Placement in Pool

Carefully lower the cleaner into the pool. Ensure it sinks to the bottom and no air bubbles are trapped underneath.

### 5. Operation

#### 5.1 Starting a Cleaning Cycle

The Gosvor Pivot features an intuitive control button for simplified operation.

1. Ensure the cleaner is fully charged.
2. Place the cleaner into the pool.
3. Press the power button (refer to the cleaner's specific button location). The cleaner will begin its cleaning cycle automatically.

## 5.2 Wall and Floor Cleaning

The Gosvor Pivot is designed to clean both the floor and walls of your inground pool, providing a comprehensive cleaning solution. Its advanced algorithms and responsive navigation system ensure thorough coverage.



Figure 3: The Gosvor Pivot demonstrating its ability to clean both pool walls and floors.

## 5.3 Self-Parking Feature

When the battery level is low, the Gosvor Pivot will automatically navigate itself to the side of the pool for easy retrieval. This feature prevents the cleaner from stopping in the middle of the pool when its battery is depleted.

# Self Parking Technology

Stop near the pool side in low battery



Figure 4: The Gosvor Pivot utilizing its self-parking technology to return to the pool edge.

## 6. Care and Maintenance

### 6.1 Cleaning the Filter

The Gosvor Pivot features a spacious fine filter designed to capture a wide range of debris. Regular cleaning of the filter is crucial for optimal performance.

1. Remove the cleaner from the pool.
2. Open the filter compartment (refer to your cleaner's specific design for access).
3. Remove the filter basket/cartridge.
4. Rinse the filter thoroughly with a garden hose until all debris is removed.
5. Inspect the filter for any damage and replace if necessary.
6. Reinsert the clean filter and close the compartment securely.

# Powerful Active Brushes

Better scrubbing performance



Figure 5: Illustration of the powerful active brushes, which contribute to effective debris collection into the filter.

## 6.2 Draining and Storage

After each use, or before storing for an extended period, ensure the cleaner is properly drained and stored.

1. Remove the cleaner from the pool.
2. Allow the cleaner to drain completely. The quick drainage feature allows for rapid water expulsion.
3. Wipe down the exterior of the cleaner with a soft cloth.
4. Store the cleaner in a cool, dry place, away from direct sunlight and extreme temperatures.

# Quick Drainage Lightweight

For convenience of use



**10**  
Pounds



**10**  
Seconds



Figure 6: The Gosvor Pivot being removed from the pool, highlighting its lightweight design and quick drainage.

## 7. Troubleshooting Guide

Refer to the table below for common issues and their solutions.

Problem	Possible Cause	Solution
Cleaner does not start	Battery is low or depleted.	Charge the cleaner fully.
Cleaner moves slowly or erratically	Filter is clogged with debris.	Clean the filter thoroughly.
Cleaner does not pick up debris effectively	Filter is dirty or damaged; brushes are worn.	Clean or replace the filter; inspect and replace brushes if necessary.

Problem	Possible Cause	Solution
Cleaner stops mid-cycle	Battery is depleted.	Retrieve cleaner and recharge.

## 8. Technical Specifications

Feature	Specification
Model Name	Pivot
Brand	Gosvor
Color	Gray
Product Dimensions	13.4"L x 13.2"W x 6.8"H
Power Source	Battery Powered
Max Pool Area	Up to 1,100 Sq.ft
Battery Life (Approx.)	100 minutes
Charging Time (Approx.)	3 hours

## 9. Warranty and Customer Support

The Gosvor Pivot Robotic Pool Cleaner comes with a manufacturer's warranty. Please refer to the warranty card included in your package for specific terms and conditions, including coverage duration and limitations.

For technical assistance, troubleshooting not covered in this manual, or warranty claims, please contact Gosvor customer support. Contact information can typically be found on the product packaging, the official Gosvor website, or your purchase receipt.

When contacting support, please have your product model name (Pivot) and purchase information readily available to expedite assistance.