Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- Huayu /
- > Huayu SW-V8 Lloyd Smart 6 Voice Remote Control User Manual

Huayu SW-V8 Lloyd Smart 6

Huayu SW-V8 Lloyd Smart 6 Voice Remote Control User Manual

INTRODUCTION

This manual provides detailed instructions for the setup, operation, and maintenance of your Huayu SW-V8 Lloyd Smart 6 Voice Remote Control. This remote is designed for seamless interaction with compatible Lloyd, Sansui, Haier, and Skyworth Smart TVs, offering convenient access to various functions and streaming services.

PRODUCT OVERVIEW

The Huayu SW-V8 Lloyd Smart 6 Voice Remote Control is an ergonomic device designed for intuitive control of your smart television. It features a comprehensive button layout, including dedicated keys for popular streaming platforms and integrated voice control capabilities.





The image displays the black Huayu SW-V8 Lloyd Smart 6 Voice Remote Control alongside its white retail packaging. The remote features a power button, user profile button, Google Assistant button, settings button, a large circular navigation pad, back button, home button, TV input button, volume up/down, mute, and dedicated buttons for Netflix, Prime Video, and YouTube. The packaging highlights 'HUAYU in collaboration with Orange' and states 'SW-V8 LLOYD SMART 6 VOICE REMOTE Use For LLOYD /SANSUI/ HAIER /SKYWORTH'.

Button Functions

- Power Button (Red Circle with Line): Turns the TV on or off.
- User Profile Button (Person Icon): Accesses user profiles or quick settings.
- Google Assistant Button (Colored Circle): Activates voice control for commands and searches.
- Settings Button (Gear Icon): Opens the TV's settings menu.

- Circular Navigation Pad (White Ring): Navigates through menus and selects items.
- Back Button (Left Arrow): Returns to the previous screen or menu.
- Home Button (House Icon): Returns to the TV's home screen.
- TV Input Button (TV Icon): Changes the TV input source.
- Volume Up/Down (+/-): Adjusts the television volume.
- Mute Button (Speaker with Slash): Mutes or unmutes the TV audio.
- Netflix Button: Direct access to the Netflix application.
- Prime Video Button: Direct access to the Prime Video application.
- YouTube Button: Direct access to the YouTube application.

SETUP

1. Battery Installation

- 1. Locate the battery compartment on the back of the remote control.
- 2. Slide open the battery cover.
- 3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
- 4. Close the battery cover securely.

2. Pairing with Your TV

For initial use or after battery replacement, the remote may need to be paired with your TV. The pairing process can vary slightly depending on your TV model. Refer to your TV's user manual for specific instructions if the general steps below do not work.

- 1. Ensure your TV is powered on.
- 2. Point the remote control towards the TV.
- 3. Press and hold the **Home Button** and **Back Button** simultaneously for approximately 3-5 seconds.
- 4. A pairing indicator (often an LED on the remote or a message on the TV screen) should appear, confirming the remote is in pairing mode.
- 5. Release the buttons once the pairing process begins.
- 6. Follow any on-screen prompts on your TV to complete the pairing.

OPERATING INSTRUCTIONS

Basic Navigation

- Use the **Circular Navigation Pad** to move the cursor or highlight items on your TV screen. Press the center of the pad to select.
- Press the **Home Button** to return to the main menu or smart TV dashboard.
- Use the **Back Button** to go back to the previous menu or exit an application.
- Adjust volume with the Volume Up/Down buttons. Press the Mute Button to silence the audio.

Voice Control

- Press the **Google Assistant Button** (colored circle) to activate voice control.
- Speak clearly into the microphone located at the top of the remote.
- You can use voice commands to search for content, open apps, control playback, or ask questions (e.g., "Open Netflix," "Search for action movies," "What's the weather?").

Streaming Service Access

 Press the dedicated Netflix, Prime Video, or YouTube buttons for instant access to these streaming applications.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the remote control. Do not use liquid cleaners or abrasive materials.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or it stops functioning. Always replace both batteries at the same time with new ones of the same type (AAA).
- Storage: If the remote will not be used for an extended period, remove the batteries to prevent leakage.

TROUBLESHOOTING

Issue	Possible Solution
Remote not responding	 Check battery orientation and ensure they are not depleted. Replace if necessary. Ensure there are no obstructions between the remote and the TV's IR receiver. Re-pair the remote with the TV (refer to 'Pairing with Your TV' section).
Voice control not working	 Ensure the remote is properly paired and connected to the TV. Check TV settings to ensure voice control is enabled. Speak clearly and close to the remote's microphone.
Dedicated app buttons not launching apps	 Ensure the TV has an active internet connection. Verify that the respective applications are installed and updated on your TV. Check TV settings for any app restrictions.

SPECIFICATIONS

Feature	Detail
Model	SW-V8 Lloyd Smart 6 (Internal: Ime-rc01)
Brand	Huayu

Feature	Detail
Compatible Devices	Lloyd, Sansui, Haier, Skyworth Smart TVs
Connectivity Technology	Infrared (IR) and Bluetooth (for voice control)
Special Features	Voice Control (Google Assistant), Dedicated Netflix, Prime Video, YouTube Buttons
Power Source	2 x AAA Batteries (not included)
Color	Black
Product Dimensions	Approximately 15 x 4.5 x 15 cm
Item Weight	Approximately 50 g

WARRANTY AND SUPPORT

This product is typically covered by a manufacturer's warranty against defects in materials and workmanship. Please refer to the warranty information provided at the time of purchase or contact your retailer for specific details regarding warranty duration and terms.

For technical support or further assistance, please contact the product retailer or manufacturer's customer service. Keep your purchase receipt as proof of purchase for any warranty claims.

Related Documents - SW-V8 Lloyd Smart 6



Οδηγός Χρήσης Universal Τηλεχειριστηρίου HUAYU RM-L1385

Οδηγίες για τη ρύθμιση και χρήση του universal τηλεχειριστηρίου HUAYU RM-L1385, με χειροκίνητη και αυτόματη αναζήτηση κωδικού.



HUAYU K-1036E+L Universal A/C Remote User Manual and Setup Guide

This document provides a comprehensive user manual for the HUAYU K-1036E+L universal air conditioner remote control. It includes detailed instructions on battery installation, remote setup via manual code entry or automatic search, clock setting, timer functions, and a complete list of compatible air conditioner brands and their corresponding codes.



HUAYU K-91E Universal Air Conditioner Remote Controller User Manual

Comprehensive user manual for the HUAYU K-91E universal air conditioner remote controller, detailing setup, functions, brand compatibility, code search methods, timer settings, and important tips for optimal use.



HUAYU RM-L1200+ Universal Remote Control Setup Guide

Instructions and guide for setting up the HUAYU RM-L1200+ Universal Remote Control, including manual and automatic code search methods.



HUAYU RM-SAT1111+B Universal Satellite Remote Receiver Operating Instructions

Comprehensive operating instructions for the HUAYU RM-SAT1111+B universal satellite remote receiver, including setup, panel description, and troubleshooting.



Huayu RM-L1595 Universal Remote Control User Manual

This manual provides detailed instructions for the Huayu RM-L1595 universal remote control, designed for Telefunken devices. Learn setup, button functions, and troubleshooting tips for seamless operation.