

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [TARSHYRY](#) /

› [TARSHYRY 5-in-1 Electric Trimmer User Manual](#)

TARSHYRY TARSHYRYinxgzymf7c

TARSHYRY 5-in-1 Electric Trimmer User Manual

Model: TARSHYRYinxgzymf7c

1. INTRODUCTION

Thank you for choosing the TARSHYRY 5-in-1 Electric Trimmer. This versatile device is designed for efficient and gentle hair removal across various body parts, including the bikini area, face, eyebrows, nose, arms, and legs. Please read this manual thoroughly before first use to ensure proper operation, maintenance, and safety.



Image 1.1: The TARSHYRY 5-in-1 Electric Trimmer with its various interchangeable heads.

2. PRODUCT OVERVIEW AND FEATURES

The TARSHYRY 5-in-1 Electric Trimmer is engineered for comprehensive personal grooming with its multi-functional design and user-friendly features.

- **5-in-1 Multi-functional Design:** This device includes five interchangeable heads for trimming eyebrows, nose hair, facial hair, underarm hair, arm hair, bikini parts, and thigh hair.
- **Wet & Dry Use:** The trimmer supports both wet and dry operation, allowing for convenient use in the shower or for quick dry trims.
- **Waterproof and Washable:** The entire unit is washable, enabling direct rinsing under water for easy cleaning and hygiene maintenance.
- **Efficient and Smooth Trimming:** Precision trimming structures minimize pulling and discomfort, providing a smooth and effective hair removal experience.
- **Durable Construction:** Made from high-quality ABS and stainless steel for long-lasting performance.
- **180° Rotation:** The main body features a 180-degree rotating head for enhanced flexibility and reach during use.

Full Body Hair Trimmer



Trimming
eyebrow



Trimming
nose hair



Facial shaver



Underarm
hair removal



Arm hair
removal



Bikini parts



Thigh hair
removal



Image 2.1: The main trimmer unit and its five distinct attachment heads.

Painless and Gentle Hair Removal



Image 2.2: Detail of the trimmer heads, highlighting the sharp, skin-friendly blade tip and rounded design for gentle hair removal.

Your browser does not support the video tag.

Video 2.3: A short overview demonstrating the 5-in-1 versatility, painless hair removal, and waterproof design of the TARSHYRY trimmer.

3. COMPONENTS

The package includes the following components:

- Main Trimmer Body
- Bikini Trimmer Head
- Facial Shaver Head
- Eyebrow Trimmer Head
- Nose Hair Trimmer Head
- Cleaning Brush
- USB Charging Cable

4. SETUP AND CHARGING

4.1 Initial Charging

1. Before first use, fully charge the trimmer. Connect the USB charging cable to the trimmer's charging port and a suitable USB power adapter (not included).
2. The LED display will indicate charging status. A full charge typically takes approximately 2-3 hours.
3. Disconnect the charger once fully charged. Do not overcharge.

4.2 Attaching/Detaching Trimmer Heads

1. To attach a head, align the head with the main body and gently twist or push until it clicks into place.
2. To detach a head, twist or pull it gently from the main body. Ensure the device is turned off before changing heads.

5. OPERATION

Ensure your skin is clean and dry or wet, depending on your preference for use. Press the power button to turn the trimmer on.

5.1 Using the Bikini Trimmer Head

- For the bikini area, hold the trimmer flat against the skin and move it slowly against the direction of hair growth.
- The 180° rotating head can be adjusted for optimal angle and reach.

5.2 Using the Facial Shaver Head

- For facial hair, gently glide the shaver head over the skin in small, circular motions or against the direction of hair growth.
- Be cautious around sensitive areas.

5.3 Using the Eyebrow Trimmer Head

- Use for precise shaping and trimming of eyebrows. Move gently in the desired direction.
- Always trim in a well-lit area and use a mirror.

5.4 Using the Nose Hair Trimmer Head

- Carefully insert the trimmer tip into the nostril or ear canal.
- Move the trimmer in a circular motion to trim unwanted hair. Do not insert too deeply.

Powerful and Silent



Image 5.1: The trimmer's head can rotate 180 degrees for flexible use.

DESIGN FOR FULL BODY CARE




Image 5.2: The trimmer is designed for full body care, including armpits, legs, bikini area, and arms.

6. MAINTENANCE AND CLEANING

Regular cleaning ensures optimal performance and hygiene of your trimmer.

1. **Turn Off Device:** Always ensure the trimmer is turned off before cleaning.
2. **Remove Head:** Detach the trimmer head from the main body.
3. **Rinse:** Rinse the detached head and the main body (if used wet) under running water. The device is fully washable.
4. **Brush:** Use the provided cleaning brush to remove any trapped hairs from the blades and inside the head.
5. **Dry:** Allow all parts to air dry completely before reattaching the head or storing the device.
6. **Storage:** Store the trimmer in a cool, dry place away from direct sunlight.

IPX5 Waterproof Easy to clean



Image 6.1: The trimmer is IPX5 waterproof, allowing for easy cleaning under running water.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Trimmer does not turn on.	Battery is low or depleted.	Charge the trimmer fully.
Trimmer pulls hair or is ineffective.	Blades are clogged with hair or dull.	Clean the trimmer head thoroughly. If blades are dull, consider replacing the head if available.
Device stops working during wet use.	Water may have entered internal components (unlikely for waterproof device, but possible if seals are compromised).	Ensure all seals are properly closed before wet use. If issue persists, contact customer support.
Charging indicator not working.	Faulty charging cable or power adapter.	Try a different USB cable and power adapter.

8. SPECIFICATIONS

- **Model Number:** TARSHYRYinxgzymf7c
- **Manufacturer:** TARSHYRY
- **Power Source:** AC/DC (Rechargeable via USB)
- **Item Weight:** 198 Grams (approx. 6.98 ounces)
- **Package Dimensions:** 7.87 x 5.12 x 1.57 inches
- **Waterproof Rating:** IPX5 (for main unit, specific rating for full washability)
- **Additional Features:** Adjustable (referring to rotating head)
- **Recommended Uses:** Indoor/Outdoor personal grooming

9. SAFETY INFORMATION

Please observe the following safety precautions:

- Keep the device out of reach of children.
- Do not use the trimmer on irritated, damaged, or infected skin. Consult a doctor if you have any skin conditions.
- Avoid pressing the blades too hard against the skin to prevent irritation or cuts.
- Do not disassemble or attempt to repair the device yourself. Contact qualified personnel for service.
- Ensure the charging port is dry before connecting the USB cable.
- Do not expose the device to extreme temperatures or direct sunlight for prolonged periods.

10. WARRANTY AND SUPPORT

This product comes with a standard manufacturer's warranty. For warranty claims, technical support, or any questions regarding your TARSHYRY 5-in-1 Electric Trimmer, please refer to the contact information provided with your purchase or visit the official TARSHYRY website.