



Manuals.plus /

› LINSY HOME /

› LINSY HOME Rubik I Modular Sofa Instruction Manual

LINSY HOME Rubik I

LINSY HOME Rubik I Modular Sofa Instruction Manual

Model: Rubik I (B0DY1KJC84)

INTRODUCTION

Thank you for choosing the LINSY HOME Rubik I Modular Sofa. This manual provides essential information for the safe assembly, operation, and maintenance of your new modular sofa. Please read these instructions carefully before use and retain them for future reference.

SAFETY INFORMATION

Important Safety Warnings:

- All foam and upholstered surfaces meet flammability standards.
- Keep the sofa away from open flames or high heat sources to prevent fire hazards.
- Ensure all components are securely fastened during assembly to prevent instability.
- Do not exceed the weight capacity of 300 lbs per seat.

PACKAGE CONTENTS

Before beginning assembly, verify that all components are present and undamaged. The package should include:

- Modular Sofa Sections (4 seats)
- Ottomans (2 units)
- Multifunctional Console
- Cushions
- Assembly Hardware (U-shaped brackets, console feet)



Image: The complete LINSY HOME Rubik I Modular Sofa setup, including the console and two ottomans, arranged in a U-shape configuration in a living room setting.

SETUP AND ASSEMBLY

Assembly of the LINSY HOME Rubik I Modular Sofa is designed to be straightforward and does not require additional tools. Follow these steps:

1. **Unpack Components:** Carefully remove all sofa sections, ottomans, and the console from their packaging.
2. **Attach Console Feet:** Locate the feet for the multifunctional console and securely attach them.
3. **Arrange Sofa Sections:** Position the modular sofa sections and ottomans in your desired configuration. The sofa features interlocking explosion-proof connectors on the underside of each module.
4. **Connect Modules:** Align the U-shaped brackets on the bottom of each module and slide them together to securely connect the sections. This allows for various L-shaped or U-shaped layouts.
5. **Integrate Console:** The console can be placed between any two sofa sections or at the end as an armrest. Ensure it is stable.

1.5X Larger Storage Space




Image: A hand demonstrating how to connect two modular sofa sections using the built-in U-shaped brackets on the underside, ensuring a secure fit.

How Essential is a Tailored Console?




Image: Four different modular sofa configurations, highlighting the versatility of the console and individual sections to create various layouts.

OPERATING INSTRUCTIONS

Modular Flexibility

The Rubik I sofa is designed for ultimate modular flexibility. You can easily reconfigure the sections to adapt to different room layouts or functional needs. To change the configuration, simply lift the connected sections slightly to disengage the U-shaped brackets, rearrange as desired, and then reconnect.

Using the Multifunctional Console

The console serves multiple purposes:

- **Charging Station:** The console is equipped with 2 AC outlets, 1 USB port, and 1 Type-C port. Plug in the console's power cord to an electrical outlet to activate the charging features.
- **Reversible Tabletop:** The console features a reversible tabletop. One side is wooden for stability, suitable for drinks or snacks. The other side is padded for comfort, functioning as an armrest or additional seating surface.
- **Hidden Storage:** Lift the tabletop to access a hidden storage compartment, ideal for remotes, books, or small items.



Image: A person utilizing the integrated power outlets (2 AC, 1 USB, 1 Type-C) on the console to charge a laptop, with a drink in the cup holder and the wooden tabletop in use.

Product Size



Securely connect sofa with sturdy U-shaped brackets




Image: A detailed view of the multifunctional console, showing its dimensions, integrated power strip, cup holders, reversible tabletop, and a pull-out drawer for additional storage.

Hidden Storage Seats

Each seat module and ottoman includes a hidden storage compartment. To access, simply lift the seat cushion. These compartments are suitable for storing blankets, pillows, remote controls, or board games, helping to keep your living space organized.

Tailor-Made Accessories

The Selection That Gives Your Lovely Sofa A Boost





Image: A sofa seat with its cushion lifted, revealing a spacious hidden storage compartment underneath, suitable for various household items.

MAINTENANCE AND CARE

Proper care will extend the life and appearance of your LINSY HOME sofa.

- **Cleaning Fabric:** The durable polyester fabric is designed for easy maintenance. For general cleaning, vacuum regularly to remove dust and debris.
- **Spot Cleaning:** For spills, blot immediately with a clean, dry cloth. For stubborn stains, use a mild fabric cleaner according to the product instructions, testing on an inconspicuous area first.
- **Removable Covers:** Most seat and back cushion covers are removable for washing (armrest covers are not removable). Follow the care instructions on the fabric label for best results.
- **Frame Care:** Wipe the sofa frame and console surfaces with a soft, damp cloth. Avoid harsh chemicals.



Image: A woman removing a blue cushion cover from a sofa, indicating that covers are removable for washing, with a dog sitting nearby.

TROUBLESHOOTING

This section addresses common issues you might encounter.

- **Sofa sections do not connect securely:** Ensure the U-shaped brackets on the underside of each module are properly aligned and fully engaged. Lift and reseat the modules if necessary.
- **Console charging ports are not working:** Verify that the console's power cord is securely plugged into a functional electrical outlet. Check for any tripped circuit breakers.
- **Storage drawer/lid does not close properly:** Check for any obstructions inside the storage compartment or along the drawer tracks. Ensure the item is not overfilled.
- **Sofa feels too firm:** The seat cushions feature a blend of Bamboo Charcoal Memory Foam and high-density foam. Initial firmness is normal and will soften slightly with use.

SPECIFICATIONS

Brand	LINSY HOME
Model	Rubik I Modular Sofa
Type	Sectional, Modular
Color	Blue
Product Dimensions (Overall)	45.7"D x 127.6"W x 34.3"H
Seat Height	17.7 Inches
Seating Capacity	6.0
Weight Capacity (per seat)	300 lbs
Material	Polyester Fabric, Bamboo Charcoal Memory Foam, High-Density Foam, Steel Springs, Wood Frame
Special Features	Hidden Storage, Multifunctional Console (2 AC outlets, 1 USB, 1 Type-C), Modular Design
Assembly Required	Yes
Certifications	CA65 certified polyester fabric, BIFMA X5.4-2020 (for safety, durability, structure)

Product Size & Weight Capacity



Image: A diagram illustrating the overall dimensions of the modular sofa in a U-shape configuration, including individual module

measurements and the 300 lbs weight capacity per seat.

WARRANTY INFORMATION

The LINSY HOME Rubik I Modular Sofa comes with a **Limited Warranty**. For specific terms and conditions, please refer to the warranty card included with your purchase or contact LINSY HOME customer support.

CUSTOMER SUPPORT

If you have any questions, require assistance with assembly, or need to report a missing or damaged part, please contact LINSY HOME customer support through the retailer where you purchased the product or visit the official LINSY HOME website for contact details.

For more information, visit the [LINSY HOME Store on Amazon](#).

