

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [DUSONLAP](#) /

› [DUSONLAP E6 Open Ear Earbuds User Manual](#)

DUSONLAP E6

DUSONLAP E6 Open Ear Earbuds User Manual

Model: E6

INTRODUCTION

Thank you for choosing the DUSONLAP E6 Open Ear Earbuds. This manual provides essential information for setting up, operating, and maintaining your new earbuds. Please read it carefully to ensure optimal performance and longevity of your device.




The DUSONLAP E6 earbuds are designed for a perfect fit and all-day comfort, preserving ear health.

PACKAGE CONTENTS

Please check the package for the following items:

- Open-ear headphones (Left & Right)
- Quick charging case
- USB-C fast charging cable
- User Manual



The package includes the DUSONLAP E6 open ear headphones, their quick charging case, a USB-C fast charging cable, and this user manual.

PRODUCT OVERVIEW

The DUSONLAP E6 Open Ear Earbuds are designed for comfort and high-quality audio. Featuring an open-ear design, they allow you to stay aware of your surroundings while enjoying your audio. Equipped with Bluetooth 5.4 and 14.2mm dynamic drivers, they deliver clear sound and stable connectivity.

DUSONLAP E6

Perfect Fit and All-Day Comfort
Preserve Your Ears

- Bluetooth 5.4
- IPX7 Waterproof
- Smart Touch Control
- Comfortable to Wear
- HiFi Sound
- 32 Hours Playtime

The DUSONLAP E6 earbuds feature 14.2mm dynamic drivers for powerful HiFi stereo sound and Bluetooth 5.4 for clear calls.

SETUP

1. Charging the Earbuds and Case

Before first use, fully charge the earbuds and the charging case. Connect the provided USB-C cable to the charging case and a power source. The charging case features an intuitive smart display to show battery levels.

- A single charge provides up to 8 hours of playtime for the earbuds.
- The charging case extends total playtime to 32 hours.
- A full charge for the case typically takes 1.5 hours.

IPX7 Water-Resistant

Resistant to rain and sweat, perfect for intense workouts and outdoor activities.




The charging case provides up to 32 hours of total playtime, with 8 hours on a single earbud charge and 1.5 hours for a full charge.

2. Wearing the Earbuds

The DUSONLAP E6 earbuds feature an ergonomic ear hook design for a secure and comfortable fit without inserting into the ear canal.

1. **Step 1:** Simply remove the headphones from the charging case.
2. **Step 2:** Hang the headphones on your ear bone for a perfect fit.
3. **Step 3:** Turn the earphones and slide it behind the ear.
4. **Step 4:** Adjust the ear hook, wear, and pull down the ear hook for a secure fit.




Follow these steps to correctly wear your DUSONLAP E6 earbuds for optimal comfort and secure fit.

Bluetooth 5.4 & Superior Call Clarity

① Bluetooth 5.4 Enhanced

Bluetooth 5.4 – Faster Data Transfer, Reliable Performance.



The ergonomic ear hook design ensures a comfortable and secure fit, made from skin-friendly, ultra-lightweight silicone.

3. Pairing with Your Device

The earbuds utilize Bluetooth 5.4 for quick and stable connections.

1. **One-Step Pairing:** Open the charging case. The earbuds will automatically power on and enter pairing mode.
2. On your device (smartphone, tablet, laptop), go to Bluetooth settings and select "E6" from the list of available devices.
3. Once connected, you will hear a confirmation tone, and the earbuds will be ready for use.
4. To disconnect, simply place the earbuds back into the charging case and close the lid. They will automatically power off and disconnect.



Ride with Confidence, Stay in Tune.

Open-ear design lets you enjoy music while staying alert to traffic and surroundings, ensuring safety on every ride.

The earbuds feature one-step pairing: simply open the case to automatically connect to your device.


OPERATING THE EARBUDS

Touch Controls

The DUSONLAP E6 earbuds feature touch-sensitive controls on each earbud. The following table outlines the common functions:

Action	Function
Single Tap (L/R)	Play / Pause Music

Action	Function
Double Tap (L)	Volume -
Double Tap (R)	Volume +
Triple Tap (L/R)	Activate Voice Assistant
Press & Hold (L) for 2s	Previous Track
Press & Hold (R) for 2s	Next Track
Single Tap (during call)	Answer / End Call
Press & Hold (during call) for 2s	Reject Call



Wide Compatibility

Whether it is iOS or various Android smartphones and tablets, laptops, etc, you can easily pair them for a fast and stable connection

The DUSONLAP E6 earbuds feature intuitive touch controls for managing music playback, calls, and activating your device's voice assistant.

MAINTENANCE

1. Cleaning

To maintain optimal performance and hygiene, regularly clean your earbuds and charging case.

- Use a soft, dry, lint-free cloth to wipe the earbuds and charging case.
- Do not use abrasive cleaners, solvents, or aerosol sprays.
- Avoid getting moisture into any openings.

2. Water Resistance

The DUSONLAP E6 earbuds are rated IPX7 waterproof, meaning they can withstand sweat, rain, and splashes. This makes them suitable for workouts and outdoor activities.

- Do not submerge the earbuds in water for extended periods.
- Ensure the earbuds are dry before placing them back into the charging case to prevent damage.

Smart Touch Control



The earbuds are IPX7 waterproof, making them resistant to sweat, rain, and splashes for use in various conditions.

3. Storage

When not in use, store the earbuds in their charging case to protect them from dust and damage, and to keep them charged.

- Store in a cool, dry place away from extreme temperatures.
- Avoid dropping or subjecting the earbuds and case to strong impacts.

TROUBLESHOOTING

If you encounter any issues with your DUSONLAP E6 earbuds, please refer to the following common solutions:

1. Earbuds Not Pairing:

- Ensure both earbuds are charged.
- Turn off Bluetooth on your device and turn it back on.
- Delete "E6" from your device's Bluetooth history and try pairing again.
- Place earbuds back in the case, close the lid, wait a few seconds, then open to re-initiate pairing mode.

2. No Sound or Low Volume:

- Check the volume level on both your device and the earbuds.
- Ensure the earbuds are properly connected to your device.
- Try playing audio from a different application or source.

3. Charging Issues:

- Verify the USB-C cable is securely connected to both the case and the power source.
- Try using a different USB-C cable or power adapter.
- Ensure the charging contacts on the earbuds and inside the case are clean and free of debris.

4. Intermittent Connection:

- Ensure you are within the Bluetooth range (up to 15 meters) of your device.
- Avoid strong electromagnetic interference from other devices.
- Reset the earbuds by placing them in the case and closing the lid for 10 seconds.

SPECIFICATIONS

Key technical specifications for the DUSONLAP E6 Open Ear Earbuds:

Feature	Detail
Model Name	E6
Connectivity Technology	Wireless (Bluetooth)
Bluetooth Version	5.4
Bluetooth Range	15 Meters
Audio Driver Type	Dynamic Driver (14.2mm)
Battery Life (Earbuds)	Up to 8 Hours
Total Playtime (with Case)	Up to 32 Hours
Charging Time (Case)	Approx. 1.5 Hours
Water Resistance Level	IPX7
Control Method	Touch Control
Earpiece Shape	Open-ear
Material	Silicone
Item Weight	0.15 Kilograms (5.3 ounces)

WARRANTY AND SUPPORT

DUSONLAP stands behind the quality of its products.

- Warranty:** The DUSONLAP E6 earbuds come with a two-year warranty from the date of purchase, covering manufacturing defects.
- Customer Service:** For any questions, technical support, or warranty claims, please contact DUSONLAP customer service. Refer to the contact information provided on the product packaging or the official DUSONLAP website.

Why choose DUSONLAP E6?

- ① Open design
- ② Flexible and skin-friendly material
- ③ Ultra-light design
- ④ 24-hour customer service
- ⑤ Two-year warranty



The DUSONLAP E6 earbuds offer an open design, flexible and skin-friendly materials, an ultra-light design, and come with a two-year warranty.

© 2025 DUSONLAP. All rights reserved.