

[Manuals.plus](#) /

> [Cozmara](#) /

> Cozmara Candle Warmer Lamp with Timer & Dimmer Instruction Manual (Model CWL-US001)

Cozmara CWL-US001

Cozmara Candle Warmer Lamp Instruction Manual

Model: CWL-US001

IMPORTANT SAFETY INSTRUCTIONS

Please read all instructions carefully before using the Cozmara Candle Warmer Lamp. Retain this manual for future reference.

- Do not immerse the lamp or power cord in water or other liquids.
- Always place the lamp on a stable, flat, heat-resistant surface.
- Ensure the candle jar is centered directly beneath the warming bulb.
- Do not touch the bulb or the area directly beneath it when the lamp is in operation, as it will be hot.
- Unplug the lamp from the power outlet when not in use or before cleaning.
- Keep out of reach of children and pets.
- Use only the specified bulb type (GU10 halogen bulb, 35W).
- Do not use with candles that have wicks, as this product is designed for flameless wax melting.

PRODUCT OVERVIEW

The Cozmara Candle Warmer Lamp provides a flameless and smokeless method for melting scented jar candles, releasing their fragrance safely. It features an adjustable height mechanism, a timer function, and a dimmer control for customized use.



Figure 1: Cozmara Candle Warmer Lamp in black with a scented candle.

Key features include:

- **Adjustable Height:** The lamp's height can be adjusted to accommodate various sizes of jar candles, ensuring optimal warming.
- **Timer Function:** Set the lamp to automatically turn off after 2, 4, or 8 hours.
- **Dimmer Control:** Adjust the brightness of the bulb, which also controls the heat intensity for wax melting.

- **Flameless Operation:** Melts wax using heat from the bulb, eliminating the need for an open flame and reducing soot.



Figure 2: Flameless and smokeless operation of the candle warmer lamp.

PACKAGE CONTENTS

Verify that all items are present in the package:

- Cozmara Candle Warmer Lamp (1 unit)

- GU10 Halogen Bulbs (2 units)
- Instruction Manual (this document)

SETUP

1. **Unpack:** Carefully remove all components from the packaging.
2. **Insert Bulb:** Gently insert one of the provided GU10 halogen bulbs into the lamp head socket. Ensure it is securely twisted into place.
3. **Place Candle:** Position your desired jar candle on the wooden base of the lamp.
4. **Adjust Height:** Loosen the knob on the lamp's stand to adjust the height of the lamp head. Position the bulb approximately 1-2 inches above the top surface of the candle for optimal warming. Tighten the knob to secure the height.




Figure 3: Adjustable height mechanism for different candle sizes.

5. **Connect Power:** Plug the power cord into a standard electrical outlet.

OPERATING INSTRUCTIONS

The Cozmara Candle Warmer Lamp is controlled via an inline switch on the power cord.




Figure 4: Inline control panel for the candle warmer lamp.

1. **Power On/Off:** Press the power button (**O/I**) to turn the lamp on or off.
2. **Adjust Brightness/Heat:** Use the plus (+) and minus (-) buttons to cycle through the 4 brightness levels. Higher brightness levels provide more heat for faster wax melting and stronger fragrance diffusion.
3. **Set Timer:** Press the timer button (**Clock icon**) to select a desired operating duration: 2 hours, 4 hours, or 8 hours. The lamp will automatically shut off after the selected time.

For a visual demonstration of the product's features, please refer to the official video below:

Your browser does not support the video tag.

Video 1: Official video demonstrating the features and operation of the Cozmara Candle Warmer Lamp, including its timer and dimmer functions.

MAINTENANCE

- **Cleaning:** Ensure the lamp is unplugged and completely cool before cleaning. Wipe the lamp and base with a soft, dry cloth. Do not use abrasive cleaners or immerse in water.
- **Bulb Replacement:** If the bulb burns out, ensure the lamp is unplugged and cool. Carefully remove the old bulb and replace it with a new GU10 halogen bulb (35W).

TROUBLESHOOTING

Problem	Possible Cause	Solution
Lamp does not turn on.	Not plugged in; power outage; faulty bulb.	Check power connection; verify power outlet; replace bulb.
Candle wax not melting or scent is weak.	Bulb too far from candle; low brightness setting; candle type.	Adjust lamp height closer to the candle; increase brightness setting; ensure candle is suitable for warmer lamps.
Lamp turns off unexpectedly.	Timer function activated.	Check timer setting; reset if necessary.

SPECIFICATIONS

Feature	Detail
Brand	Cozmara
Model Number	CWL-US001
Color	Black
Material	Metal
Product Dimensions	9.5"L x 5.5"W x 5.5"H
Item Weight	1.8 Pounds
Number of Pieces	1
Mounting Type	Tabletop
UPC	635508742260

WARRANTY AND SUPPORT

For warranty information or technical support, please contact Cozmara customer service through the retailer where the product was purchased or visit the official Cozmara website. Please have your model number (CWL-US001) and purchase date available when contacting support.



© 2025 Cozmara. All rights reserved.