

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [VTech](#) /

› [VTech Sing and Stroll Kitty Instruction Manual](#)

VTech 80-574835

VTech Sing and Stroll Kitty Instruction Manual

Model: 80-574835

[Introduction](#)

[What's in the](#)

[Box](#)

[Setup](#)

[Operating](#)

[Maintenance](#)

[Troubleshooting](#)

[Warranty &](#)

[Support](#)

[Specifications](#)

1. INTRODUCTION

The VTech Sing and Stroll Kitty is an interactive pull-along toy designed for children aged 12-36 months. This toy encourages motor skill development through pushing and pulling, while also introducing numbers, feelings, and music through light-up buttons. It includes accessories for pretend play, fostering imaginative animal care.



The VTech Sing and Stroll Kitty, ready for interactive play.

2. WHAT'S IN THE BOX

Please ensure all components are present before use:

- Sing and Stroll Kitty
- Mouse accessory
- Bottle accessory
- Ball accessory
- Quick Start Guide



The Sing and Stroll Kitty with all its accessories.

3. SETUP

3.1 Battery Installation

The VTech Sing and Stroll Kitty requires 2 AAA batteries for operation. Batteries are included for demonstration purposes only; new batteries are recommended for regular use.

1. Locate the battery compartment on the underside of the kitty.
2. Using a screwdriver, open the battery compartment cover.
3. Insert 2 new AAA batteries, ensuring correct polarity (+/-).
4. Replace the battery compartment cover and secure it with the screw.



The battery compartment is located on the underside of the toy.

3.2 Power On/Off and Volume Control

Locate the power switch and volume control slider on the side of the kitty. Slide the switch to the 'On' position to activate the toy. Adjust the volume to your preferred level using the slider.

4. OPERATING INSTRUCTIONS

4.1 Push and Pull Play

The Sing and Stroll Kitty is designed for interactive movement. Push or pull the kitty using the attached cord to hear melodies, songs, and sound effects. Observe as the kitty wobbles and swishes its tail during movement, engaging your child's motor skills.



Pull the kitty to activate sounds and tail movement.

4.2 Interactive Buttons

The kitty features colorful light-up buttons on its side. Press these buttons to:

- Listen to various songs and melodies.
- Learn about the kitty and its characteristics.
- Explore numbers and feelings through engaging phrases.



Press the light-up buttons for interactive learning and music.

4.3 Pretend Play Accessories

Use the included bottle, mouse, and ball accessories to engage in imaginative animal care. Children can pretend to feed, play with, and care for their kitty, fostering nurturing skills and creative play.



Engage in pretend play with the kitty and its accessories.

4.4 Official Product Video

Watch the official VTech video demonstrating the Sing and Stroll Kitty's features, including its walking, wiggling tail, interactive buttons, and accessories.

5. MAINTENANCE

5.1 Cleaning Instructions

To clean the VTech Sing and Stroll Kitty, wipe the surface with a slightly damp cloth. Do not immerse the toy in water. Avoid using harsh chemicals or abrasive cleaners.

5.2 Cord Storage

When the toy is not in use, the pull cord can be conveniently stored in a dedicated compartment located on the underside of the kitty. This helps keep the toy tidy and prevents tangles.



The pull cord can be stored in the compartment underneath the kitty.

6. TROUBLESHOOTING

If you experience issues with your VTech Sing and Stroll Kitty, please refer to the following common solutions:

- **No Sound or Intermittent Sound:** Check if the power switch is in the 'On' position and if the volume is turned up. Replace batteries if they are low or depleted.
- **Toy Not Moving/Wobbling:** Ensure the toy is on a flat, smooth surface. Check if the wheels are obstructed. Verify that batteries are correctly installed and have sufficient power.
- **Buttons Not Responding:** Replace batteries. Ensure the toy is powered on.

If problems persist, please contact VTech customer support.

7. SPECIFICATIONS

Feature	Detail
Product Dimensions	9.96 x 8.03 x 4.57 inches
Item Weight	1.2 pounds

Model Number	80-574835
Manufacturer Recommended Age	12 months and up
Batteries	2 AAA batteries required (included for demo)
Release Date	June 15, 2025

8. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the VTech Quick Start Guide included with your product or visit the official VTech website. You can also visit the [VTech Store on Amazon](#) for additional product information and resources.