

[Manuals.plus](#) /

› [EDJO](#) /

› EDJO 2.4G Full-Sized Ergonomic Wireless Keyboard and Mouse Combo User Manual

EDJO B0FD9FR46G

EDJO 2.4G Full-Sized Ergonomic Wireless Keyboard and Mouse Combo User Manual

Model: B0FD9FR46G

1. INTRODUCTION

This manual provides comprehensive instructions for the setup, operation, maintenance, and troubleshooting of your EDJO 2.4G Full-Sized Ergonomic Wireless Keyboard and Mouse Combo. Please read this manual carefully before using the product to ensure proper function and longevity.



Image 1.1: The EDJO 2.4G Full-Sized Ergonomic Wireless Keyboard and Mouse Combo.

2. SETUP

2.1 Package Contents

- 1 x EDJO Wireless Keyboard
- 1 x EDJO Wireless Mouse
- 1 x 2.4G USB Receiver (stored in the mouse battery compartment)
- 1 x User Manual

2.2 Battery Installation

The keyboard requires one (1) AA battery, and the mouse requires one (1) AA battery (batteries not included).

1. **For the Mouse:** Open the battery compartment cover located on the underside of the mouse. Insert one AA battery, ensuring correct polarity (+/-). The 2.4G USB receiver is stored in this compartment. Remove the receiver before

closing the cover.

2. **For the Keyboard:** Open the battery compartment cover on the underside of the keyboard. Insert one AA battery, ensuring correct polarity (+/-). Close the cover.

WIRELESS OPTICAL MOUSE

3 Levels Adjustable DPI
(800-1600-2400)



Previous Page

Next Page

Anti-slip roller



Laser light

ON/OFF Switch



USB Receiver

1 x AA battery
(Not Included)

Note: The USB receiver is stored in the battery compartment of the mouse.

Image 2.1: Location of the USB receiver and battery compartment in the mouse.




Image 2.2: The USB receiver is securely stored within the mouse's battery compartment.

2.3 Connecting the USB Receiver

1. Locate the 2.4G USB receiver inside the mouse battery compartment.
2. Plug the USB receiver into an available USB port on your computer (desktop, laptop, PC, etc.).
3. The keyboard and mouse will automatically connect to your computer. No additional drivers or software installation are required.

2.4G WIRELESS KEYBOARD AND MOUSE COMBO

Plug & Play, One nano receiver connects both the keyboard and mouse



Image 2.3: The 2.4G wireless connection provides a stable link up to 33 feet (10 meters).



Image 2.4: The compact 2-in-1 nano USB receiver connects both keyboard and mouse.

3. OPERATING INSTRUCTIONS

3.1 Keyboard Features

- **Ergonomic Design:** The full-sized keyboard features an integrated palm rest and foldable holders to maintain an optimal typing angle, reducing wrist strain during extended use.
- **Anti-Slide Pads:** Equipped with anti-slide pads to ensure stability during rapid typing.
- **Indicator Lights:** Includes dedicated indicator lights for Number Lock, Caps Lock, and Power status.



Image 3.1: The ergonomic design of the keyboard, featuring a palm rest and foldable stand.



Image 3.2: Close-up of the Number Lock, Caps Lock, and Power indicator lights on the keyboard.

3.2 Mouse Features

- **Optical Tracking:** Provides precise control on various surfaces.
- **Adjustable DPI:** Cycle through 3 DPI levels (800/1600/2400) to adjust cursor speed to your preference.
- **Symmetrical Design:** Suitable for both right-handed and left-handed users.
- **Navigation Buttons:** Includes dedicated 'Previous Page' and 'Next Page' buttons for enhanced browsing.



Image 3.3: The mouse features 3 adjustable DPI levels: 800, 1600, and 2400.

3.3 Automatic Power Saving Function

To conserve battery life, both the keyboard and mouse feature an automatic power-saving mode:

- The keyboard enters sleep mode after 30 minutes of inactivity.
- The mouse enters sleep mode after 25 seconds of inactivity.

To reactivate the device, simply click any button on the mouse or press any key on the keyboard.

3.4 Compatibility

This wireless keyboard and mouse combo is compatible with Windows XP/Vista/7/8/10/X, Mac OS, and other operating systems. It works effectively with desktops, Chromebooks, PCs, laptops, and more. Note: Some multimedia functions may not be available on Mac OS.

WIDE COMPATIBILITY

Compatible with windows XP/Vista/7/8/10, Mac and other operating system

Note: Some multimedia function are not available with Mac OS



PC



Laptop



Desktop



TV




Image 3.4: The combo is compatible with various operating systems including Windows and Mac OS.

4. MAINTENANCE

4.1 Battery Replacement

When the keyboard or mouse stops responding or exhibits intermittent connectivity, it may be time to replace the batteries. Follow the battery installation steps in Section 2.2 to replace the AA batteries in both devices.

4.2 Cleaning

To clean your keyboard and mouse, use a soft, dry cloth. For stubborn dirt, lightly dampen the cloth with water or a mild cleaning solution. Avoid using harsh chemicals or abrasive materials. Ensure devices are powered off before cleaning.

4.3 Spill-Resistant Design

The keyboard features a spill-resistant design, which helps protect against accidental liquid spills. In case of a spill, immediately disconnect the keyboard from your computer and allow it to dry completely before reuse. This feature is

designed to mitigate damage but does not guarantee full waterproofing.



Image 4.1: The keyboard's spill-resistant design helps protect against minor liquid exposure.

5. TROUBLESHOOTING

- **No Connection/Lag:**
Ensure the USB receiver is securely plugged into a working USB port. Check that both the keyboard and mouse have fresh batteries installed. Move the devices closer to the USB receiver to rule out range issues (maximum 33 feet).
- **Devices Not Turning On:**
Verify that batteries are correctly inserted with proper polarity. Replace batteries with new ones if necessary.
- **Mouse Tracking Issues:**
Clean the optical sensor on the underside of the mouse. Ensure you are using the mouse on a suitable surface; highly reflective or transparent surfaces may affect tracking. Adjust the DPI setting using the button on the mouse.
- **Keyboard Input Errors:**
Check for any stuck keys. Ensure the keyboard is not in sleep mode. Re-insert the USB receiver.

6. SPECIFICATIONS

Feature	Detail
Brand	EDJO
Model	B0FD9FR46G
Color	Galaxy Blue
Connectivity Technology	2.4G Wireless
Special Features	Ergonomic, Wrist Rest
Compatible Devices	Laptop, Personal Computer
Power Source	Battery Powered (1x AA for keyboard, 1x AA for mouse)
Keyboard Layout	QWERTY
Number of Keys	104

Keyboard Description	Membrane
Mouse DPI Levels	800/1600/2400
Hand Orientation	Ambidextrous
Compatible Operating Systems	Chrome OS, Linux, Mac OS, Windows

7. WARRANTY AND SUPPORT

7.1 Warranty Information

This EDJO product comes with a 12-month warranty from the date of purchase. This warranty covers manufacturing defects and malfunctions under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or external factors.

7.2 Customer Support

If you encounter any issues or have questions regarding your EDJO Wireless Keyboard and Mouse Combo, please contact us directly via Amazon email. Our customer service team is available to provide assistance and satisfactory solutions.



Image 7.1: Diagram illustrating the recommended customer support process: contact seller first for assistance.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question