

Dreazu G2-Pro

Dreazu Pro Electric Spin Scrubber G2-Pro User Manual

Model: G2-Pro

1. INTRODUCTION

The Dreazu Pro Electric Spin Scrubber G2-Pro is designed to simplify household cleaning tasks. This device features a high-torque motor, variable speed control, and a retractable long handle, making it suitable for various surfaces including bathrooms, kitchens, and floors. This manual provides essential information for the safe and effective use of your electric spin scrubber.

2. SAFETY INFORMATION

- Read all instructions before using the appliance.
- Keep the appliance away from children.
- Do not immerse the entire unit in water. The unit is IPX7 waterproof, meaning it can withstand immersion in up to 1 meter of water for 30 minutes, but continuous submersion is not recommended.
- Use only the provided charging cable and a compatible Type-C adapter (not included).
- Do not operate the scrubber if it is damaged or malfunctioning.
- Avoid contact with moving parts during operation.
- Ensure the brush head is securely attached before use.
- Store the scrubber in a dry place when not in use.

3. PACKAGE CONTENTS

Verify that all items are present in your package:

- Dreazu Pro Electric Spin Scrubber Main Unit

- Retractable Extension Handle
- Multiple Interchangeable Brush Heads (10-in-1 versatility, including Big Flat Brush, Corner Brush, Small Brush, Gap Brush, Fibre Sponge, Sponge, Wool Cloth, Cloth)
- Type-C Charging Cable
- User Guide (this document)

7 Replacement Brush Heads

1 Gap Brushes

Meet Your Different Cleaning Needs



Figure 1: Included brush heads for various cleaning needs.

4. SETUP

4.1 Assembly

1. **Attach Brush Head:** Align the desired brush head with the main unit's rotating base and press firmly until it clicks into place. To remove, pull the brush head off.
2. **Attach Extension Handle (Optional):** For extended reach, connect the main unit to the retractable extension handle. Ensure it is securely twisted or clicked into place. The handle offers adjustable lengths from 11 inches to 48 inches. Press the button on the handle to adjust its length.




Figure 2: Easy assembly and charging port location.

4.2 Charging the Scrubber

Before first use, fully charge the scrubber. The device features an upgraded cell with AI protection for enhanced battery life and safety.

- Locate the Type-C charging port on the main unit.
- Connect the provided Type-C charging cable to the scrubber and a compatible Type-C adapter (not included).
- Charging typically takes approximately 3 hours.
- Indicator lights will show charging status. A full charge provides 60-90 minutes of working time.

Upgraded Cell with AI Protection



Figure 3: Charging the scrubber and battery protection features.

5. OPERATING INSTRUCTIONS

5.1 Power On/Off and Speed Control

The scrubber offers two working speeds:

- **Low Speed:** 350 RPM
- **High Speed:** 450 RPM

To operate:

1. Press the power button once to turn on the scrubber at Low Speed (350 RPM).
2. Press the power button a second time to switch to High Speed (450 RPM).
3. Press the power button a third time to turn off the scrubber.

Upgrade-High Speed Power

High-speed power washers

Efficient and effortless cleaning for better results

Charging Time

3 Hours

Working Time

60-90 Mins

2 MODE

350-450RPM



Double bearing rotation



More stable brush head



Larger cleaning Area



Fast heat dissipation

Figure 4: Power and speed controls.

5.2 Using Different Brush Heads

Select the appropriate brush head for your cleaning task:

- **Big Flat Brush:** Ideal for large flat surfaces like tile floors, walls, and shower doors.
- **Corner Brush:** Designed for cleaning corners, grout lines, and tight spaces.
- **Small Brush:** Suitable for smaller areas, fixtures, and detailed cleaning.
- **Gap Brush:** Specifically for narrow gaps and crevices.
- **Fibre Sponge, Sponge, Wool Cloth, Cloth:** For delicate surfaces, polishing, or specific cleaning agents.

Apply a suitable cleaning solution to the surface or brush head before operating the scrubber. Move the scrubber slowly over the surface, allowing the rotating brush to do the work.



Figure 5: Installation and use of flat brushes.



Figure 6: Installation and use of soft cleaning attachments.



Figure 7: Installation and use of corner and gap brushes.

5.3 Waterproof Rating

The entire machine is IPX7 waterproof, allowing it to be rinsed directly under a faucet. However, do not use the scrubber under water for extended periods or immerse it deeper than 1 meter.

IPX7 Waterproof



Figure 8: IPX7 Waterproof feature.

6. MAINTENANCE

6.1 Cleaning the Scrubber

- After each use, remove the brush head and rinse it thoroughly under running water.
- Wipe the main unit and handle with a damp cloth to remove any residue.
- Ensure all parts are dry before storing.

6.2 Storage

Store the Dreazu Pro Electric Spin Scrubber in a cool, dry place, away from direct sunlight and extreme temperatures. Keep brush heads organized and clean for future use.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Scrubber does not turn on.	Battery is depleted.	Charge the scrubber for 3 hours.
Reduced power or inconsistent rotation.	Low battery. / Brush head entangled.	Recharge the unit. / Check for hair or debris in the brush head and clear it. The unit has an auto-stop feature for entanglement.
Brush head detaches during use.	Brush head not securely attached.	Ensure the brush head clicks firmly into place during assembly.

8. SPECIFICATIONS

Feature	Detail
Brand	Dreazu
Model	G2-Pro
Color	Metalgray
Handle Material	Metal
Product Dimensions (L x W x H)	16.25" x 7.29" x 3.15"
Item Weight	1.22 Kilograms
Material Type	Acrylonitrile Butadiene Styrene (ABS), Metal, Stainless Steel, Steel
Speeds	Low: 350 RPM, High: 450 RPM
Charging Time	Approx. 3 hours
Working Time	60-90 minutes
Waterproof Rating	IPX7
Handle Length Adjustment	11 inches - 48 inches

9. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the contact details provided with your purchase or visit the official Dreazu website. Keep your purchase receipt as proof of purchase.