

[Manuals.plus](#) /

› [Energizer](#) /

› Energizer LED Flashlight Instruction Manual

Energizer 30039800129322

Energizer Vision HD Performance Metal Flashlight Instruction Manual

Model: 30039800129322

1. INTRODUCTION

The Energizer Vision HD Performance Metal Flashlight with Digital Focus is designed to provide powerful and reliable illumination for various situations, from outdoor activities like camping and hiking to emergency preparedness during power outages. Featuring MAXVIZ technology, this flashlight delivers a bright, high-definition beam that replicates natural daylight, offering enhanced direct and peripheral vision.




Figure 1: Energizer Vision HD Performance Metal Flashlight

2. KEY FEATURES

- **High Brightness:** Delivers up to 400 lumens, providing a powerful beam up to 115 meters.
- **MAXVIZ Technology:** Replicates daylight color and definition for optimal visibility.
- **Digital Focus:** Allows convenient adjustment from a spot beam to a flood light.

- **Multiple Light Modes:** Features High, Low, and Emergency Strobe light modes.
- **Durable Construction:** Made with aircraft-grade aluminum for maximum durability.
- **Water Resistance:** IPX4 water-resistant construction withstands splashing.
- **Long-Lasting:** Provides up to 21 hours of runtime in low mode.
- **Battery Powered:** Operates on 2 AA batteries (included).



Figure 2: Durable Aircraft-Grade Aluminum Body

IPX4 WATER RESISTANCE

WITHSTANDS SPLASHING



Figure 3: IPX4 Water Resistance

HIGH MODE



ENERGY SAVER MODE



EMERGENCY STROBE)))



Figure 4: Multiple Light Modes

REPLICATES DAYLIGHT WITH MAXVIZ™ TECHNOLOGY



Figure 5: MAXVIZ Technology for Daylight Replication

3. SETUP

3.1 Battery Installation

Your Energizer Vision HD Performance Metal Flashlight requires 2 AA batteries, which are included with the product. To install or replace batteries:

1. Unscrew the tail cap of the flashlight by turning it counter-clockwise.
2. Insert two AA batteries into the battery compartment, ensuring the positive (+) and negative (-) ends align with the indicators inside the flashlight body. Typically, the positive end of the battery faces towards the head of the flashlight.
3. Screw the tail cap back on clockwise until it is securely tightened. Do not overtighten.

Note: It is recommended to check the included batteries for any signs of corrosion or rattling before first use, as some users have reported issues with pre-installed batteries. If issues occur, replace with fresh, high-quality AA alkaline batteries.

4. OPERATING INSTRUCTIONS

4.1 Power On/Off

To turn the flashlight on or off, locate the power button on the side of the flashlight body. Press the button once to turn it on, and press it again to turn it off.



Figure 6: Power Button Location

4.2 Switching Light Modes

The flashlight features three distinct light modes: High, Low, and Emergency Strobe. To cycle through these modes:

1. With the flashlight turned on, press the power button repeatedly to switch between modes.
2. The sequence is typically: **High** → **Low** → **Emergency Strobe** → **Off** (or back to High, depending on the model's specific programming).

4.3 Digital Focus Adjustment

The Digital Focus feature allows you to adjust the beam from a narrow spot to a wide flood. To adjust the focus:

- Gently twist the head of the flashlight clockwise or counter-clockwise.
- Twisting in one direction will narrow the beam for long-distance illumination (spotlight).
- Twisting in the other direction will widen the beam for broad area illumination (floodlight).



Figure 7: LED Array for Digital Focus

5. MAINTENANCE

5.1 Cleaning

To maintain optimal performance and appearance:

- Wipe the flashlight body with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- Keep the lens clean for maximum light output. Use a lens cleaning cloth if necessary.

5.2 Battery Care

To prolong battery life and prevent damage to the flashlight:

- Replace all batteries at the same time. Do not mix old and new batteries, or different types of batteries.
- Remove batteries if the flashlight will not be used for an extended period to prevent leakage and corrosion.
- Dispose of used batteries responsibly according to local regulations.

6. TROUBLESHOOTING

- **Flashlight does not turn on or operates intermittently:**
 - Ensure batteries are inserted correctly with proper polarity (+/-).
 - Check if batteries are fresh and fully charged. Replace with new batteries if necessary.
 - Ensure the tail cap is screwed on tightly to ensure proper electrical contact.
 - Inspect battery contacts inside the flashlight for dirt or corrosion. Clean gently with a cotton swab if needed.
- **Flashlight gets excessively hot during use:**
 - While some heat generation is normal, excessive heat may indicate a problem. Ensure you are using the correct type and size of batteries (AA alkaline).
 - If the flashlight becomes too hot to handle, turn it off and allow it to cool down. If the issue persists, discontinue use and contact customer support.
- **Button is unresponsive or difficult to press:**
 - Ensure no debris is lodged around the button.
 - If the button feels stuck or unresponsive, it may indicate an internal issue. Do not attempt to disassemble the flashlight beyond battery replacement.

7. SPECIFICATIONS

Brand	Energizer
Model Number	30039800129322
Light Source Type	LED
Brightness	400 Lumens (High Mode)
Beam Distance	Up to 115 meters
Power Source	Battery Powered
Battery Type	2 AA Alkaline Batteries (included)
Voltage	3 Volts

Material	Aircraft-Grade Aluminum
Water Resistance Level	IPX4 (Water Resistant)
Product Dimensions	1.89"D x 4.76"W x 9.45"H
Item Weight	5.9 ounces
Special Features	Digital Focus, Daylight Color Replication, Multiple Light Modes

8. WARRANTY AND SUPPORT

Specific warranty details are not provided within this manual. For information regarding warranty coverage, product support, or to contact customer service, please refer to the official Energizer website or the contact information provided on the product packaging.

You can visit the official Energizer store on Amazon for more information:[Energizer Store](#)