



[Manuals.plus](#) /

› [WIN STELLAR](#) /

› WIN STELLAR 24" x 80" Mirrored Sliding Barn Door Instruction Manual

WIN STELLAR B0FD9XXVDF

WIN STELLAR 24" x 80" Mirrored Sliding Barn Door Instruction Manual

Model: B0FD9XXVDF

1. IMPORTANT SAFETY INFORMATION

Please read all instructions carefully before installation and use. Failure to follow these instructions may result in injury or product damage.

- **Wall Structure:** Ensure the wall where the track will be mounted is structurally sound and capable of supporting the weight of the door and hardware. Consult a professional if unsure.
- **Drilling:** The door slab requires drilling for hardware attachment. Use appropriate tools and follow drilling guidelines to prevent damage.
- **Header Board:** A header board (not included) is recommended for proper installation, especially if wall studs do not align with track mounting points.
- **Children and Pets:** Keep children and pets away from the door during installation and ensure they do not play with the door unattended.
- **Mirror Care:** Handle the mirrored surface with care to avoid breakage. Clean with appropriate glass cleaner.

2. PACKAGE CONTENTS

The WIN STELLAR Mirrored Sliding Barn Door and its hardware are shipped in two separate packages to ensure safe transportation. Please verify all components are present and undamaged before beginning installation.



Image: Product packaging showing two separate boxes for the door slab and hardware kit, labeled '01 Nickel Plated Barn Door Hardware Pack' and '02 Door Slab x1'.



Image: Detailed packing list showing the barn door slab, sliding door track kit, floor guide, rollers, screws, and a wrench.

Included Components:

- 1x Mirrored Door Slab (24" x 80")
- 1x Hidden Style Track System
- 2x High-quality Pulley Components (Rollers)
- 1x Floor Guide
- Mounting Screws and Anchors
- Installation Wrench

3. SPECIFICATIONS

This section provides detailed dimensions and product specifications for the 24" x 80" Mirrored Sliding Barn Door.

Safe Delivery Of Packages Is Our Main Concern




Image: Diagram illustrating rough opening height, panel size, track length, and minimum ceiling clearance, accompanied by a table of various door dimensions.

Product Dimensions and Requirements (for 24" x 80" variant)

Feature	Value
Door Slab Dimensions (W x H)	24 inches x 80 inches
Door Slab Thickness	1.2 inches
Track Length	72 inches
Rough Opening Height	Less than or equal to 80 inches
Minimum Ceiling Clearance	86 inches
Material	White Primed Wood, Glass Mirror
Hardware Finish	Nickel Plated
Manufacturer	WIN STELLAR

4. SETUP AND INSTALLATION

This barn door system is designed for straightforward installation, suitable for a DIY project. All necessary hardware and instructions are included. A header board is not included and may be required.



Option Name	Each Panel Size(Width)	Each Panel Size(Height)	Track Length	Enough Opening Height	Minimum Ceiling Clearance
18 x 80	18	80	72	≤ 80	86
24 x 80	24	80	72	≤ 80	86
28 x 80	28	80	72	≤ 80	86
30 x 80	30	80	72	≤ 80	86
32 x 80	32	80	72	≤ 80	86
36 x 80	36	80	72	≤ 80	86
24 x 96	24	96	72	≤ 96	102
28 x 96	28	96	72	≤ 96	102
30 x 96	30	96	72	≤ 96	102
32 x 96	32	96	72	≤ 96	102
36 x 96	36	96	72	≤ 96	102

Image: Close-up view of the hidden track system and high-quality pulley components, highlighting the low-profile rails and smooth glide mechanism.

Installation Steps Overview:

- 1. Preparation:** Unpack all components and verify against the packing list. Gather necessary tools (e.g., drill, level, measuring tape, screwdriver).
- 2. Measure and Mark:** Determine the desired height for the track. Use a level to mark the precise location for the track on the wall. Ensure adequate clearance above the door opening.
- 3. Install Header Board (if needed):** If your wall studs do not align with the track mounting points, install a sturdy header board (minimum 1x4 or 2x4 lumber) securely into wall studs.
- 4. Mount the Track:** Attach the hidden style track to the wall or header board using the provided screws and anchors. Ensure it is perfectly level and securely fastened.
- 5. Attach Rollers to Door:** Drill pilot holes into the top edge of the door slab as per the template (if provided) or instructions. Securely attach the high-quality pulley components (rollers) to the door.

6. **Install Floor Guide:** Position the floor guide at the bottom of the door opening to prevent the door from swinging out. Mark and drill holes, then secure the guide to the floor.
7. **Hang the Door:** Carefully lift the door and hook the rollers onto the track. Ensure the door moves freely and smoothly along the track.
8. **Adjust and Test:** Make any necessary adjustments to the floor guide or track stoppers to ensure proper operation and alignment. Test the door's movement multiple times.

5. OPERATING INSTRUCTIONS

The WIN STELLAR Mirrored Sliding Barn Door is designed for smooth and quiet operation, providing a space-saving solution for various rooms.



Image: A white mirrored sliding barn door installed in a room, showcasing its aesthetic and functional design.

Widely Used



Image: Collage showing the mirrored sliding barn door being used in a living room, bathroom, bedroom, and study room, demonstrating its versatility.

Basic Operation:

- To open or close the door, gently push or pull the door slab along the track.
- The high-quality pulley components ensure a silent and smooth glide. Avoid forcing the door if it encounters resistance.
- The door can be used as a room divider, closet door, or a decorative accent.

6. MAINTENANCE

Regular maintenance will ensure the longevity and optimal performance of your barn door.

- **Cleaning the Mirror:** Use a soft, lint-free cloth and a standard glass cleaner to clean the mirrored surface. Avoid abrasive cleaners or materials that could scratch the mirror.
- **Cleaning the Door Slab:** Wipe the white primed door slab with a soft, damp cloth. Avoid harsh chemicals.
- **Track and Rollers:** Periodically inspect the track for any debris or obstructions and clean as necessary. Check the rollers for smooth operation. If they become stiff, a small amount of silicone-based lubricant

can be applied to the roller bearings.

- **Hardware Check:** Every few months, check all screws and fasteners on the track, rollers, and floor guide to ensure they are tight. Retighten if loose.

7. TROUBLESHOOTING

If you encounter any issues with your barn door, refer to the following common solutions:

- **Door Not Sliding Smoothly:**
 - Check the track for any obstructions or dirt. Clean thoroughly.
 - Inspect the rollers for damage or wear. Lubricate if needed.
 - Ensure the track is level. An unlevel track can cause resistance.
- **Door Rubbing Against Wall/Floor:**
 - Verify the floor guide is correctly installed and adjusted.
 - Check if the track is securely mounted and not bowing.
- **Excessive Noise During Operation:**
 - Lubricate the rollers.
 - Ensure all hardware is tightened correctly.

8. WARRANTY AND SUPPORT

The barn door hardware has passed 100,000 open-and-close tests, ensuring lifelong use and durability. For any questions, concerns, or assistance with installation or product issues, please contact WIN STELLAR customer service. Refer to your purchase documentation for specific contact details.