

MgaoLo B0FD9Z5TT8

MgaoLo Upgraded Mini Karaoke Machine User Manual

Model: B0FD9Z5TT8 | Brand: MgaoLo

INTRODUCTION

This manual provides essential information for the safe and effective operation of your MgaoLo Upgraded Mini Karaoke Machine. This portable Bluetooth speaker system includes two wireless microphones, an interactive emoji display, and colorful LED lights, designed for an engaging audio experience. Please read this manual thoroughly before use and retain it for future reference.

WHAT'S IN THE BOX



Image: The package contents, including the purple karaoke speaker, two wireless microphones, a USB-C charging cable, and the user manual.

- 1x Karaoke Speaker
- 2x Wireless Microphones
- 1x USB Type-C Charging Cable
- 1x User Manual

PRODUCT OVERVIEW



Image: The main karaoke speaker unit in purple, featuring a front grill with an emoji display, and two wireless microphones. The MgaoLo Mini Karaoke Machine consists of a compact speaker unit and two wireless microphones. The speaker features top-mounted controls for playback and volume, a side-mounted handle, and a front-facing LED display for interactive emojis and light shows. The microphones are designed for comfortable handling and include individual controls for power, volume, and voice effects.



Image: An exploded view of the speaker's internal audio components, illustrating its advanced sound technology for clear and immersive audio.

SETUP

1. Power On/Off

- **Speaker:** Long press the power button on the top of the speaker to turn it on or off. The LED display will activate.
- **Microphones:** Long press the power button on each microphone to turn it on or off. A blue indicator light will illuminate when powered on.

2. Bluetooth Pairing

EASY TO CONNECT & PLAY

Match Your Mobile Device Quickly



Image: The karaoke speaker displaying its various connectivity options including Bluetooth, TF Card, and AUX input, shown with multiple devices.

1. Ensure the karaoke speaker is powered on and in Bluetooth pairing mode (indicated by a blinking light or specific emoji).
2. On your smartphone, tablet, or other Bluetooth-enabled device, go to the Bluetooth settings.
3. Search for available devices and select "MgaoLo Karaoke" (or similar name, refer to your device's Bluetooth list).
4. Once connected, the speaker will emit an audible confirmation, and the indicator light will become solid.
5. The wireless microphones will automatically pair with the speaker when both are powered on.

3. Other Connection Options

- **TF Card:** Insert a TF (Micro SD) card (not included) into the designated slot on the speaker. The speaker will automatically switch to TF card playback mode.
- **AUX Input:** Connect an external audio device using a 3.5mm AUX cable (not included) to the AUX port on the speaker. The speaker will switch to AUX mode.

OPERATING INSTRUCTIONS

1. Music Playback

- Once connected via Bluetooth, TF card, or AUX, play music from your connected device.
- Use the play/pause button on the speaker to control music playback.
- Use the volume buttons (+/-) on the speaker to adjust the music volume.
- Use the skip track buttons (forward/backward) on the speaker to navigate through songs.

2. Microphone Usage

- Ensure both microphones are powered on and paired with the speaker.
- Speak or sing into the microphone. The sound will be amplified through the speaker.
- Use the volume buttons (+/-) on the microphone to adjust the microphone's volume independently.
- **Echo Effect:** Short press the echo button on the microphone to cycle through different echo levels.
- **Voice Changer:** Short press the voice changer button on the microphone to cycle through 5 different voice effects (Original, Baby, Male, Female, Monster).



Image: A visual representation of the five distinct voice effects that can be applied using the wireless microphones.

3. LED Lights & Emoji Display

- The speaker features multi-color LED lights that sync with music rhythms.
- Short press the light button on the speaker to cycle through different light modes and emoji displays.
- Long press the light button to turn the lights on or off.

Your browser does not support the video tag.

Video: A short demonstration of the Mini Karaoke Machine for Kids K60, showcasing its features and operation.

Your browser does not support the video tag.

Video: A detailed overview of the Mini Karaoke Machine for Kids, highlighting its design and functionality.

CHARGING



Image: Visual guide to the battery and charging features, indicating play time, charging duration, and battery capacity.

- Connect the provided USB Type-C charging cable to the DC 5V port on the speaker and to a compatible USB power adapter (not included).
- Connect the charging cable to the charging port at the bottom of each microphone.
- The indicator light on the speaker/microphones will show charging status (e.g., red for charging, blue/off for fully charged).
- A full charge typically takes 2-3 hours. The speaker provides 6-10+ hours of play time on a full charge.

MAINTENANCE

- Clean the device with a soft, dry cloth. Do not use abrasive cleaners or solvents.

- Keep the device away from water, moisture, and direct heat sources.
- Store the device in a cool, dry place when not in use.

TROUBLESHOOTING

Issue	Solution
No sound from speaker	Ensure speaker is powered on, volume is up, and correctly paired/connected. Check source device volume.
Microphone not connecting	Ensure microphones are charged and powered on. Restart both microphones and speaker.
LED lights not working	Short press the light button to cycle modes. Long press to turn on/off. Ensure speaker is powered on.
Poor sound quality	Ensure devices are within Bluetooth range. Check for interference. Adjust volume levels on both speaker and microphones.

SPECIFICATIONS

Feature	Detail
Item Weight	1.06 pounds
Product Dimensions	4.33 x 3.94 x 2.36 inches
Batteries	1 Nonstandard Battery (included)
Battery Type	Lithium Ion
Power Source	Battery Powered
Color	Purple
Compatible Devices	Smartphone, Tablet, MP3 Player, TV, Speaker
Connector Type	USB Type C
Speaker Count	1
Special Feature	Echo Effect, Light Up Speaker, Lightweight, Portable, Rechargeable
Recommended Uses	Home

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the contact details provided on the product packaging or visit the official MgaoLo website. Keep your purchase receipt for warranty claims.

Top 10 Best Fitness Trackers
for Yoga

The fitness industry is booming, and with it, the demand for fitness trackers. These devices offer a variety of features, from step counting to heart rate monitoring. However, not all fitness trackers are created equal. Some are better suited for certain activities than others. This article will help you choose the best fitness tracker for your needs.

When it comes to fitness trackers, there are a few key features to look for:

1. Accuracy: The most important feature of a fitness tracker is its accuracy. You want to make sure that the data it provides is reliable.

2. Battery Life: A fitness tracker should last for at least a week on a single charge. If you have to charge it every day, it's not very useful.

3. Design: A fitness tracker should be comfortable to wear and look good. If you don't like the way it looks, you won't wear it.

4. Price: Fitness trackers range in price from around \$20 to over \$100. You should choose one that fits your budget.

[Best Fitness Trackers for Yoga: Top 10 Picks for Your Practice](#)

Discover the top 10 fitness trackers ideal for yoga practitioners. This guide compares features, battery life, design, and more to help you find the perfect device for your wellness journey.