Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

GOJOOASIS 7 Pieces Modular Outdoor Sectional with Fire Pit Table

GOJOOASIS 7-Piece Modular Outdoor Sectional with Fire Pit Table User Manual

Model: 7 Pieces Modular Outdoor Sectional with Fire Pit Table
Brand: GOJOOASIS

1. Important Safety Information

Please read and understand all instructions and safety warnings before assembling, operating, or maintaining this product. Failure to follow these instructions may result in property damage, personal injury, or death. Keep this manual for future reference.

General Safety Precautions:

- Ensure all components are securely fastened before use.
- Do not exceed the weight capacity of 400 pounds per sectional piece.
- Keep children and pets away from the furniture during assembly and operation of the fire pit.
- Place the furniture on a flat, stable surface.
- Do not use this product for purposes other than its intended use.

Fire Pit Safety Precautions:

- For outdoor use only. Do not use indoors or in an enclosed area.
- Maintain a safe distance from combustible materials.
- Ensure proper ventilation.
- Use only a 20 LB propane tank (not included).
- Never leave the fire pit unattended when in operation.
- Allow the fire pit to cool completely before moving or covering.
- Do not store a spare propane cylinder under or near the fire pit.
- Keep the area around the fire pit clear and free from flammable liquids or vapors.

2. Package Contents

Your GOJOOASIS 7-Piece Modular Outdoor Sectional with Fire Pit Table is shipped in multiple packages. Verify

that all components listed below are present before beginning assembly.

- 2 x Corner Sofas
- 4 x Armless Sofas
- 1 x Fire Pit Table
- 6 x Seat Cushions
- 8 x Back Cushions
- 2 x Decorative Pillows
- 1 x Glass Wind Guard (for Fire Pit)
- 1 x Cover Panel (for Fire Pit)
- 1 x Fire Pit Table Cover
- Blue Glass Stones (for Fire Pit)
- Assembly Hardware and Tools



Image 2.1: Components of the sectional sofa, highlighting the PE rattan, structural base, adjustable feet, and cushion straps.

3. Setup and Assembly

Assembly is required for this furniture set. It is recommended to have two people for assembly. Ensure all parts are present and undamaged before starting.

3.1. Sectional Sofa Assembly:

1. Unpack all sofa components and hardware.
2. Attach the backrests and armrests (if applicable) to the seat frames using the provided bolts and wrench. Do not fully tighten bolts until all pieces are aligned.
3. Connect individual sofa pieces using the included connectors to form your desired configuration.
4. Once all pieces are connected and aligned, fully tighten all bolts.
5. Place the seat and back cushions onto the sofas. The seat cushions feature Velcro fasteners to prevent movement.
6. Adjust the sofa feet for stability on uneven surfaces.



Image 3.1: Examples of free combination and arrangement options for the modular sectional sofa.

3.2. Fire Pit Table Assembly:

1. Unpack the fire pit table components.

2. Assemble the table frame and attach the tabletop.
3. Install the burner assembly into the designated opening in the tabletop.
4. Place the blue glass stones evenly over the burner.
5. Install the glass wind guard around the burner area.
6. Connect the gas hose from the burner to the propane tank regulator. Ensure all connections are tight.
7. Slide a 20 LB propane tank (not included) into the hidden storage compartment. The compartment features a drawer pulley for easy access.
8. Close the storage compartment door.



Image 3.2: Hidden tank storage compartment with drawer pulley for easy propane tank access.

4. Operating Instructions (Fire Pit)

Follow these steps to safely operate your fire pit table.

4.1. Before First Use:

- Perform a leak test on all gas connections. Apply a soapy water solution to connections; bubbles indicate a

leak. If a leak is detected, turn off the gas supply immediately and tighten connections. Do not operate if a leak persists.

- Ensure the fire pit is on a level, non-combustible surface.

4.2. Ignition:

1. Open the valve on the propane tank.
2. Press and hold the ignition button (labeled '01' in image).
3. While holding the ignition button, slowly turn the control knob (labeled '02' in image) to the 'LOW' position.
4. Once the flame ignites, continue to hold the ignition button for 10-15 seconds to allow the thermocouple to heat up.
5. Release the ignition button. If the flame extinguishes, repeat steps 2-4.



Image 4.1: Simple ignition and flame adjustment controls for the fire pit.

4.3. Flame Adjustment:

- To adjust the flame height, rotate the control knob between 'LOW' and 'HIGH' settings.

4.4. Shutting Down:

1. Turn the control knob to the 'OFF' position.
2. Close the valve on the propane tank.
3. Allow the fire pit to cool completely before covering or storing.




Image 4.2: The fire pit in operation, demonstrating its heat output and design features.

5. Maintenance and Care

Proper maintenance will extend the life and appearance of your GOJOOASIS patio furniture set.

5.1. Wicker and Frame Care:

- The PE wicker is waterproof and UV-proof. Clean with a mild soap and water solution and a soft cloth. Rinse thoroughly and allow to air dry.
- The steel frame is durable. Inspect periodically for any signs of rust or damage. Clean with a damp cloth and dry immediately.

- Avoid using harsh chemicals or abrasive cleaners, as these can damage the materials.

5.2. Cushion Care:

- The cushion covers are made of fade-resistant fabric and are easy to clean. They feature invisible zippers for removal.
- Hand wash or machine wash covers on a gentle cycle with cold water and mild detergent. Air dry only; do not tumble dry.
- The cushions are filled with thick cotton. Store cushions indoors or cover them during inclement weather or prolonged periods of non-use to protect them from moisture and UV exposure.
- Ensure cushions are completely dry before storing to prevent mildew.



Image 5.1: Details of the 4-inch thick cushions, highlighting their features for comfort and maintenance.

5.3. Fire Pit Care:

- Regularly inspect the burner and gas connections for debris or damage.
- Clean the glass wind guard with glass cleaner and a soft cloth.
- When not in use, cover the fire pit table with the provided cover to protect it from the elements.

- Ensure the fire pit is completely cool before covering.

6. Troubleshooting

If you encounter issues with your GOJOOASIS patio furniture set, refer to the following common solutions.

6.1. Fire Pit Not Igniting:

- **Check Propane Tank:** Ensure the propane tank valve is fully open and the tank contains sufficient fuel.
- **Gas Connection:** Verify that the gas hose is securely connected to both the burner and the propane tank regulator. Perform a leak test if necessary.
- **Ignition Button:** Ensure the ignition button is pressed and held for the recommended duration (10-15 seconds) after turning the control knob.
- **Battery:** The ignition system may require an AAA battery (not included). Check if the battery needs replacement.
- **Air in Line:** If it's the first use or after a tank change, there might be air in the gas line. Repeat the ignition process several times to purge the air.

6.2. Low Flame or Irregular Flame:

- **Propane Level:** The propane tank may be low on fuel.
- **Regulator Issue:** The propane tank regulator may have activated its safety feature (excess flow valve) due to a rapid opening of the tank valve. Close the tank valve, wait 30 seconds, then slowly reopen it.
- **Burner Obstruction:** Check the burner ports for any debris or blockages.

6.3. Cushions Sliding:

- Ensure the Velcro fasteners on the underside of the seat cushions are properly engaged with the corresponding fasteners on the sofa frame.

7. Specifications

Feature	Specification
Brand	GOJOOASIS
Model	7 Pieces Modular Outdoor Sectional with Fire Pit Table
Material	Alloy Steel Frame, PE Wicker
Cushion Material	Thick Cotton Fill, Fade-Resistant Fabric Covers
Color (as reviewed)	Peacock Blue - Fire Pit Table
Corner Sofa Dimensions	29.1"L x 29.1"W x 26.6"H
Armless Sofa Dimensions	23.6"L x 29.1"W x 26.6"H
Fire Pit Table Dimensions	42"L x 24"W x 25"H
Item Weight (Total)	Approximately 190 Pounds

Feature	Specification
Weight Capacity (per sectional)	400 Pounds
Fire Pit Heat Output	50,000 BTU
Fire Pit Ignition Type	Push-button
Fire Pit Battery Type	AAA (Not Included)
Recommended Propane Tank	20 LBS (Not Included)
Assembly Required	Yes

8. Warranty and Support

For warranty information or customer support regarding your GOJOOASIS patio furniture set, please refer to the product packaging or contact GOJOOASIS customer service directly. Contact details can typically be found on the manufacturer's website or through your point of purchase.

© 2026 GOJOOASIS. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FDB1LRNQ

More documents and user manuals: **https://manuals.plus/**