

## SEYVUM MJ8602

# SEYVUM 20V MJ8602 Trimmer Spool Line Instruction Manual

Model: MJ8602 Trimmer Spool Line

## 1. INTRODUCTION

---

This manual provides essential information for the safe and effective use of your SEYVUM 20V MJ8602 Trimmer Spool Line. Please read these instructions carefully before installation and operation to ensure proper function and to prevent damage or injury. Keep this manual for future reference.

## 2. PRODUCT OVERVIEW

---

The SEYVUM Trimmer Spool Line is a replacement accessory designed for specific SEYVUM string trimmers. It provides a fresh supply of cutting line for maintaining your lawn and garden edges.

### Package Contents:

- 3 x 16.5 ft Replacement Trimmer Line Spools (pre-wound)
- 1 x Replacement Spool Cap

The spools are constructed from high-quality ABS, and the line is made from durable polyamide nylon thread, designed for effective cutting performance.



This image displays the three pre-wound trimmer line spools and the included replacement cap, ready for installation.

### 3. COMPATIBILITY

---

This replacement spool line is **only compatible with the SEYVUM 20V MJ8602 String Trimmer**. It is specifically designed for machines sold before or including May 2025. Using this spool with other trimmer models or brands may result in improper function, damage to the trimmer, or personal injury.

### 4. SAFETY INFORMATION

---

Always prioritize safety when handling power tools and their accessories. Failure to follow these safety instructions may result in serious injury.

- **Disconnect Power:** Before installing or replacing the spool, always ensure the string trimmer is turned OFF and the battery pack is removed to prevent accidental starting.
- **Wear Protective Gear:** Always wear safety glasses or goggles, long pants, and sturdy footwear when operating a string trimmer.
- **Inspect Components:** Before each use, inspect the trimmer head, spool, and cap for any signs of damage or wear. Replace damaged parts immediately.
- **Keep Clear:** Ensure bystanders, children, and pets are at a safe distance (at least 50 feet/15 meters) from the operating area.

- **Use Correct Parts:** Only use genuine SEYVUM replacement parts specified for your model.

## 5. INSTALLATION GUIDE

---

Replacing the trimmer spool is a straightforward process. The replacement spools come pre-wound for convenience.

### Steps for Spool Replacement:

1. **Prepare the Trimmer:** Ensure the string trimmer is turned OFF and the battery pack is removed. Place the trimmer on a stable, flat surface.
2. **Remove Old Spool Cap:** Locate the spool cap on the trimmer head. Press the tabs or buttons on the sides of the cap (if present) and lift the cap off. Some models may require twisting the cap counter-clockwise.
3. **Remove Old Spool:** Carefully lift out the empty or broken spool from the trimmer head. Note the orientation of the spool for correct installation of the new one.
4. **Install New Spool:** Take a new pre-wound SEYVUM replacement spool. Align the notches or slots on the new spool with the corresponding features inside the trimmer head. Ensure the line is fed through the eyelet on the trimmer head.
5. **Replace Spool Cap:** Place the new replacement spool cap (or your existing cap if it's in good condition) back onto the trimmer head. Press down firmly until it clicks into place, or twist clockwise until secure. Ensure the cap is fully seated and locked.
6. **Check Line Extension:** Gently pull on the trimmer line to ensure it extends freely. If the line does not extend, the spool may not be seated correctly.

## 6. OPERATING GUIDELINES

---

Once the new spool is installed, reinsert the battery pack into your SEYVUM 20V MJ8602 String Trimmer. Follow the operating instructions provided with your string trimmer for safe and effective use. The trimmer line will automatically feed or can be advanced manually as per your trimmer's design.

## 7. STORAGE AND MAINTENANCE

---

- **Storage:** Store unused spools in a cool, dry place away from direct sunlight and extreme temperatures. This helps maintain the integrity and flexibility of the nylon line.
- **Cleaning:** Keep the trimmer head and spool cap free from debris, grass clippings, and dirt. A clean trimmer head ensures proper line feeding.
- **Inspection:** Periodically inspect the spool cap for cracks or wear. A damaged cap can affect line feeding and trimmer performance. Replace if necessary.

## 8. TROUBLESHOOTING

---

### Line Not Feeding:

- Ensure the spool is correctly seated in the trimmer head.
- Check if the line is tangled or jammed within the spool.
- Inspect the spool cap for damage that might obstruct line movement.
- Verify that the line is properly threaded through the eyelet.

### Line Breaking Frequently:

- Ensure you are using the correct line diameter (0.065-inch) for your trimmer.

- Avoid hitting hard surfaces like concrete, rocks, or fences, which can cause premature line breakage.
- Check for excessive wear or damage to the trimmer head's eyelets, which can fray the line.

## 9. TECHNICAL SPECIFICATIONS

---

<b>Brand</b>	SEYVUM
<b>Model Number</b>	70-US-SL8602-2
<b>Line Diameter</b>	0.065 inches
<b>Line Length per Spool</b>	16.5 feet
<b>Spool Material</b>	High-quality ABS
<b>Line Material</b>	Polyamide Nylon Thread
<b>Package Quantity</b>	3 Spools, 1 Cap
<b>Compatibility</b>	SEYVUM 20V MJ8602 String Trimmer (machines sold before May 2025 inclusive)

## 10. CUSTOMER SUPPORT

---

If you have any questions, require assistance with installation, or encounter issues not covered in this manual, please contact SEYVUM customer support. Refer to your original trimmer manual or the SEYVUM website for contact information.