

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Candy](#) /

› [Candy CNBQL3518EV Built-in Combined Refrigerator Instruction Manual](#)

Candy CNBQL3518EV

Candy CNBQL3518EV Built-in Combined Refrigerator Instruction Manual

Brand: **Candy** | Model: **CNBQL3518EV**

1. INTRODUCTION

Thank you for choosing the Candy CNBQL3518EV Built-in Combined Refrigerator. This appliance is designed to seamlessly integrate into your kitchen while offering efficient food storage. With a total net capacity of 268 liters and an Energy Efficiency Class E, it provides a reliable solution for your refrigeration needs. This manual provides essential information for the safe and efficient use of your new appliance.

2. SAFETY INFORMATION

Please read this manual carefully before installing and using the appliance. Keep it for future reference. Improper installation, use, or maintenance can cause injury or damage. Always follow basic safety precautions, including:

- Ensure the appliance is properly grounded.
- Do not damage the refrigerant circuit.
- Keep ventilation openings clear of obstruction.
- Do not use mechanical devices or other means to accelerate the defrosting process, other than those recommended by the manufacturer.
- Do not use electrical appliances inside the food storage compartments, unless they are of the type recommended by the manufacturer.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

3. INSTALLATION

The Candy CNBQL3518EV is a built-in appliance designed for seamless integration into your kitchen cabinetry. Proper installation is crucial for optimal performance and safety. This refrigerator features reversible doors, allowing you to adjust the door opening direction to suit your kitchen layout.

Unpacking and Initial Placement

Carefully unpack the refrigerator and remove all packaging materials. Ensure the appliance is placed on a stable, level surface. Allow the refrigerator to stand upright for at least 4 hours before plugging it in to allow the refrigerant to settle.






Figure 1: Front view of the Candy CNBQL3518EV built-in combined refrigerator, ready for installation.

Built-in Installation Guide

For detailed steps on built-in installation, including securing the appliance within the cabinet and attaching the cabinet doors, please refer to the following video. While this video demonstrates a similar Electrolux model, the general principles and steps for built-in refrigerator installation are applicable.

Your browser does not support the video tag.

Video 1: Installation guide for a built-in refrigerator. This video provides a general overview of the installation process for integrated fridge/freezer units.

Door Reversal

The doors of your Candy CNBQL3518EV refrigerator are reversible. If you need to change the opening direction, consult the detailed instructions provided in the full product manual or contact a qualified technician. This process typically involves carefully detaching the hinges and reattaching them on the opposite side.

4. OPERATING INSTRUCTIONS

Your Candy CNBQL3518EV refrigerator is designed for user-friendly operation. Here are key functions to help you get started:

Temperature Control

The refrigerator does not feature a built-in display. Temperature settings are typically controlled via an internal dial or buttons located at the top of the refrigerator compartment. Refer to the markings for colder or warmer settings. The Super Cool function allows for rapid cooling of newly added items, while the ECO mode helps optimize energy consumption.



Figure 2: Internal control panel for temperature adjustment and special functions.

Interior Organization

The refrigerator compartment offers 194 liters of net capacity, featuring 4 adjustable glass shelves and 5 door balconies for flexible storage. A dedicated vegetable drawer helps keep produce fresh. The internal LED light ensures clear visibility of contents.





Figure 3: Interior view of the refrigerator, showcasing adjustable shelves and door storage.



Figure 4: Close-up of the vegetable crisper drawer, designed to maintain optimal humidity for fresh produce.

Freezer Compartment

The top-mounted freezer compartment has a net capacity of 74 liters and a 4-star rating, indicating its suitability for long-term storage of frozen foods. It has a freezing capacity of 3 kg/24h and can maintain temperature for up to 13 hours during a power failure.



Figure 5: The freezer compartment, featuring multiple drawers for organized storage of frozen items.

5. MAINTENANCE

Regular maintenance ensures the longevity and efficiency of your refrigerator.

Cleaning

Clean the interior and exterior of your refrigerator regularly with a mild detergent and warm water. Avoid abrasive cleaners or solvents. Ensure the appliance is unplugged before cleaning.

Defrosting

The refrigerator compartment features automatic defrosting. The freezer compartment utilizes Low Frost technology, which significantly reduces ice build-up compared to traditional freezers, making manual defrosting less frequent and easier. For more information on Low Frost technology and its benefits, watch the video below:

Your browser does not support the video tag.

Video 2: Explanation of Low Frost technology, which minimizes ice formation and simplifies defrosting.

6. TROUBLESHOOTING

If you experience issues with your refrigerator, consult the following common troubleshooting tips before contacting service:

- **Appliance not cooling:** Check if the power cord is securely plugged in. Ensure the temperature settings are correct. Verify that the door is closed properly.
- **Unusual noises:** Slight noises from the refrigerant circulating are normal. Ensure the appliance is level and not touching any walls or cabinets.
- **Water leakage:** Check if the drain hole in the refrigerator compartment is clear. Ensure the water collection tray at the back is correctly positioned.

- **Excessive ice build-up (freezer):** While Low Frost reduces ice, ensure the freezer door is sealing properly and not left open for extended periods.

If the problem persists, unplug the appliance and contact customer support.

7. SPECIFICATIONS

Feature	Value
Brand	Candy
Model Number	CNBQL3518EV
Appliance Placement	Built-in
Product Color	White
Built-in Display	No
Door Hinge	Right
Reversible Doors	Yes
Shelf Material	Glass
Adjustable Shelves	Yes
Number of Compressors	1
Recessed Handles	Yes
Number of Doors	2
Total Net Capacity	268 L
Climate Class	SN-ST
Noise Emission Class	B
Noise Level	35 dB
Ice Production	No
Minimum Operating Temperature	10 °C
Maximum Operating Temperature	38 °C
Water Dispenser	No
Water Supply Type	Not supported
Holiday Function	No
ECO Mode	Yes
Refrigerator Net Capacity	194 L
No Frost (Refrigerator)	No
Multi-Airflow System (Refrigerator)	No

Feature	Value
Number of Refrigerator Shelves	4
Number of Vegetable Drawers	1
Super Cool Function	Yes
Cooling System	Ventilated
Internal Light	Yes
Lamp Type	LED
Automatic Defrost (Refrigerator)	Yes
Refrigerator Door Balconies	5
Antibacterial Compartment	No
Freezer Position	Top-mounted
Freezer Net Capacity	74 L
Freezing Capacity	3 kg/24h
Power Failure Autonomy	13 h
Star Rating	4*
No Frost (Freezer)	No
Energy Efficiency Class	E
Product Dimensions (W x D x H)	55.5 x 54 x 177.3 cm
Product Weight	56 kg

8. WARRANTY AND SUPPORT

Your Candy CNBQL3518EV refrigerator comes with a standard manufacturer's warranty. Please refer to the warranty card included with your purchase for specific terms and conditions. For technical assistance, spare parts, or any other inquiries, please contact Candy customer support or visit the official Candy website.

You can also visit the [Candy Store on Amazon](#) for more information and products.