

TCL 32S4K

TCL 32S4K Series Full HD Smart QLED Google TV User Manual

Model: 32S4K

1. INTRODUCTION

This manual provides essential information for the safe and efficient operation of your TCL 32S4K Series Full HD Smart QLED Google TV. Please read this manual thoroughly before using the television and retain it for future reference. Your TCL 32S4K TV features a Full HD QLED display, Google TV operating system, HDR10 support, and Dolby Audio for an immersive viewing experience.



Figure 1.1: Front view of the TCL 32S4K Series Full HD Smart QLED Google TV.

2. SAFETY INFORMATION

To ensure safe operation and prevent damage, observe the following precautions:

- Do not expose the TV to rain or moisture to prevent fire or electric shock.
- Do not block ventilation openings. Ensure adequate space around the TV for proper airflow.
- Protect the power cord from being walked on or pinched.
- Only use attachments/accessories specified by the manufacturer.
- Unplug the TV during lightning storms or when unused for long periods.
- Refer all servicing to qualified service personnel.

3. PACKAGE CONTENTS

Verify that all items listed below are included in your package:

- 1 x TCL LED TV (Model 32S4K)
- 1 x Audio Cable
- 1 x Stand (for table mounting)
- 1 x User Manual (this document)
- 1 x Remote Control
- 1 x Warranty Card
- 2 x AAA Batteries (for remote control)
- 1 x Power Cord

4. SETUP

4.1 Physical Installation

Your TV can be installed on a table using the included stand or mounted on a wall (wall mount kit sold separately).

4.1.1 Installing the TV Stand

1. Carefully place the TV face-down on a soft, flat surface to prevent screen damage.
2. Align the stand bases with the corresponding slots on the bottom of the TV.
3. Secure the stand bases using the provided screws. Ensure they are firmly attached.

4.1.2 Wall Mounting (Optional)

If you choose to wall mount your TV, ensure you use a VESA-compatible wall mount kit appropriate for the TV's size and weight. Follow the instructions provided with your wall mount kit. It is recommended to have professional installation for wall mounting.




Figure 4.1: Rear view of the TCL 32S4K TV, showing mounting points and port area.

4.2 Connecting Peripherals

Connect your external devices to the TV using the appropriate ports located on the back and side of the television.

- **HDMI Devices:** Connect Blu-ray players, gaming consoles, or set-top boxes to the HDMI ports.
- **USB Devices:** Insert USB drives for media playback or software updates into the USB port.
- **Antenna/Cable:** Connect your antenna or cable TV feed to the Antenna Input.
- **LAN:** For a wired internet connection, connect an Ethernet cable to the LAN port.

4.3 Initial Power On and Setup Wizard

After connecting the power cord, press the power button on the remote control or the TV. The TV will guide you through the initial setup process:

1. **Language Selection:** Choose your preferred language.

2. **Region/Country:** Select your region.
3. **Network Connection:** Connect to your Wi-Fi network or use a wired connection (see 4.4).
4. **Google Account Sign-in:** Sign in with your Google account to access Google TV features, apps, and personalized recommendations.
5. **Channel Scan:** Scan for available TV channels (if using an antenna/cable).
6. **Terms and Conditions:** Accept the terms and conditions to proceed.

4.4 Network Connection

To access smart features and online content, connect your TV to the internet.

- **Wi-Fi:** During the initial setup or via the settings menu, select your Wi-Fi network from the list and enter the password.
- **Wired (Ethernet):** Connect an Ethernet cable from your router to the LAN port on the TV. The TV will automatically detect the wired connection.

5. OPERATING YOUR TV

5.1 Remote Control Functions

The included remote control allows you to navigate the TV's interface and control various functions. Insert the two AAA batteries into the remote control, ensuring correct polarity.

- **Power Button:** Turns the TV on or off.
- **Navigation Buttons (Up/Down/Left/Right):** Move through menus and options.
- **OK Button:** Confirms selections.
- **Back Button:** Returns to the previous screen.
- **Home Button:** Accesses the Google TV home screen.
- **Volume Up/Down:** Adjusts the volume level.
- **Channel Up/Down:** Changes TV channels.
- **Google Assistant Button:** Activates voice control.
- **App Shortcut Buttons:** Direct access to popular streaming services (e.g., Netflix, Prime Video).

5.2 Google TV Interface

Google TV organizes your favorite content from various streaming services into one personalized home screen. You can browse movies, shows, and live TV, get recommendations, and manage your watchlist.

- **Home Screen:** Displays personalized recommendations, installed apps, and quick access to content categories.
- **Apps:** Download and manage applications from the Google Play Store.
- **Library:** Access your purchased or rented content.
- **Live TV:** If you have a TV tuner or compatible streaming service, access live broadcasts.

5.3 Smart Features

- **Google Assistant:** Press the Google Assistant button on your remote and speak into the microphone to search for content, control smart home devices, get answers, and more.
- **Screen Mirroring:** Cast content from your smartphone or tablet to the TV using built-in Chromecast technology. Ensure your device and TV are on the same Wi-Fi network.

- **Web Browser:** Access the internet directly from your TV using the integrated web browser.

6. CONNECTIVITY

The TCL 32S4K TV offers a range of connectivity options for various devices.



Figure 6.1: Side view of the TCL 32S4K TV, highlighting connectivity ports.

Port Type	Description	Quantity
HDMI	High-Definition Multimedia Interface for digital audio/video input.	2
USB	Universal Serial Bus for connecting storage devices or peripherals.	1
LAN (Ethernet)	For wired network connection.	1

Port Type	Description	Quantity
Antenna Input	For connecting an external antenna or cable TV.	1
Satellite Input	For connecting a satellite dish.	1
Digital Audio Out (Optical)	For connecting to external audio systems with optical input.	1
AV IN Adapter	For connecting older devices using composite video and stereo audio.	1
Headphone Out	For connecting headphones.	1

7. MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your TV.

- **Cleaning the Screen:** Gently wipe the screen with a soft, lint-free cloth. For stubborn marks, use a screen-specific cleaning solution applied to the cloth, not directly to the screen.
- **Cleaning the Cabinet:** Use a soft, dry cloth to wipe the TV cabinet. Do not use abrasive cleaners or solvents.
- **Ventilation:** Ensure the ventilation openings on the back of the TV are not blocked to prevent overheating.
- **Power Cord:** Regularly check the power cord for any damage. If damaged, replace it immediately with an authorized part.

8. TROUBLESHOOTING

Before contacting service, try the following solutions for common issues:

Problem	Possible Solution
No power	Check if the power cord is securely plugged into the TV and the power outlet. Ensure the power outlet is active. Try a different outlet.
No picture, but sound is present	Ensure the correct input source is selected. Check cable connections to external devices.
No sound, but picture is present	Check the volume level and ensure the TV is not muted. Verify audio cable connections for external devices.
Remote control not working	Replace the batteries in the remote control. Ensure there are no obstructions between the remote and the TV's IR sensor.
Cannot connect to Wi-Fi	Ensure your Wi-Fi router is on and functioning. Re-enter the Wi-Fi password carefully. Try restarting your router and the TV.
Picture is distorted or unclear	Check antenna or cable connections. Adjust picture settings (brightness, contrast, sharpness). If using an external device, check its output resolution.

9. SPECIFICATIONS



Figure 9.1: Dimensions of the TCL 32S4K Series Full HD Smart QLED Google TV.

Feature	Specification
Model	32S4K
Screen Size	32 Inches (80 cm)
Display Technology	QLED
Resolution	Full HD (1920 x 1080 Pixels)
Refresh Rate	60 Hz
Operating System	Google TV

Feature	Specification
Processor	64-bit Quad Core Processor
RAM	1 GB
Internal Storage (ROM)	8 GB
Audio Output	24 Watts
Audio Technology	Dolby Audio
Connectivity	Wi-Fi 4, Ethernet, Bluetooth, 2x HDMI, 1x USB
Special Features	HDR 10, 100% Color Volume Plus, Micro Dimming, Google Assistant, Screen Mirroring, Multiple Eye Care
Viewing Angle	178 Degrees
Power Consumption (On-mode)	65.0 Watts
Annual Energy Consumption	62 kWh
Product Dimensions (LxWxH)	71.5 x 18 x 46.5 cm (with stand)
Item Weight	3.19 kg

10. WARRANTY AND SUPPORT

Your TCL 32S4K Series Full HD Smart QLED Google TV comes with a**1-year warranty** provided by the manufacturer from the date of purchase. Please retain your purchase receipt as proof of purchase for warranty claims.

For technical support, service requests, or further inquiries, please refer to the contact information provided on the warranty card or visit the official TCL support website for your region.

Manufacturer: TCL India

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question