

LC V5

LC V5 2-in-1 Baby Stroller Instruction Manual

Model: V5

	Safety Information	Package Contents	Setup	Operating
Instructions	Maintenance	Troubleshooting	Specifications	Warranty & Support

INTRODUCTION

Thank you for choosing the LC V5 2-in-1 Baby Stroller. This manual provides essential information for the safe assembly, operation, and maintenance of your stroller. Please read it thoroughly before use and keep it for future reference. The LC V5 is a versatile 2-in-1 convertible stroller designed to adapt from a newborn bassinet to a toddler seat, suitable for children up to 4 years old. It features an adjustable backrest with three positions and a fully adjustable sun canopy for optimal comfort and protection. The portable bassinet can be positioned parent-facing or forward-facing, allowing for better visibility and interaction. Its elegant design includes luxurious black fabric with stylish rose gold frame accents and a leather-covered handle. A convenient folding mechanism allows for compact storage and transport, and it includes a matching diaper bag for essentials.

IMPORTANT SAFETY INFORMATION

- Always use the 5-point safety harness to secure your child.
- Never leave your child unattended in the stroller.
- Ensure all locking mechanisms are engaged before placing a child in the stroller.
- Do not overload the storage basket; maximum capacity is 4.5 kg.
- The stroller is designed for children up to 22 kg.
- Avoid placing hot liquids or heavy objects on the handle.
- Keep fingers clear of moving parts during folding and unfolding.
- Regularly check for loose parts, damaged components, or worn fabric. Discontinue use if any damage is found.
- This stroller is not suitable for running or skating.

PACKAGE CONTENTS

Please ensure all components are present before assembly.

- Stroller Frame (Aluminum)
- Convertible Bassinet/Toddler Seat (Premium Padded Polyester)
- Sun Canopy (Polyester)
- 4 Wheels (Rubber)
- Diaper Bag
- Instruction Manual



Image: Main components of the LC V5 Stroller. Shows the black frame with rose gold accents, the convertible seat, and wheels.

SETUP AND ASSEMBLY

1. Unfolding the Frame:

Place the folded stroller frame on a flat surface. Release the folding latch (if present, usually on the side of the frame). Lift the handle upwards until the frame clicks into its fully open position. Ensure all locking mechanisms are securely engaged.

2. Attaching the Wheels:

Insert the rear wheels into the axle until they click into place. For the front wheels, push them into the designated slots on the front legs until they lock. Pull on each wheel to ensure it is securely attached.

3. Attaching the Seat Unit (Bassinet/Toddler Seat):

Align the connectors on the bottom of the seat unit with the corresponding slots on the stroller frame. Push down firmly until you hear a click, indicating it is securely attached. Test the attachment by gently lifting the seat unit.



Image: Illustrates the process of attaching the convertible seat unit to the stroller frame. Shows the connection points.

4. Attaching the Sun Canopy:

Attach the sun canopy to the designated points on the seat unit. Ensure it is firmly secured to provide adequate shade.

OPERATING INSTRUCTIONS

Converting the Seat Unit (Bassinet to Toddler Seat)

The V5 stroller features a convertible seat unit. To change between bassinet and toddler seat modes, locate the adjustment straps or levers usually found on the underside or sides of the seat. Follow the specific instructions provided in the detailed manual for your model to safely convert the unit. Ensure all fasteners are secured after conversion.

Adjusting the Backrest

The backrest has three recline positions. To adjust, locate the lever or button on the back of the seat unit. Press or lift the mechanism and move the backrest to the desired position. Release the mechanism to lock it in place. Always ensure the backrest is securely locked before use.

Reversing the Seat Direction

The seat unit can be parent-facing or forward-facing. To reverse the seat, first ensure the child is removed from the stroller. Locate the release buttons or levers on both sides of the seat unit where it connects to the frame. Press these buttons simultaneously and lift the seat unit off the frame. Rotate the seat unit 180 degrees and re-attach it to the frame, ensuring it clicks securely into place on both sides.

Using the Safety Harness

The stroller is equipped with a 5-point safety harness. Place your child in the seat and bring the shoulder straps over their shoulders, the waist straps around their waist, and the crotch strap between their legs. Connect all buckles into the central buckle until you hear a click. Adjust the straps for a snug, secure fit, ensuring they are not too tight or too loose.

Applying the Brakes

To engage the brakes, push down firmly on the brake pedal, typically located near one of the rear wheels, until the stroller stops moving. To release, lift the pedal upwards. Always engage the brakes when the stroller is stationary.

Folding the Stroller

Ensure the seat is in the forward-facing position and fully upright (if applicable). Remove any items from the storage basket. Locate the folding mechanism, usually on the handle or sides of the frame. Follow the quick-fold system instructions for your model. Once folded, secure the folding latch to prevent accidental unfolding.

MAINTENANCE AND CARE

- **Cleaning Fabric:** The polyester fabric can be cleaned by wiping with a damp cloth. Use mild soap if necessary. Do not machine wash or tumble dry.
- **Cleaning Frame:** Wipe the aluminum frame with a soft, damp cloth. Avoid abrasive cleaners.
- **Wheel Maintenance:** Regularly check wheels for debris and clean as needed. Lubricate moving parts of the wheels and axles periodically with a silicone-based lubricant.
- **Storage:** Store the stroller in a dry, cool place away from direct sunlight and extreme temperatures.
- **Inspections:** Periodically check all screws, rivets, and fasteners to ensure they are tight and secure. Inspect the safety harness for wear and tear.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Stroller does not fold/unfold smoothly.	Folding mechanism is stiff or obstructed.	Ensure all components are clear. Apply a silicone lubricant to moving parts. Refer to the folding instructions.
Wheels squeak or are difficult to turn.	Debris in wheel mechanism or lack of lubrication.	Clean wheels and axles. Apply silicone lubricant to the wheel bearings.
Seat unit is not securely attached.	Not properly aligned or locked into place.	Ensure the seat unit connectors are fully engaged with the frame slots until a click is heard. Check for obstructions.
Brakes are not engaging or releasing.	Brake mechanism is dirty or misaligned.	Clean the brake mechanism. Check for any obstructions. If the problem persists, contact customer support.

PRODUCT SPECIFICATIONS

Brand	LC
Model Number	V5
Color	Black with Rose Gold accents
Frame Material	Aluminum
Seat Material	Premium Padded Polyester
Canopy Material	Polyester
Wheel Material	Rubber
Recommended Maximum Child Weight	22 kg
Product Weight	6.8 kg

Dimensions (L x W x H)	85 cm x 45 cm x 105 cm
Folded Size	Compact Airplane Cabin Size
Harness Type	5-point harness
Number of Wheels	4
Maximum Basket Weight Capacity	4.5 kg
Car Seat Compatible	Yes (Maximum 20 kg)
Safety Standard	EN 1888-1:2018
Folding System	Quick Fold System

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the warranty card included with your purchase or contact the manufacturer directly. Keep your proof of purchase for any warranty claims.

Manufacturer: LC

Part Number: V5

© 2024 LC. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0FDF31T4C>

More documents and user manuals: **<https://manuals.plus/>**