Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

TIMU F9-EU-4B

TIMU Tagigo Tracker F9-EU-4B User Manual

Bluetooth Object Locator for Android and Apple Systems

Introduction

This manual provides comprehensive instructions for the TIMU Tagigo F9-EU-4B Bluetooth object locator. Designed to help you quickly find your lost items, the Tagigo tracker offers compatibility with both Android and Apple systems, robust IP67 water resistance, and a long-lasting replaceable battery.




Image: A single TIMU Tagigo tracker, showcasing its compact design.

Package Contents

Verify that all items are present in your package:

- Tagigo Bluetooth Trackers (4 units)
- CR2032 Battery (pre-installed, plus one spare)
- Lanyards for keys (4 units)



Image: Contents of the Tagigo tracker package, including four trackers, lanyards, and a spare battery.

Setup and Pairing

The Tagigo tracker is compatible with both Apple Find My and Google Find Hub applications. Please note that the tracker can only be connected to one device at a time.



Image: Tagigo tracker compatibility with Apple Find My and Google Find Hub, emphasizing single device connection.

iOS Pairing Instructions

1. Activate Bluetooth and Location services on your iOS device. Open the "Find My" application.
2. Tap on "Items" > "Add Item" > "Other Supported Item".
3. Press the button on the Tagigo device once. When you hear a tone, click "Connect" on your iPhone screen.



Image: Step-by-step guide for pairing the Tagigo tracker with an iOS device using the Apple Find My app.

Android Pairing Instructions

1. Download the Google Find Hub application from the Google Play Store.
2. Press the power button on the Tagigo device once to put it into pairing mode.
3. The connection page will appear automatically. Click "Connect".



Image: Step-by-step guide for pairing the Tagigo tracker with an Android device using the Google Find Hub app.

Operating Your Tagigo Tracker

Once paired, your Tagigo tracker offers several functions to help you locate your belongings.

Finding Lost Items

- **Play Sound:** Within Bluetooth range (up to 150 meters or 500 feet), tap the "Play Sound" button in your phone's application. The Tagigo will emit a sound up to 100 dB, guiding you to your item.
- **Global Tracking:** Utilize the network of Apple Find My or Google Find Hub to locate your item even when it's out of your personal Bluetooth range. The location is updated anonymously by other devices in the network.
- **Map Search:** View the last known location of your Tagigo tracker on a map within the application.

Additional Features

- **Lost Mode:** If an item is lost, activate "Lost Mode" in the app. This can display a message and contact information

to anyone who finds your item.

- **Departure Reminder:** Receive alerts on your phone if you leave an item with a Tagigo tracker behind.
- **Share with Family and Friends:** Share the location of your Tagigo tracker with trusted contacts through the application.




Image: Overview of Tagigo tracker features: Global Tracking, Departure Reminder, Share with Family and Friends, Lost Mode, and Sound Localization.

Maintenance

Battery Replacement

The Tagigo tracker uses a replaceable CR2032 coin cell battery, which provides approximately 2 years of use. A spare battery is included in your package.

1. Locate the small groove on the side of the Tagigo tracker.
2. Carefully open the casing using a small tool (e.g., a coin or flathead screwdriver).
3. Remove the old CR2032 battery.
4. Insert the new CR2032 battery with the positive (+) side facing up.
5. Close the casing securely, ensuring a tight seal to maintain water resistance.



Image: Illustration of the Tagigo tracker's internal battery compartment, highlighting the replaceable CR2032 battery and its 2-year lifespan.

Water Resistance

The Tagigo tracker is rated IP67, meaning it is resistant to dust and can withstand immersion in water up to 1 meter for 30 minutes. Ensure the casing is properly sealed after battery replacement to maintain this rating.

Troubleshooting

If you encounter issues with your Tagigo tracker, refer to the following common solutions:

- **Device not connecting/pairing:**
  - Ensure Bluetooth and Location services are enabled on your smartphone or tablet.
  - Make sure the Tagigo tracker is within Bluetooth range of your device.
  - Press the button on the tracker to activate pairing mode.
  - Check if the battery needs replacement.
  - Ensure you are not trying to connect the tracker to multiple devices simultaneously. It supports only one connection at a time.
- **Inaccurate location:**
  - Location accuracy depends on the density of other devices in the Find My/Find Hub network. In areas with fewer users, updates might be less frequent or precise.
  - Ensure your phone's location services are set to high accuracy.
- **Sound alarm not loud enough:**
  - The alarm volume is fixed at 100 dB. Ensure there are no obstructions covering the tracker's speaker.
- **Device stopped working after some time:**
  - Replace the CR2032 battery.
  - If the issue persists after battery replacement, contact customer support.

Specifications

Feature	Detail
Brand	TIMU
Model Number	F9-EU-4B
Connectivity Technology	Bluetooth 5.4
Compatible Devices	Smartphone, Tablet (Android & Apple iOS)
Control Method	Application (Apple Find My, Google Find Hub)
Water Resistance Rating	IP67
Battery Type	CR2032 (replaceable)
Average Battery Life	730 days (2 years)
Alarm Volume	100 dB
Bluetooth Range	Up to 150 meters (500 feet)
Material	Plastic
Dimensions	33 × 33 × 9 mm

Weight	8 g

Warranty and Support

For warranty information or technical assistance, please refer to the retailer where you purchased the TIMU Tagigo tracker or visit the official TIMU website. Keep your proof of purchase for warranty claims.

For further inquiries, you may also contact customer support through the application or the manufacturer's provided contact channels.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question