Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- > boAt /
- > boAt Aavante Prime 5.1 5000D Soundbar User Manual

boAt Aavante Prime 5.1 5000D

boAt Aavante Prime 5.1 5000D Soundbar User Manual

Model: Aavante Prime 5.1 5000D (HA0103)

1. Introduction

The boAt Aavante Prime 5.1 5000D is a 5.1 channel home theatre soundbar system designed to deliver an immersive audio experience. Featuring Dolby Audio, 500W RMS output, and multiple connectivity options, this system enhances your entertainment with rich, powerful sound. This manual provides essential information for setting up, operating, and maintaining your soundbar system.

2. WHAT'S IN THE BOX

Carefully unpack all components and ensure the following items are included:

- Soundbar
- Subwoofer
- 2 x Satellite Speakers
- Remote Control
- Power Cable
- Audio Cables (e.g., AUX, HDMI eARC, Optical specific cables may vary)
- User Manual



Image: All components of the boAt Aavante Prime 5.1 5000D soundbar system, including the main soundbar, subwoofer, and two satellite speakers.

3. PRODUCT OVERVIEW

3.1 Main Components

- Soundbar: The central unit housing multiple speakers for front audio channels.
- Subwoofer: Provides deep bass frequencies for enhanced audio impact.
- Satellite Speakers: Two wired rear speakers for surround sound effects.

3.2 Controls and Indicators

The soundbar features onboard controls (typically for power, volume, and input selection) and LED indicators. The primary control method is the included remote control.





Image: The master remote control for the soundbar, alongside icons representing various connectivity options: Optical, Bluetooth v5.3, AUX IN, HDMI (ARC), and USB.

4. SETUP

4.1 Placement

Optimal placement is crucial for a 5.1 channel system to achieve the best surround sound experience.

- **Soundbar:** Place the soundbar centrally below your television. Ensure it is not obstructed. It can be tabletop mounted or wall-mounted.
- **Subwoofer:** Position the subwoofer on the floor, ideally in the front of the room, near the soundbar. Experiment with placement to find the best bass response for your room.
- Satellite Speakers: Place the two wired satellite speakers behind your primary listening position, one on the left and one on the right, facing towards the listener.



Image: A visual representation of a 5.1 channel home theatre setup, illustrating the placement of the soundbar, subwoofer, and two rear satellite speakers around a seating area for an immersive audio experience.

4.2 Connections

Connect the soundbar system to your audio source (e.g., TV, media player) using one of the available methods:

- HDMI (eARC): For the best audio quality and control, connect an HDMI cable from the soundbar's HDMI (eARC) port to your TV's HDMI (eARC) port. This allows for high-quality audio transmission and TV remote control integration.
- 2. **Optical:** Connect an optical cable from the soundbar's OPTICAL IN port to your TV's optical digital audio output.
- 3. AUX IN: Use a 3.5mm audio cable to connect the soundbar's AUX IN port to the audio output of your device.
- 4. USB: Insert a USB drive into the USB port to play audio files directly.
- 5. **Wired Subwoofer and Satellite Speakers:** Connect the wired subwoofer and satellite speakers to the designated ports on the soundbar according to the labels.

After connecting, plug the power cable into the soundbar and then into a power outlet.

5. OPERATING INSTRUCTIONS

5.1 Power On/Off

Press the Power button on the soundbar or the remote control to turn the system on or off.

5.2 Input Selection

Press the 'Input' button on the remote control or the soundbar to cycle through available input sources: HDMI (eARC), Optical, AUX, USB, and Bluetooth.

5.3 Bluetooth Pairing

- 1. Switch the soundbar to Bluetooth mode using the 'Input' button. The LED indicator will flash, indicating pairing mode.
- 2. On your mobile device, enable Bluetooth and search for available devices.
- 3. Select "boAt Aavante Prime 5.1 5000D" from the list.
- 4. Once paired, the LED indicator will stop flashing and remain solid.

5.4 EQ Modes

The soundbar features multiple Equalizer (EQ) modes to optimize audio for different content types. Use the 'EQ' button on the remote control to switch between:

- Movie Mode: Enhances dialogue and cinematic effects.
- Music Mode: Optimizes audio for music playback.
- News Mode: Clarifies speech for news and spoken content.




Image: A visual representation of the soundbar's tailored soundscapes, showing icons for Movie, News, and Music modes, indicating optimized audio experiences for each content type.

5.5 Remote Control Functions

The master remote control allows you to manage all functions of the soundbar system, including:

- · Power On/Off
- · Volume Up/Down
- Mute
- Input Source Selection
- EQ Mode Selection
- Bass/Treble Adjustment
- Playback Controls (for USB/Bluetooth modes)

6. MAINTENANCE

To ensure the longevity and optimal performance of your soundbar system, follow these maintenance guidelines:

- Cleaning: Use a soft, dry cloth to clean the surfaces of the soundbar, subwoofer, and satellite speakers. Do not use liquid cleaners or abrasive materials.
- Ventilation: Ensure proper ventilation around all components. Do not block any vents.
- Environment: Avoid exposing the system to extreme temperatures, humidity, direct sunlight, or dust.
- Cables: Periodically check all cable connections to ensure they are secure.

7. TROUBLESHOOTING

If you encounter issues with your boAt Aavante Prime 5.1 5000D, refer to the following troubleshooting steps:

Problem	Possible Cause	Solution
No power	Power cable not connected; Power outlet faulty	Ensure power cable is securely connected. Try a different power outlet.
No sound	Incorrect input selected; Volume too low; Mute activated; Loose audio cables	Select the correct input source. Increase volume. Deactivate mute. Check all audio cable connections.
Bluetooth pairing fails	Soundbar not in pairing mode; Device too far; Interference	Ensure soundbar is in Bluetooth pairing mode. Move device closer. Restart both devices.
Remote control not working	Batteries depleted; Obstruction; Remote out of range	Replace remote control batteries (2 AA batteries). Remove any obstructions between remote and soundbar. Ensure remote is within operating range.
Poor sound quality	Incorrect EQ mode; Source audio quality; Speaker placement	Adjust EQ mode. Ensure source audio is high quality. Review speaker placement.

If the issue persists after attempting these solutions, please contact boAt customer support.

8. SPECIFICATIONS

The following are the technical specifications for the boAt Aavante Prime 5.1 5000D Soundbar system:

Feature	Specification
Model Name	Aavante
Model Number	HA0103
Speaker Type	Soundbar
Surround Sound Channel Configuration	5.1
Speaker Maximum Output Power	500 Watts RMS

Feature	Specification
Special Feature	Dolby Enabled
Connectivity Technology	Bluetooth v5.3, AUX, USB, Optical, HDMI (eARC)
Wireless Communication Technology	Bluetooth
Frequency Response	20 KHz (typical, full range not specified)
Audio Output Mode	Surround
Control Method	Remote
Power Source	Wired
Product Dimensions	87D x 6.7W x 9H Centimeters
Item Weight	6 kg
Batteries Required (for remote)	2 AA batteries (included)
Mounting Type	Tabletop Mount (also wall-mountable)

9. WARRANTY AND SUPPORT

9.1 Warranty Information

The boAt Aavante Prime 5.1 5000D Soundbar comes with a limited warranty. Please refer to the warranty card included in your product packaging for specific terms and conditions. An optional 1-year extended warranty may be available from authorized sellers.

9.2 Customer Support

For technical assistance, troubleshooting, or warranty claims, please contact boAt customer support through their official website or the contact information provided in your product documentation.

Related Documents - Aavante Prime 5.1 5000D



boAt Aavante Prime 5.1 5000D Soundbar User Manual

User manual for the boAt Aavante Prime 5.1 5000D 5.1-channel Dolby Audio soundbar system. Covers setup, operation, safety, connectivity, and specifications for an immersive home audio experience.



boAt Aavante Prime Beat 5.1 Channel Dolby Audio Soundbar User Manual

User manual for the boAt Aavante Prime Beat 5.1 Channel Dolby Audio Soundbar. Learn about product overview, components, safety, setup, installation, connections, operation, and specifications.







boAt AAVANTE BAR 5500DA User Manual

User manual for the boAt AAVANTE BAR 5500DA 5.1.2 Channel 500W Dolby Atmos Sound Bar with Wired Subwoofer & Dual Wireless Rear Satellites. Includes setup, installation, operation, and technical specifications.



boAt Aavante Prime 5.1 5050D Soundbar User Manual

Comprehensive user manual for the boAt Aavante Prime 5.1 5050D 500W RMS 5.1 Channel Dolby Audio Soundbar. Includes setup, installation, safety, and operation guides.



boAt Aavante Prime 5.1 5000DA Soundbar User Manual

Comprehensive user manual for the boAt Aavante Prime 5.1 5000DA 5.1-Channel Dolby Atmos Soundbar, covering setup, operation, safety, and specifications.







boAt Aavante Bar 3200D 5.1 Channel Soundbar User Manual | Setup and Operation

Comprehensive user manual for the boAt Aavante Bar 3200D 5.1 channel soundbar. Learn how to set up, connect, and operate your 350W RMS Dolby sound system with wired subwoofer and wireless rear speakers.