

[Manuals.plus](#) /

› [VINGLI](#) /

› VINGLI 110' U Shaped Comfy Sectional Couch User Manual

VINGLI B0FDGD2KRW

VINGLI 110' U Shaped Comfy Sectional Couch User Manual

Model: B0FDGD2KRW

PRODUCT OVERVIEW

The VINGLI 110' U Shaped Comfy Sectional Couch is a versatile and comfortable seating solution designed for modern living spaces. This 4-seater sofa features a double chaise configuration, upholstered in a soft and durable corduroy fabric. It is engineered with high-density foam and spring support for lasting comfort and includes removable seat and back cushions for easy maintenance.



Image: The VINGLI U-shaped sectional couch in beige corduroy, showcasing its full configuration in a living room setting.

SPECIFICATIONS

Brand	VINGLI
Model	B0FDGD2KRW
Product Dimensions (D x W x H)	48.4"D x 111.4"W x 33.3"H
Seat Depth	20.9 inches
Seat Height	16.5 Inches

Seating Capacity	4 people
Upholstery Material	Corduroy Fabric
Color	Corduroy-beige
Assembly Required	Yes
Special Features	5.9" Thick Cushion, Double Chaise, Removable Back & Seat Cushions



Image: Detailed dimensions of the VINGLI U-shaped sectional couch, including overall length, depth, and height, as well as individual seat and chaise measurements.

SETUP AND ASSEMBLY

The VINGLI U-shaped sectional couch requires assembly. It is recommended to have at least two people for the assembly process. Ensure all components are present before beginning.

Package Contents:

- Sofa sections (main body, two chaise sections)
- Back cushions
- Seat cushions
- Legs
- Assembly hardware (bolts, washers, Allen wrench)
- Instruction manual (this document)

Assembly Steps:

1. **Unpack Components:** Carefully remove all parts from the packaging. Lay them out on a clean, soft surface to prevent scratches.
2. **Attach Legs:** Locate the pre-drilled holes on the bottom of each sofa section. Screw the wooden legs into these holes. Ensure they are tightened securely.
3. **Connect Sections:** Align the connecting brackets on the sides of the sofa sections. Slide the sections together until they lock firmly in place. Repeat for all sections to form the U-shape.
4. **Place Cushions:** Position the seat cushions onto the sofa base. Then, place the back cushions against the backrest. The removable design allows for easy placement and adjustment.
5. **Final Check:** Verify that all connections are secure and the sofa is stable before use.



Image: Close-up views of the sofa's components, highlighting the detachable back cushions, removable seat cushions, and the wood grain texture of the footrests/legs, which are key for assembly and maintenance.

OPERATING AND USAGE

The VINGLI U-shaped sectional couch is designed for comfortable seating and relaxation. Its modular design allows for flexible use within your living space.

Key Features:

- **Spacious Seating:** Accommodates up to four people comfortably with ample space on the double chaises for stretching out.
- **Comfortable Cushioning:** Features 5.9-inch thick padded cushions with high-density foam and supportive pocket coils for superior comfort and support.
- **Corduroy Fabric:** The luxurious corduroy fabric offers a soft, plush feel, warmth in winter, and breathability in summer. Its textured surface helps camouflage minor spills.

- **Removable Cushions:** Both seat and back cushions are removable, making them easy to clean, wash, or replace. This also allows for versatile use, such as transforming seat cushions into floor pillows.
- **Lazy Recline Design:** The backrest is designed to provide optimal support for the neck, lumbar, hips, and legs, promoting ultimate relaxation.

U-Shape Sectional Sofa



Image: A woman comfortably seated on the U-shaped sectional sofa, illustrating the breathable nature of the corduroy fabric and the substantial cushioning provided by the 5.9-inch thick padded seats and high-density foam with pocket coils.

Lazy recline design:

Seat and back angle for ultimate relaxation



Image: A woman reclining on the sofa, with annotations indicating the support points for the neck, lumbar, hips, and legs, demonstrating the ergonomic "lazy recline" design.

MAINTENANCE AND CARE

Proper care and maintenance will extend the life and appearance of your VINGLI sectional couch.

General Care:

- **Regular Vacuuming:** Vacuum the sofa regularly using a soft brush attachment to remove dust and debris.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight can cause fabric fading. Position the sofa away from direct sunlight or use curtains/blinds.
- **Rotate Cushions:** Periodically rotate and flip seat and back cushions to ensure even wear and maintain their shape.
- **Protect from Pets:** While the fabric is durable, consider using throws or covers if you have pets to protect against scratches and excessive pet hair.

Cleaning Instructions:

- **Spot Cleaning:** For small spills, blot immediately with a clean, dry cloth. Do not rub. For stubborn stains, use a mild fabric cleaner specifically designed for upholstery, testing on an inconspicuous area first.
- **Removable Cushions:** The removable seat and back cushions are designed for easy cleaning. Most corduroy upholstery is machine washable. Refer to the care label on the cushions for specific washing instructions. Typically, machine wash cold on a gentle cycle and air dry.
- **Deep Cleaning:** For a thorough cleaning, professional upholstery cleaning is recommended every 12-18 months.



Image: A close-up view of the corduroy fabric, emphasizing its skin-friendly texture and smooth lines, which contribute to its ease of maintenance and aesthetic appeal.

TROUBLESHOOTING

This section addresses common issues you might encounter with your VINGLI sectional couch.

Problem	Possible Cause	Solution
Sofa feels unstable or wobbly.	Legs are not tightened properly or sections are not fully connected.	Ensure all legs are securely screwed into their fittings. Check that all sectional connectors are fully engaged and locked.
Cushions appear lumpy or misshapen.	Uneven wear from prolonged use in one spot.	Fluff and rotate cushions regularly. This helps redistribute the filling and maintain shape.
Fabric has a stain.	Spill or dirt accumulation.	Immediately blot the stain with a clean, dry cloth. For washable cushions, follow care label instructions. For non-removable areas, use a mild upholstery cleaner as directed.
Squeaking noises when sitting.	Loose connections or friction between frame components.	Re-tighten all assembly hardware. If the issue persists, inspect the frame for any rubbing points and apply a small amount of silicone spray if accessible and safe for materials.

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the details provided at the time of purchase or contact VINGLI customer service directly.

- **Warranty Coverage:** Specific warranty terms and duration may vary. Please retain your proof of purchase for any warranty claims.
- **Contact Support:** For assistance with assembly, parts, or any product-related inquiries, visit the official VINGLI store on Amazon or their website.
- **Online Resources:** Additional support and FAQs may be available on the VINGLI brand page:[VINGLI Amazon Store](#).

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0FDGD2KRW>

More documents and user manuals: <https://manuals.plus/>