

NILLKIN Nillkin Foldable Bluetooth Keyboard (B0FDGDH8CG)

Nillkin Foldable Bluetooth Keyboard with Touchpad and Numeric Keypad User Manual

Model: B0FDGDH8CG

1. INTRODUCTION

Thank you for choosing the Nillkin Foldable Bluetooth Keyboard. This compact and versatile keyboard is designed to enhance your productivity across multiple devices and operating systems. Please read this manual carefully to ensure proper setup and operation.

2 in 1 テンキー 高感度タッチパッド



Image 1.1: The Nillkin Foldable Bluetooth Keyboard in its fully unfolded state, ready for use.

2. PRODUCT OVERVIEW

2.1 Key Features

- **Compact & Portable:** Three-fold design, lightweight (approx. 238g), easily fits into bags.
- **Integrated Touchpad & Numeric Keypad:** High-precision touchpad (59x64mm) with multi-gesture support and a switchable numeric keypad.
- **Comfortable Typing:** Laptop-like feel with full-size keys, pantograph structure, 19mm key pitch, and 1.2mm key travel.
- **Efficient Power Management:** Type-C fast charging, long battery life (1 week+ continuous use, 150 days standby), auto-sleep, and auto power on/off.
- **Multi-Device & Multi-OS Support:** Bluetooth 5.0 for stable connection up to 10m. Connects up to 3 devices simultaneously, compatible with iOS, Android, Mac, and Windows.
- **Durable Design:** High-quality hinge tested for over 50,000 folds, magnetic closure.

2.2 Package Contents

- Nillkin Foldable Bluetooth Keyboard x 1
- USB-C Charging Cable x 1

- Storage Pouch x 1
- User Manual x 1



Image 2.1: Contents of the Nillkin Foldable Bluetooth Keyboard package.

3. SETUP INSTRUCTIONS

3.1 Power On/Off

- **Power On:** Unfold the keyboard. The keyboard will automatically power on.
- **Power Off:** Fold the keyboard. The keyboard will automatically power off.
- Alternatively, use the dedicated ON/OFF switch located on the side of the keyboard.



Image 3.1: The keyboard's compact folded size (18.2 x 10.8 x 1.6cm) and extended dimensions (34.2 x 10.8 x 0.95cm).

3.2 Bluetooth Pairing

Ensure your device has Bluetooth functionality enabled before proceeding. If your device lacks Bluetooth, a separate Bluetooth dongle may be required.

1. Activate Pairing Mode:

- Turn on the keyboard by unfolding it or using the power switch.
- Press **Fn + A (BT1)** briefly to select Bluetooth channel 1.
- Press and hold **Fn + C (Pairing)** for approximately 3 seconds. The blue indicator light for Bluetooth connection 1 will flash, indicating the keyboard is in pairing mode.

2. On Your Device:

- Go to your device's Bluetooth settings (e.g., *Settings > Bluetooth* on iOS/Android, or *System Preferences > Bluetooth* on Mac, or *Settings > Devices > Bluetooth & other devices* on Windows).
- Ensure Bluetooth is turned on. Your device will begin searching for nearby Bluetooth devices.

3. Connect:

- Locate "Nillkin Foldable Keyboard" (or similar name) in the list of available devices.
- Tap or click on the device name to initiate pairing.
- If prompted for a PIN code, enter the code displayed on your device's screen using the Nillkin keyboard, then press **Enter**.

- Once connected, the keyboard is ready for use. The blue indicator light will turn solid or extinguish,

depending on the device.

Video 3.1: Detailed usage instructions for the Nillkin Foldable Bluetooth Keyboard, including pairing steps.

3.3 Multi-Device Pairing & Switching

The keyboard supports simultaneous connection to up to three devices. After pairing each device, you can switch between them with a single touch.

- **Pairing Additional Devices:** Follow the Bluetooth pairing steps (Section 3.2) for each device, using **Fn + S (BT2)** for the second device and **Fn + D (BT3)** for the third device.
- **Switching Devices:** Once paired, press **Fn + A (BT1)**, **Fn + S (BT2)**, or **Fn + D (BT3)** to instantly switch between your connected devices.



Image 3.2: Connect up to three devices simultaneously and switch between them easily.

Video 3.2: Operation video demonstrating Bluetooth connection and switching between devices.

4. OPERATING INSTRUCTIONS

4.1 Keyboard Layout & Typing

The keyboard features a standard layout with a comfortable 19mm key pitch and a responsive pantograph key structure for a quiet and efficient typing experience.



Image 4.1: The full keyboard layout, including function keys and the integrated numeric keypad/touchpad.

4.2 Touchpad & Numeric Keypad Functions

The right side of the keyboard integrates a high-precision touchpad and a numeric keypad. You can switch between these modes for enhanced functionality.

- **Switching Modes:** Press **Fn + Right Command key** to toggle between touchpad mode and numeric keypad mode.
- **Touchpad Gestures:** Supports various multi-touch gestures for smooth scrolling and navigation.
- **Left/Right Click:** Dedicated left and right click buttons are available below the touchpad area.



Image 4.2: The 2-in-1 design of the numeric keypad and touchpad, highlighting its functions.

4.3 Shortcut Keys

The keyboard includes 14 types of shortcut keys to improve work efficiency. These are typically accessed by pressing the **Fn** key in combination with the corresponding function key (F1-F12).

- **Fn + F1/F2:** Brightness adjustment
- **Fn + F3:** Search
- **Fn + F4:** Back
- **Fn + F5:** Skip
- **Fn + F6:** Next
- **Fn + F7:** Mute
- **Fn + F8:** Volume down
- **Fn + F9:** Volume up
- **Fn + F10:** Show task window
- **Fn + F11:** Screenshot
- **Fn + F12:** Screen lock

Video 4.1: Product demonstration highlighting the keyboard's features and functionality.

4.4 Language Switching

- **iOS / Mac:** Press **Ctrl + Spacebar**.
- **Android:** Press **Ctrl + Spacebar** or **Shift + Spacebar**.
- **Windows:** Press **Alt + Shift**.

5. CHARGING

The keyboard features a large-capacity battery and Type-C fast charging. A full charge provides over a week of continuous use and up to 150 days of standby time.

- **Charging Port:** Connect the provided USB-C cable to the charging port on the keyboard and to a suitable USB power source.
- **Charging Indicator:** The red indicator light will stay on during charging and turn off when fully charged.
- **Battery Level Check:** Press **Fn + Left Command key** to check the current battery level via the LED indicators.



Image 5.1: Type-C charging port and battery status indicators.

6. MAINTENANCE

- Keep the keyboard clean by wiping it with a soft, dry cloth.
- Avoid exposing the keyboard to extreme temperatures, humidity, or direct sunlight.
- Do not disassemble the keyboard, as this will void the warranty.
- The keyboard features a magnetic design for secure closure. Avoid placing it near strong magnetic fields.



Image 6.1: Cleaning the keyboard with a soft cloth.

7. TROUBLESHOOTING

If you encounter issues with your Nillkin Foldable Bluetooth Keyboard, please refer to the following common solutions:

- **Keyboard not pairing:**
 - a. Ensure the keyboard is fully charged.
 - b. Confirm the keyboard is in pairing mode (blue indicator light flashing).
 - c. Check that Bluetooth is enabled on your device.
 - d. Move the keyboard closer to your device and ensure no obstructions are between them.
 - e. Try restarting both the keyboard and your device.
- **Keys not responding:**
 - a. Check the battery level.
 - b. Ensure the keyboard is properly connected to your device.
 - c. If using the numeric keypad, ensure it is not in touchpad mode.
- **Touchpad not working:**
 - a. Ensure the keyboard is in touchpad mode (not numeric keypad mode).
 - b. For iPad users, ensure "AssistiveTouch" is enabled in your iPad settings.
 - c. Some gestures may not be supported depending on the OS or application.
- **Connection drops frequently:**
 - a. Ensure the keyboard is within the 10m Bluetooth range.
 - b. Minimize interference from other wireless devices.
 - c. Ensure the keyboard is fully charged.

8. SPECIFICATIONS

Feature	Detail
Brand	Nillkin
Model	B0FDGDH8CG
Product Dimensions (Unfolded)	34.2 x 10.8 x 0.95 cm
Product Dimensions (Folded)	18.2 x 10.8 x 1.6 cm
Item Weight	490 g (approx. 238g for main body)
Connectivity Technology	Bluetooth 5.0
Compatible Devices	iPad OS, Windows 10+, Mac OS X 10.10+, Android 4.3+, Smartphones, Tablets, Laptops, PCs
Power Source	Battery Powered (Rechargeable)
Lithium Battery Energy Content	2.6 Watt-hours
Number of Lithium Ion Cells	4
Material	ABS, Silicone, Polycarbonate

9. WARRANTY AND SUPPORT

Nillkin products come with a comprehensive warranty and dedicated customer support:

- **Manufacturer Warranty:** 2 years from the date of purchase.
- **Quality Guarantee:** 30-day quality guarantee for returns/exchanges of defective products.
- **Customer Service:** 24/365 customer service is available. For any issues, please contact us via your Amazon account: *Account Service > Order History > Contact Seller*. We aim to respond within 24 hours.



Image 9.1: Nillkin's commitment to quality, warranty, and customer support.

