

Gamrombo Xbox

Gamrombo Wireless Gaming Controller User Manual

Model: Xbox

Brand: Gamrombo

INTRODUCTION

This manual provides detailed instructions for the Gamrombo Wireless Gaming Controller, designed for use with Xbox One, Xbox Series X|S, Xbox One S|X, PC, Android, iOS, and Windows 11/10/8/7. It features Hall effect triggers and joysticks, adjustable RGB lighting, macro functions, turbo mode, and a 3.5mm audio jack for an immersive gaming experience.

SETUP AND INITIAL CONNECTION

Compatibility

The Gamrombo Wireless Gaming Controller is compatible with a wide range of platforms, including:

- Xbox One, Xbox Series X, Xbox Series S, Xbox One S, Xbox One X, Xbox 1, Xbox Elite Controller Series, Xbox Core Controller
- PC (Windows 11/10/8/7)
- Android devices
- iOS devices

STRONG COMPATIBILITY

The game controller compatible with PC, Mac, Steam, Samsung, iOS, Android and Windows 7 and above system



PC/Windows
7 and above



MAC/Laptop



Android



iOS/iPad



Samsung



Steam

Image illustrating the Gamrombo controller's compatibility with various platforms including PC/Windows, Mac/Laptop, Android, iOS/iPad, Samsung, and Steam.

Firmware Upgrade

If you experience connection issues or require technical upgrades, it is recommended to update the controller's firmware. The upgrade process is performed on a Windows PC.

1. Ensure the controller is turned off before starting the upgrade.
2. Download the upgrade program from the official link: [we.tl/t-eSMIX0c9Yk](https://t.me/eSMIX0c9Yk)
3. Follow the instructions provided with the upgrade program.
4. If the connection is interrupted during the upgrade, try using a different USB port on your PC.

If you can't connect your Xbox, upgrade your controller

Upgrade program download URL: we.tl/t-eSMIX0c9Yk

Watch the video upgrade steps URL: youtu.be/BEzuR9TQNFE

It will continue to be compatible with Xbox devices after upgrading, and the upgrade can only be done on Windows PC. Upgrading is easy and only takes 2-3 minutes.



Image showing the Gamrombo controller with text overlay instructing users to upgrade the controller if connection issues occur, providing a download link and video tutorial link.

Upgrade Video Tutorial

Your browser does not support the video tag.

Video tutorial demonstrating the steps to upgrade the Gamrombo Wireless Gaming Controller firmware on a PC.

OPERATING INSTRUCTIONS

Hall Effect Sensors

The controller is equipped with four Hall effect sensors for enhanced joystick and trigger control. These sensors provide precise and reliable input detection, resulting in smoother and more accurate movement and aiming during gameplay.

Adjustable RGB Lighting

Customize your gaming experience with the controller's RGB lighting effects. You can switch between various colors

and eight adjustable modes to match your preferences and create an immersive atmosphere.

SEVEN ADJUSTABLE
COLORS & EIGHT ADJUSTABLE MODES

Feel free to switch between various RGB lighting effects in any game and space to give you a cool gaming experience



Colorful Glitter



Colorful Mode



Rocker Area



Central Area



Grip Area



Regional Light



Color Cycle



Colorful

A collage of eight images, each showing the Gamrombo controller with different RGB lighting effects and modes, such as Colorful Glitter, Rocker Area, and Color Cycle.

Dual Vibration Motors

Experience realistic feedback with the built-in dual vibration motors. These motors provide tactile sensations that enhance immersion in games, with adjustable intensity levels (Weak, Moderate, Strong).

EXCITING DUAL-VIBRATION MOTORS

built-in dual motors shock provide excellent vibration effect



Image depicting the Gamrombo controller with visual effects indicating dual-vibration motors, showing 'Weak', 'Moderate', and 'Strong' vibration levels, set against a background of racing game scenes.

6-Axis Motion Sensor

The integrated 6-axis motion sensor enhances dynamic feeling and provides precise control for games that utilize motion input. This allows for improved direction control, visual field angle changes, and responsive actions.

6-AXIS MOTION SENSOR ENHANCE DYNAMIC FEELING

built-in dual motors shock provide excellent vibration effect



Three panels illustrating the 6-axis motion sensor feature of the Gamrombo controller, showing 'Direction Control', 'Visual Field Angle Change', and 'Action Responsive' in gaming scenarios.

Semi Auto Turbo Mode

Activate the Semi Auto Turbo Mode for rapid firing in games. To use this feature:

1. Press and hold the **TURBO** key.
2. While holding **TURBO**, press any function key (e.g., A, B, X, Y, LB, RB, LT, RT).
3. Release both keys. The selected function key will now have the turbo function enabled.

To disable the turbo function for a key, repeat the same operation.

MULTIFUNCTIONAL GAME CONTROLLER

Semi Auto Turbo Mode

**LB/ RB/ LT/ RT
A/B/X/Y**



Press and hold the TUBRO key without letting go, and then press and hold any function key (such as the A key), then the operation is completed, and the A key has realized the TUBRO function



Close: Repeat the operation to close the "turbo" function of the corresponding key.

Image highlighting the Semi Auto Turbo Mode feature of the Gamrombo controller, with instructions on how to activate it by pressing the TUBRO key and a function key.

Editable Macro Function

The controller supports programmable macro functions, allowing you to assign a sequence of up to 16 key values to a single button.

1. Press the **[Set]** key.
2. Press any function key (ABXY/LB/RB/LT/RT/L3/R3/Turbo/Cross Key/Left&Right joysticks).
3. Press the **[PL]/[PR]** key to record the macro.



Image detailing the Editable Macro Function of the Gamrombo controller, showing programmable buttons and instructions for setting up macro key values.

3.5mm Audio Jack

Connect any compatible headset to the integrated 3.5mm audio headset jack for in-game audio and communication.

MAINTENANCE

To ensure the longevity and optimal performance of your Gamrombo Wireless Gaming Controller, follow these general maintenance guidelines:

- Keep the controller clean by wiping it with a soft, dry cloth. Avoid using harsh chemicals or abrasive materials.
- Store the controller in a cool, dry place away from direct sunlight and extreme temperatures.
- Avoid dropping the controller or subjecting it to strong impacts.
- Do not attempt to disassemble the controller, as this may void any potential warranty and cause damage.

TROUBLESHOOTING

Connection Issues

If you experience difficulty connecting your controller, please refer to the [Setup and Initial Connection](#) section, specifically the Firmware Upgrade instructions. An outdated firmware version can sometimes cause connectivity problems.

Other Technical Issues

For any other technical issues or assistance, please contact the seller for support.

SPECIFICATIONS

Feature	Detail
ASIN	B0FDGGQ91R
Item Model Number	Xbox
Manufacturer	Gamrombo
Item Weight	12.3 ounces
Package Dimensions	6.77 x 4.76 x 2.91 inches
Date First Available	June 17, 2025



SUPPORT

For technical assistance, warranty inquiries, or any questions regarding your Gamrombo Wireless Gaming Controller, please contact the seller directly through your purchase platform.



© 2025 Gamrombo. All rights reserved.

Related Documents - Xbox

	<p>Gamrombo Controller Software Upgrade Guide</p> <p>Step-by-step guide to upgrade your Gamrombo wireless controller software, including download links, connection instructions, and important post-upgrade notes.</p>
	<p>Gamrombo Wired Controller Upgrade Software Guide</p> <p>Learn how to download and install the latest upgrade software for your Gamrombo wired controller using the MP325 Update tool. Follow step-by-step instructions for a smooth firmware update.</p>

