

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [ZWP](#) /

› [ZWP Replacement Ceiling Fan Remote Control User Manual for FS-HX-R520, E27, Ruibutrade, Smart Egg, Nuueo CFL03-L, OPONL FS2057-WH](#)

## ZWP FS-HX-R520, E27, Ruibutrade, Smart Egg, Nuueo CFL03-L, OPONL FS2057-WH

# ZWP Replacement Ceiling Fan Remote Control User Manual

Models: FS-HX-R520, E27, Ruibutrade, Smart Egg, Nuueo CFL03-L, OPONL FS2057-WH

## 1. INTRODUCTION

---

This manual provides detailed instructions for the ZWP Replacement Ceiling Fan Remote Control. It is designed to be compatible with various ceiling fan models, including FS-HX-R520, E27, Ruibutrade, Smart Egg, Nuueo CFL03-L, and OPONL FS2057-WH. Please read this manual thoroughly before use to ensure proper operation and longevity of your remote control.

## 2. PRODUCT OVERVIEW

---

The ZWP Replacement Ceiling Fan Remote Control is a high-quality, durable, and ergonomic device designed for convenient operation of compatible ceiling fans. It features a comfortable hand feeling and is made from wear-resistant ABS material with soft silicone buttons.



**Figure 2.1:** ZWP Replacement Ceiling Fan Remote Control. This image displays the front view of the white remote control, showcasing its ergonomic design and button layout.



**Figure 2.2:** Close-up of ZWP Remote Control Buttons. This image highlights the soft silicone buttons and the ABS environmental protection material used in the remote's construction, emphasizing quality and user comfort.

## 3. SETUP

### 3.1 Battery Installation

The remote control requires two (2) AAA batteries (not included). Follow these steps to install the batteries:

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch (if present) to open the compartment.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Close the battery compartment cover by sliding it back into place until it clicks securely.




**Figure 3.1:** Battery Installation. This image illustrates the open battery compartment of the remote control and shows two AAA batteries, indicating their correct insertion polarity. The text "Work Right Out Of The Box After Putting Batteries" and "Requires Two AAA batteries (Batteries are not included)" are also visible.

### 3.2 Pairing / Programming

This ZWP Replacement Ceiling Fan Remote Control is designed for immediate use. **No programming is required.** Simply install the batteries, and the remote will be ready to operate your compatible ceiling fan.

## 4. OPERATING INSTRUCTIONS

Familiarize yourself with the buttons and their functions for optimal control of your ceiling fan.



**Figure 4.1:** Remote Control Button Functions. This image provides a detailed view of the remote's buttons, with dotted lines pointing to specific functions like CCT-, CCT+, fan speed, and timer settings (1h, 2h, 4h).

- **Power Button (Red Circle with Line):** Turns the fan and light ON/OFF.
- **Fan Speed Button (Fan Icon):** Cycles through fan speed settings (e.g., Low, Medium, High).
- **Light Button (Light Bulb Icon):** Turns the light ON/OFF.
- **CCT- / CCT+ Buttons (Sun/Moon Icons with CCT):** Adjusts the Correlated Color Temperature (CCT) of the light, making it warmer or cooler.
- **Dimming Buttons (Sun/Moon Icons without CCT):** Adjusts the brightness level of the light.
- **M Button (Mode):** May cycle through different light modes or fan modes, depending on the fan model.
- **Wind Mode Buttons (Wavy Lines):** Activates different wind modes, such as natural breeze or sleep mode.
- **Timer Buttons (1h, 2h, 4h):** Sets the fan or light to turn off automatically after 1, 2, or 4 hours.

#### 4.1 Operational Distance

The remote control has an effective operational distance of approximately 8 meters (26 feet). Ensure there are no significant obstructions between the remote and the ceiling fan receiver for optimal performance.



**Figure 4.2:** Operational Distance. This image shows the remote control being used in a bedroom setting with a ceiling fan, illustrating its effective operational range of 8 meters.



Figure 4.3: Signal Strength. This image depicts the remote control being used outdoors with a ceiling fan, visually representing strong signal transmission and extended service life.

## 5. MAINTENANCE

## 5.1 Battery Replacement

Replace batteries when the remote's operational range decreases or if it becomes unresponsive. Always replace both AAA batteries simultaneously with new ones. Do not mix old and new batteries, or different types of batteries.

## 5.2 Cleaning

Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners, abrasive cleaners, or solvents, as these may damage the surface or internal components.

## 5.3 Storage

If the remote control will not be used for an extended period, remove the batteries to prevent leakage and potential damage to the device.

## 6. TROUBLESHOOTING

---

- **Remote not responding:**

- Check if the batteries are inserted correctly with the correct polarity.
- Replace old batteries with new AAA batteries.
- Ensure there are no obstructions between the remote and the fan's receiver.
- Verify that the fan's main power supply is ON.

- **Short operational range:**

- Replace batteries with new ones.
- Reduce distance between the remote and the fan.
- Remove any potential interference sources (e.g., other electronic devices).

- **Fan or light not responding to specific buttons:**

- Ensure your ceiling fan model supports the specific function (e.g., CCT adjustment, specific wind modes).
- Some functions may require the fan to be in a certain state (e.g., light must be on to dim).

## 7. SPECIFICATIONS

---

<b>Brand</b>	ZWP
<b>Compatible Models</b>	FS-HX-R520, E27, Ruibutrade, Smart Egg, Nuueo CFL03-L, OPONL FS2057-WH Ceiling Fans
<b>Power Source</b>	2 x AAA Batteries (not included)
<b>Material</b>	High-quality ABS, Soft Silicone Buttons
<b>Operational Distance</b>	Up to 8 meters (approx. 26 feet)
<b>Dimensions</b>	7.4 x 2.5 x 1.1 inches (approx.)
<b>Item Weight</b>	2.08 ounces (approx.)
<b>Special Feature</b>	Ergonomic Design

## 8. WARRANTY AND SUPPORT

---

ZWP is committed to providing high-quality products. If you encounter any issues or have questions regarding your ZWP Replacement Ceiling Fan Remote Control, please do not hesitate to contact the seller directly through your purchase platform. We are dedicated to assisting you and resolving any concerns promptly.

For further assistance, please refer to the contact information provided with your purchase or visit the ZWP store page on Amazon: [ZWP Store](#).

