

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [ZWP](#) /

› [ZWP Replacement Remote Control User Manual for LITTARBY, AURALK, OSTIVE Ceiling Fans](#)

## ZWP Replacement Remote Control

# ZWP Replacement Remote Control User Manual

For LITTARBY 783798488341, 783798488358, AURALK FS001, OSTIVE QF-259A Ceiling Fans

## INTRODUCTION

---

This manual provides instructions for the ZWP Replacement Remote Control, designed for use with specific LITTARBY, AURALK, and OSTIVE ceiling fan models. Please read this manual thoroughly before use to ensure proper operation and longevity of your remote control.

### Compatible Ceiling Fan Models:

- LITTARBY 783798488341
- LITTARBY 783798488358
- AURALK FS001
- OSTIVE QF-259A

## SETUP

---

### 1. Package Contents

Verify that your package contains the following item:

- 1 x ZWP Replacement Remote Control

**Note:** AAA batteries are not included and must be purchased separately.

### 2. Installing Batteries

1. Locate the battery compartment on the back of the remote control.
2. Slide open the battery compartment cover.
3. Insert two (2) AAA batteries, ensuring correct polarity (+ and -) as indicated inside the compartment.
4. Close the battery compartment cover securely.

## Work Right Out of The Box After Putting Batteries

Requires Two AAA batteries  
(Batteries are not included)



Image: Back of the remote control with the battery compartment open, illustrating the correct insertion of two AAA batteries. The remote requires two AAA batteries, which are not included.

The remote control is designed to function immediately after battery installation, requiring no additional programming for compatible ceiling fans.

### OPERATING INSTRUCTIONS

---

The ZWP Replacement Remote Control features an ergonomic design with soft silicon buttons for comfortable and reliable operation. It operates at an effective distance of up to 8 meters.



Image: Front view of the ZWP Replacement Remote Control, displaying its layout and various function buttons.



OPERATIONAL DISTANCE: 8 METERS  
long distance remote control

Image: The remote control in a bedroom setting, demonstrating its operational range of up to 8 meters when controlling a ceiling fan.

## Button Functions




Image: A detailed diagram highlighting the specific functions of each button on the remote control, including power, fan speed, light control, color temperature adjustment, and timer settings.

- **Power Button** (⏻): Turns the ceiling fan and light ON or OFF.
- **Fan Speed Button** (🌀): Adjusts the fan speed. Press repeatedly to cycle through available speeds.
- **Light ON/OFF Button** (💡): Turns the fan light ON or OFF.
- **CCT- / CCT+ Buttons**: Adjusts the Color Correlated Temperature (CCT) of the light, making it warmer or cooler.
- **Brightness Adjustment Buttons** (\* / \*): Increases or decreases the brightness of the light.
- **M Button**: Memory function or mode selection (specific function may vary by fan model).
- **Wind Mode Buttons** (≈): Cycles through different wind modes (e.g., natural breeze, sleep mode).
- **Timer Buttons (2h / 4h)**: Sets the fan to turn off automatically after 2 or 4 hours.
- **Night Mode Button** (☾): Activates a low-light or low-speed mode for nighttime use.

## MAINTENANCE

- **Cleaning**: Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.

- **Battery Replacement:** Replace batteries when the remote's operational range decreases or buttons become unresponsive. Always replace both batteries simultaneously with new AAA batteries.
- **Storage:** If the remote control will not be used for an extended period, remove the batteries to prevent leakage and damage.
- **Environmental Protection:** The remote is made of high-quality ABS material with soft silicon buttons, designed for durability and user comfort.



Image: A close-up view emphasizing the construction materials of the remote control, specifically the ABS body and soft silicon buttons, which contribute to its ergonomic feel and durability.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Remote control not responding.	<ul style="list-style-type: none"> <li>◦ Dead or incorrectly inserted batteries.</li> <li>◦ Remote is out of range.</li> <li>◦ Obstruction between remote and fan receiver.</li> </ul>	<ul style="list-style-type: none"> <li>◦ Replace batteries with new AAA batteries, ensuring correct polarity.</li> <li>◦ Move closer to the ceiling fan (within 8 meters).</li> <li>◦ Remove any objects blocking the signal path.</li> </ul>
Intermittent response.	<ul style="list-style-type: none"> <li>◦ Low battery power.</li> <li>◦ Interference from other electronic devices.</li> </ul>	<ul style="list-style-type: none"> <li>◦ Replace batteries.</li> <li>◦ Ensure no strong signal-emitting devices are near the fan receiver.</li> </ul>
Remote works for some functions but not others.	<ul style="list-style-type: none"> <li>◦ Compatibility issue with specific fan model features.</li> </ul>	<ul style="list-style-type: none"> <li>◦ Verify your ceiling fan model is listed as compatible. Not all fan models support every remote function.</li> </ul>

If you encounter issues not covered here, please refer to the support information provided by the seller or your ceiling fan manufacturer.

## SPECIFICATIONS

<b>Brand</b>	ZWP
<b>Model</b>	Replacement Remote Control (Compatible with LITTARBY 783798488341, 783798488358, AURALK FS001, OSTIVE QF-259A)
<b>Material</b>	High-quality ABS with Soft Silicon Buttons
<b>Color</b>	White
<b>Power Source</b>	2 x AAA Batteries (not included)
<b>Operational Distance</b>	Up to 8 meters
<b>Item Weight</b>	2.08 ounces (approx. 59 grams)
<b>Package Dimensions</b>	7.4 x 2.5 x 1.1 inches (approx. 18.8 x 6.35 x 2.8 cm)
<b>Special Feature</b>	Ergonomic Design
<b>Max Supported Devices</b>	1 (Ceiling Fan)

## SUPPORT AND CONTACT

For any questions or assistance regarding your ZWP Replacement Remote Control, please contact the seller directly through the platform where the purchase was made. Providing your order details will help expedite the support process. The manufacturer is ZWP.



ZWP Replacement Remote Control User Manual. All rights reserved.