

PD22.5W 50000mAh

Generic PD22.5W 50000mAh Power Bank User Manual

Model: PD22.5W 50000mAh

1. PRODUCT OVERVIEW

The Generic PD22.5W 50000mAh Power Bank is a portable charging solution designed to keep your electronic devices powered on the go. It features a high-capacity battery, fast charging technology, a digital LED display for battery status, and an integrated flashlight. This power bank is compatible with a wide range of Android and iOS devices.

Key Features:

- Massive 50000mAh Capacity:** Provides extended power for multiple charges.
- PD22.5W Fast Charging:** Supports rapid charging for compatible devices.
- Digital LED Display:** Clearly shows the remaining battery level.
- Integrated Flashlight:** Offers illumination for emergency situations.
- Universal Compatibility:** Works with both Android and iOS smartphones and tablets.
- Multiple Output Ports:** Includes various ports and built-in cables for diverse device connections.
- Portable Design:** Compact construction with a convenient carrying strap.

POWER BANK 50000 MAH

ESPECIFICAÇÕES

ALTA CAPACIDADE

POTENCIA 22.5W

CABOS EMBUTIDOS

MULTIPLAS ENTRADAS

ALTA CAPACIDADE

LANTERNA



Figure 1.1: Front view of the Power Bank, illustrating its digital display and key features such as high capacity, 22.5W power delivery, built-in cables, multiple input/output options, and integrated flashlight.

2. PACKAGE CONTENTS

Please check the package contents upon unboxing. If any items are missing or damaged, contact your retailer.

- Generic PD22.5W 50000mAh Power Bank
- User Manual (this document)

3. SETUP

3.1 Initial Charging of the Power Bank

1. Before first use, fully charge the power bank.
2. Connect the power bank to a suitable USB wall adapter (not included) using one of its built-in input cables (USB-C

or Lightning) or an external USB cable via the USB-C port.

3. The digital LED display will show the charging progress. It is fully charged when the display shows "100%".

Note: For optimal charging speed, use a PD (Power Delivery) compatible wall adapter.

4. OPERATING INSTRUCTIONS

4.1 Charging Your Devices

The power bank offers multiple ways to charge your devices:

- **Using Built-in Cables:**

- Identify the appropriate built-in cable (USB-C or Lightning) for your device.
- Connect the built-in cable directly to your device's charging port.

- **Using External Cables and USB Ports:**

- Connect your device's charging cable to one of the available USB-A output ports or the USB-C output port on the power bank.
- Connect the other end of the cable to your device.

Charging will begin automatically. The LED display will show the power bank's remaining battery level.

POWER BANK 50000 MAH

ESPECIFICAÇÕES DAS PORTAS



4 PORTAS USB-A
CARREGAR DISPOSITIVOS

1 PORTAS USB-C
PARA CARREGAR
POWER BANK / DISPOSITIVOS

1 PORTAS LIGHTNING
PARA CARREGAR
POWER BANK / DISPOSITIVOS

2 CABOS EMBUTIDOS
TIPO-C
LIGHTNING

Figure 4.1: Detailed view of the Power Bank's ports, including four USB-A ports, one USB-C port, one Lightning port, and two integrated cables (Type-C and Lightning) for versatile device charging.

4.2 Using the LED Display

The integrated digital LED display shows the current battery percentage of the power bank. This allows you to monitor the remaining charge and know when to recharge the power bank.

4.3 Using the Flashlight

The power bank includes a built-in LED flashlight for convenience.

- To turn on the flashlight: Press and hold the power button for approximately 3 seconds.
- To turn off the flashlight: Press and hold the power button again for approximately 3 seconds.

POWER BANK 50000 MAH

→
BENEFICIOS



**MULTIPLAS
PORTAS**



LANTERNA



**CABOS
EMBUTIDOS**



**ALÇA DE
SEGURANÇA**

Figure 4.2: Overview of the Power Bank's features, including its multiple ports, integrated flashlight, built-in charging cables, and a practical carrying strap.

5. MAINTENANCE

5.1 Cleaning

- Wipe the power bank with a soft, dry cloth.
- Do not use harsh chemicals, abrasive cleaners, or immerse the device in water.

5.2 Storage

- Store the power bank in a cool, dry place away from direct sunlight and extreme temperatures.
- For long-term storage, it is recommended to charge the power bank to approximately 50-70% every three months to maintain battery health.

5.3 Battery Care

- Avoid fully discharging the power bank frequently.
- Do not expose the power bank to fire or dispose of it in regular waste. Follow local regulations for battery disposal.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Power bank not charging	Charging cable is faulty or not properly connected. Wall adapter is not working or insufficient. Power bank is fully charged.	Check cable connections; try a different cable. Try a different wall adapter. Check the LED display for battery level.
Device not charging from power bank	Power bank battery is depleted. Device charging cable is faulty or not properly connected. Device is incompatible.	Recharge the power bank. Check cable connections; try a different cable or port. Ensure your device is compatible with USB charging.
Flashlight not working	Power bank battery is too low. Incorrect operation.	Recharge the power bank. Ensure you are pressing and holding the power button for the correct duration (approx. 3 seconds).

7. SPECIFICATIONS

Model	PD22.5W 50000mAh Power Bank
Brand	Generic
Battery Capacity	50000mAh
Fast Charging Technology	PD22.5W
Input Ports	USB-C (also output), Built-in USB-C, Built-in Lightning
Output Ports	4 x USB-A, 1 x USB-C, 1 x Lightning, Built-in USB-C, Built-in Lightning
Special Features	Digital LED Display, Built-in LED Flashlight, Carrying Strap
Compatibility	Android and iOS devices
Dimensions (H x W x D)	15 x 7 x 7 cm (approximate product dimensions)
Weight	1 kg
Power Source	Battery (1 x 12V battery included)

POWER BANK 50000 MAH

MEDIDAS & PESO



Figure 7.1: Physical dimensions and weight of the Power Bank. The image indicates a height of 15cm, width of 7cm, and a weight of 1kg.

8. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation provided at the time of purchase or contact your retailer directly. As this is a generic product, specific warranty terms may vary by seller.