Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Aqua Vista 26-K82CS-CH-AV

Aqua Vista 26-K82CS-CH-AV Two Handle Kitchen Sink Faucet with Side Spray, Polished Chrome Round Knobs

Brand: Aqua Vista
Model: 26-K82CS-CH-AV

Introduction

The Aqua Vista 26-K82CS-CH-AV Two Handle Kitchen Sink Faucet with Side Spray is designed to provide reliable water control and convenient functionality for your kitchen. This manual provides essential information for the proper setup, operation, and maintenance of your new faucet.
The faucet features a polished chrome finish, two clear acrylic knob handles for precise temperature control, and a handy side sprayer.

Safety Information

General Safety Precautions

- Always turn off the main water supply before beginning any installation or maintenance.
- Wear appropriate personal protective equipment (PPE) such as safety glasses and gloves during installation.
- Ensure all connections are secure to prevent leaks.
- If you are unsure about any step, consult a qualified plumber.
- This product is designed for kitchen sink use only.
- Ensure the product is installed in accordance with all local plumbing and building codes.

Package Contents

Please verify that all components are present before beginning installation.

- Kitchen Faucet Assembly (Main body with two handles)
- Side Spray Nozzle
- Deck Plate (if applicable for 4-hole installation)
- Mounting Hardware
- Installation Instructions (refer to the included PDF for detailed steps)



Image: Aqua Vista 26-K82CS-CH-AV Kitchen Faucet with side spray and round knobs.

Setup and Installation

For detailed, step-by-step installation instructions, please refer to the official Installation Manual PDF provided by Aqua Vista. A link to this document is available on the product's Amazon page.

Key Installation Notes:

- This faucet is designed for installation on 3-hole, 8-inch widespread sinks, with a 4th hole required for the side spray.
- A deck plate is included for installations on 4-hole sinks.
- The faucet features brass shanks for easy and secure installation.
- Ensure all water lines are properly connected and tightened to prevent leaks.



Image: Detailed dimensions of the faucet and side spray for installation planning.



Image: The Aqua Vista faucet and side spray installed on a kitchen sink.

Operating Instructions

Water Flow Control

The Aqua Vista faucet features two clear acrylic knob handles for controlling water temperature and flow.

- Turn the **left knob** counter-clockwise for hot water.
- Turn the **right knob** counter-clockwise for cold water.
- Adjust both knobs to achieve your desired water temperature and flow rate.
- The faucet has a maximum flow rate of 1.8 Gallons Per Minute (GPM), designed to conserve water while providing effective performance.

Side Spray Operation

The included side spray nozzle simplifies tasks such as washing dishes, pots, pans, and clearing the sink.

- Ensure the main faucet handles are turned on to allow water flow to the side spray.
- Press the lever or button on the side spray nozzle to activate the spray function.
- Release the lever or button to stop the spray.



Image: The faucet's two handles and side spray nozzle.

Maintenance

Cleaning the Faucet

To maintain the polished chrome finish and ensure longevity, follow these cleaning guidelines:

- Clean regularly with a soft, damp cloth and mild soap.
- Avoid abrasive cleaners, harsh chemicals, or scouring pads, as these can damage the finish.
- Rinse thoroughly with clean water after cleaning and dry with a soft cloth to prevent water spots.

Washerless Cartridge System

This faucet is equipped with a washerless cartridge system designed to prevent water dripping. If you experience persistent dripping, it may indicate an issue with the cartridge or debris in the water lines. Consult the troubleshooting section or a professional plumber.

Troubleshooting

Problem	Possible Cause	Solution
Faucet drips or leaks from spout.	Debris in cartridge, worn cartridge, or improper installation.	Ensure handles are fully closed. Flush water lines. If dripping persists, the cartridge may need cleaning or replacement. Consult a plumber if necessary.
Low water pressure from faucet.	Aerator clogged, water supply partially closed, or plumbing issue.	Remove and clean the aerator at the end of the spout. Check that both hot and cold water supply valves are fully open. Consult a plumber if the issue persists.
Side spray not working or low pressure.	Main faucet not on, spray head clogged, or hose kinked.	Ensure main faucet handles are open. Check side spray nozzle for clogs and clean if necessary. Ensure the spray hose is not kinked under the sink.
Water spraying from sides of nozzle.	Defect in threads or improper connection of aerator/spout.	Check if the aerator is securely tightened. If the issue persists and appears to be a manufacturing defect, contact Aqua Vista customer support.

Specifications

Feature	Detail
Brand	Aqua Vista
Model Number	26-K82CS-CH-AV
Color	Polished Chrome Round Knobs
Finish Type	Chrome
Material	Brass (faucet body), Acrylic (handles)
Mounting Type	Deck Mount
Number of Handles	2
Handle Type	Knob
Hole Count	4 (for faucet and side spray)
Maximum Flow Rate	1.8 Gallons Per Minute
Special Feature	Lead Free
Included Components	Two Handle Kitchen Faucet with Side Spray
Item Weight	2.59 pounds (1.18 Kilograms)
Product Dimensions	15.35 x 9.06 x 2.36 inches

Feature	Detail
UPC	820633003687
Manufacturer	Homewerks Worldwide, LLC.

Warranty and Support

Warranty Information

The Aqua Vista 26-K82CS-CH-AV Kitchen Faucet comes with a**Limited Lifetime Warranty**. Please refer to the warranty documentation included with your purchase or contact Aqua Vista customer support for full details regarding coverage and terms.

Customer Support

For technical assistance, replacement parts, or warranty claims, please contact Homewerks Worldwide, LLC. customer support. Contact information can typically be found on the manufacturer's website or on the product packaging.
You can also visit the official Aqua Vista store on Amazon for more product information and support resources:Aqua Vista Store

© 2024 Aqua Vista. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FDH3FLQ6

More documents and user manuals: **https://manuals.plus/**