

[Manuals.plus](#) /

› [Mingdaln](#) /

› Mingdaln Smartwatch I130 User Manual - Android & iPhone Compatible

Mingdaln I130

Mingdaln Smartwatch I130 User Manual

For Android and iPhone Devices

1. INTRODUCTION

Thank you for choosing the Mingdaln Smartwatch I130. This manual provides detailed instructions on how to set up, operate, and maintain your new smartwatch. Please read this manual thoroughly before using the device to ensure proper function and longevity.

2. PACKAGE CONTENTS

Please verify that all items are present in your package:

- Mingdaln Smartwatch I130 (Black)
- Charging Cable
- User Manual

3. PRODUCT OVERVIEW

Familiarize yourself with the components and controls of your Mingdaln Smartwatch I130.



Image 3.1: Mingdalu Smartwatch I130. The main display shows the time as 10:06:09, battery percentage (50%), and step count (10349). The watch features a robust design with 'POWER', 'SPORT', 'OPEN', and 'BACK' labels around the bezel, indicating button functions. The strap is black with an orange underside. An inset image displays the watch's dialer interface for making calls.

3.1 Watch Components

- **Display:** 1.85-inch touchscreen for interaction and information display.
- **Power Button:** Typically used to turn the watch on/off, wake/sleep the screen, or return to the home screen. (Labeled 'POWER' on bezel)
- **Sport Button:** Quick access to sport modes or fitness tracking features. (Labeled 'SPORT' on bezel)
- **Open Button:** May function as a customizable shortcut or app launcher. (Labeled 'OPEN' on bezel)
- **Back Button:** Used to navigate back in menus or exit applications. (Labeled 'BACK' on bezel)
- **Sensors:** Located on the rear of the watch for activity tracking and health monitoring.
- **Charging Contacts:** Magnetic contacts for connecting the charging cable.

4. SETUP

4.1 Charging the Smartwatch

1. Connect the charging cable to a USB power adapter (not included) or a computer's USB port.
2. Align the magnetic end of the charging cable with the charging contacts on the back of the smartwatch. The cable will snap into place.
3. The watch display will indicate charging status. Ensure the watch is fully charged before first use.

4.2 Pairing with Your Smartphone

To utilize all features, the smartwatch must be paired with your smartphone via Bluetooth.

1. **Download the Companion App:** Search for the official Mingdaln companion app in your smartphone's app store (Google Play Store for Android, Apple App Store for iPhone). Install the app.
2. **Enable Bluetooth:** Ensure Bluetooth is enabled on your smartphone.
3. **Open the App:** Launch the companion app on your smartphone and follow the on-screen instructions to create an account or log in.
4. **Add Device:** Within the app, navigate to the 'Add Device' or 'Pair Device' section.
5. **Select Your Smartwatch:** The app will scan for nearby devices. Select 'Mingdaln I130' or a similar identifier from the list.
6. **Confirm Pairing:** A pairing request may appear on both your phone and the smartwatch. Confirm the pairing on both devices.
7. **Complete Setup:** Follow any remaining prompts in the app to complete the setup, including granting necessary permissions for notifications, health data, etc.

5. OPERATING INSTRUCTIONS

5.1 Basic Navigation

- **Touchscreen:** Swipe left/right, up/down to navigate through menus and widgets. Tap to select an item.
- **Power Button:** Press to wake the screen or return to the watch face. Press and hold to power on/off.
- **Back Button:** Press to go back to the previous screen.

5.2 Making and Answering Calls

Once paired with your smartphone, the Mingdaln I130 allows you to manage calls directly from your wrist.

- **Answering Calls:** When an incoming call is received, the watch will display the caller ID. Tap the green phone icon on the screen to answer.
- **Making Calls:** Access the dialer function on the smartwatch (as shown in Image 3.1) to dial a number directly, or select a contact from your synced phonebook.

5.3 Sport Modes and Activity Tracking

The smartwatch features over 100 sport modes and comprehensive activity tracking.

- **Accessing Sport Modes:** Press the 'SPORT' button or navigate through the app menu to find the list of available sport modes. Select your desired activity to begin tracking.
- **Activity Tracking:** The watch continuously monitors steps, distance, calories burned, and sleep patterns. View your daily and historical data in the companion app.

5.4 Notifications

Receive notifications from your smartphone directly on your smartwatch. Ensure notification permissions are granted in the companion app.

6. MAINTENANCE

6.1 Cleaning

- Wipe the watch screen and body with a soft, lint-free cloth.
- For stubborn dirt, slightly dampen the cloth with water. Avoid using harsh chemicals or abrasive materials.

- Clean the charging contacts regularly to ensure efficient charging.

6.2 Water Resistance (IP68)

The Mingdaln I130 is rated IP68, meaning it is resistant to dust and can withstand immersion in water up to 1.5 meters for up to 30 minutes. While it is suitable for daily use, hand washing, and light rain, it is not recommended for swimming, diving, or exposure to high-pressure water jets.

- Do not expose the watch to hot water, steam, or corrosive liquids.
- After exposure to water, dry the watch thoroughly before charging.

7. TROUBLESHOOTING

If you encounter issues with your smartwatch, refer to the following common solutions:

- **Watch not turning on:** Ensure the watch is fully charged. Connect it to the charger for at least 30 minutes.
- **Cannot pair with phone:**
 - Ensure Bluetooth is enabled on your phone and the watch.
 - Make sure the watch is within range of your phone.
 - Restart both the watch and your phone.
 - Clear Bluetooth cache on your phone (Android) or forget the device and re-pair (iPhone).
- **Notifications not received:**
 - Check app permissions on your phone to ensure the companion app has access to notifications.
 - Verify that notification settings are enabled within the companion app.
 - Ensure the watch is properly connected to your phone.
- **Inaccurate activity data:** Ensure the watch is worn snugly on your wrist, not too loose or too tight.

8. SPECIFICATIONS

Feature	Detail
Model Number	I130
Brand	Mingdaln
Display Size	1.85 Inches
Operating System	Wear OS 1.1
Special Feature	Activity Tracker
GPS	No GPS
Color	Black
Compatible Devices	Smartphone (Android and iPhone)
Water Resistance	IP68
UPC	607601920296
Manufacturer	Mingdaln

Date First Available

June 18, 2025

9. WARRANTY AND SUPPORT

For warranty information, technical support, or service inquiries, please refer to the warranty card included with your product or contact Mingdaln customer service through their official website or the companion app. Please have your model number (I130) and proof of purchase ready when contacting support.

© 2025 Mingdaln. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question