



Manuals.plus /

› AMACOOOL /

› AMACOOOL F320S 10000mAh Magnetic Portable Fan Instruction Manual

AMACOOOL F320S

AMACOOOL F320S 10000mAh Magnetic Portable Fan Instruction Manual

Model: F320S | Brand: AMACOOOL

1. PRODUCT OVERVIEW

The AMACOOOL F320S is a versatile 10000mAh magnetic portable fan designed for various environments, including cruises, golf carts, camping, and home use. It features a powerful magnetic base, a foldable hook, 360-degree rotation, three fan speeds, and a multi-level LED light, ensuring comfort and convenience wherever you go.



Image 1: The AMACOOOL F320S Magnetic Portable Fan in its compact form.

2. KEY FEATURES

- **10000mAh Rechargeable Battery:** Provides 8-35 hours of operation depending on fan speed, making it ideal for extended use without frequent recharging. The battery is flight-approved for travel.
- **Strong Magnetic Base:** Equipped with 8 heavy-duty N52 magnets for secure attachment to metal surfaces like cruise cabin walls, golf cart frames, or kitchen appliances.
- **360° Rotation:** The fan head can be rotated 360 degrees horizontally and vertically, allowing for precise airflow direction.
- **3 Fan Speeds:** Choose from low, medium, or high fan speeds to suit your cooling needs.
- **3-Level LED Light:** Integrated white work light with three brightness settings, useful for various tasks or as a night light.
- **Versatile Hanging Hook:** A foldable hook on the base allows for convenient hanging in tents, on branches, or other suitable locations.
- **Compact and Portable:** Measuring 7.17 × 2.56 × 8.66 inches and weighing 1.04 lbs, it's easy to pack and carry.

Cruise-Approved Magnetic Fan

Magnetically attached to cruise cabin walls



8 Heavy-duty N52
magnets, super strong
magnetism

Image 2: Illustration of the magnetic base with N52 magnets and 360-degree rotation capability.

10000mAh Rechargeable Battery

Power Beyond Your Golf Round



Image 3: The fan attached to a golf cart, highlighting its 10000mAh battery life across different speeds (35H on Speed 1, 13H on Speed 2, 8H on Speed 3).


Powerful 3 Speeds

360° rotation to any angle



Image 4: The fan demonstrating its powerful 3 speeds and 360-degree rotation, shown standing and hanging inside a camping tent.

Smooth White Noise for Sleeping



3-level white light



Image 5: The fan providing smooth white noise and 3-level white light for sleeping or relaxation.

All-in-One Travel Fan

Magnet, Hang, Stand. Fits any cooling needs



Image 6: The fan's versatile usage options: magnetically attached in a cruise cabin, on a golf cart, hanging in a camping tent, and standing on a desk.

3. SETUP

1. **Unboxing:** Carefully remove the fan and all accessories from the packaging. Verify that all components are present: the fan unit, USB-C charging cable, and user manual.
2. **Initial Charge:** Before first use, fully charge the fan using the provided USB-C cable. Connect the USB-C end to the fan's charging port (located on the side of the base) and the USB-A end to a compatible 5V power supply (e.g., power bank, laptop, wall adapter). The indicator light will flash red during charging and turn solid red when fully charged.
3. **Positioning:** Choose your desired mounting method:
 - **Desktop/Tabletop:** Place the fan on a flat, stable surface. Adjust the fan head to your preferred angle.
 - **Magnetic Mount:** Attach the magnetic base firmly to any suitable metal surface. Ensure the surface is clean and dry for optimal adhesion.
 - **Hanging:** Extend the foldable hook from the base and hang the fan from a secure point.
 - **Wall Mount:** Use the keyhole slot on the back of the base to hang the fan on a screw or nail (not

included) on a wall.

Your browser does not support the video tag.

Video 1: This video demonstrates the unboxing and various setup options for the magnetic rechargeable travel fan, including its magnetic base and hanging hook.

4. OPERATING INSTRUCTIONS

4.1 Fan Control

1. **Power On/Speed 1:** Press the 'FAN' button once to turn on the fan at low speed (Speed 1).
2. **Speed 2:** Press the 'FAN' button a second time for medium speed (Speed 2).
3. **Speed 3:** Press the 'FAN' button a third time for high speed (Speed 3).
4. **Power Off:** Press the 'FAN' button a fourth time to turn off the fan.

4.2 Light Control

1. **Light On/Brightness 1:** Press the 'LED' button once to turn on the light at the lowest brightness setting.
2. **Brightness 2:** Press the 'LED' button a second time for medium brightness.
3. **Brightness 3:** Press the 'LED' button a third time for the brightest setting.
4. **Light Off:** Press the 'LED' button a fourth time to turn off the light.

5. MAINTENANCE

- **Cleaning:** Turn off the fan and unplug it before cleaning. Use a soft, dry cloth to wipe the fan body and blades. Do not use harsh chemicals, abrasive cleaners, or corrosive liquids.
- **Storage:** If not in use for an extended period, fully charge the battery and store the fan in a cool, dry place.
- **Battery Care:** To prolong battery life, avoid completely draining the battery frequently. Recharge when the power is low.
- **Disassembly:** Do not attempt to disassemble or repair the fan yourself. Contact professional staff for any repairs.

6. TROUBLESHOOTING

Fault Phenomenon	Cause of the Problem	Elimination Method
No power/light	The battery is too low or the charging wire is not inserted.	Charge the fan or check the connector/charging cable.
The charging time is too long or not charged.	The charger current is less than 2A or the charging cable is damaged.	Change the charger or switch to a charging line.

7. SPECIFICATIONS

Parameter	Value
Model Number	F320S
Brand	AMACOOOL
Output Power	6 W
Input Voltage	DC 5V
Input Current	1.5 A
Output Voltage	5V-14V
Battery Capacity	10000mAh
Product Dimensions	2.56"D x 7.17"W x 8.66"H
Item Weight	600 Grams (1.32 lbs)
Number of Speeds	3
Special Feature	Magnetic, LED Light, Foldable Hook
Mounting Type	Wall Mount/Desktop/Hook Mount
Material	Plastic
Indoor/Outdoor Usage	Indoor, Outdoor

8. WARRANTY AND SUPPORT

Respect of customer, thank you for choosing our company's products. In order to better service for you, after buying the product, please read carefully, complete and properly keep the warranty card.

For support or warranty claims, please contact AMACOOOL directly:

- **Online/Email:** <https://amacool.vip/Contactus> or support@amacool.vip



Image 7: QR code for contacting AMACOOOL support.