Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Conyat X7

Conyat X7 Open Ear Headphones User Manual

Model: X7

Introduction

This manual provides detailed instructions for the proper use and maintenance of your Conyat X7 Open Ear Headphones. Please read this manual thoroughly before using the product to ensure optimal performance and longevity.

Package Contents

Verify that all items are present in your package:

- 2 x Conyat X7 Wireless Earbuds
- 1 x Fast Charging Case
- 1 x USB-C Charging Cable
- 1 x User Manual



Image: The Conyat X7 Open Ear Headphones, charging case, USB-C cable, and user manual laid out, illustrating the package contents.

Setup

1. Initial Charging

Before first use, fully charge the earbuds and the charging case.

1. Place the earbuds into the charging case.
2. Connect the USB-C charging cable to the charging port on the case and to a power source.
3. The digital display on the case will show the battery level. A full charge takes approximately 2 hours.



Image: The charging case with earbuds, connected via USB-C, displaying the battery percentage on its LED screen.

2. Wearing the Earbuds

The Conyat X7 headphones feature an open-ear design with ear hooks for a secure and comfortable fit.

1. Take out the headphones and unfold the ear hooks to their maximum angle.
2. Slide the ear hook behind your ear.
3. Adjust the earbuds to sit firmly and comfortably in front of your ear canal.




Image: A visual guide demonstrating the three steps for correctly wearing the open-ear headphones, ensuring a secure and comfortable fit.

3. Bluetooth Pairing

The earbuds automatically enter pairing mode when removed from the charging case.

1. Open the charging case and remove both earbuds. They will automatically power on and connect to each other.

2. On your device (smartphone, tablet, laptop), enable Bluetooth.
3. Search for "X7" in the list of available Bluetooth devices and select it to pair.
4. Once paired, the earbuds will automatically reconnect to your last paired device when removed from the case.



Image: A visual representation of the one-step pairing process, showing the earbuds and charging case alongside a smartphone displaying the Bluetooth connection menu with "X7" selected.

Operating Instructions

The Conyat X7 earbuds feature touch controls for various functions.

Touch Control Functions

Function	Action	Earbud
Answer Call	One-Tap	Left (L) or Right (R)
Hang Up / Refuse Incoming Call	Long Tap (2 seconds)	Left (L) or Right (R)
Volume +	One-Tap	Right (R)
Volume -	One-Tap	Left (L)
Play/Pause Music	Twice-Tap	Left (L) or Right (R)
Previous Track	Long Tap (2 seconds)	Left (L)
Next Track	Long Tap (2 seconds)	Right (R)
Voice Assistant	Triple-Tap	Left (L) or Right (R)



Image: A visual guide detailing the touch control gestures for managing calls, music playback, and activating the voice assistant on the earbuds.

Maintenance

Proper maintenance ensures the longevity and performance of your Conyat X7 headphones.

- **Cleaning:** Use a soft, dry, lint-free cloth to clean the earbuds and charging case. Do not use abrasive cleaners or solvents. The earbuds are IP7 waterproof, meaning they can withstand sweat and splashes, but should not be submerged in water.
- **Storage:** When not in use, store the earbuds in their charging case to protect them and keep them charged. Store in a cool, dry place away from extreme temperatures.
- **Battery Care:** To preserve battery life, avoid fully discharging the earbuds and charging case frequently. Charge them regularly, even if not in constant use.



Image: The earbuds shown with water splashing on them, highlighting their IP7 waterproof and sweatproof capabilities for active use.

Troubleshooting

If you encounter issues with your Conyat X7 headphones, refer to the following common solutions:

- **Earbuds not pairing with each other:**

  Ensure both earbuds are fully charged. Place them back in the charging case, close the lid, then open it and remove

them again. They should automatically connect.

- **Earbuds not connecting to device:**

  Make sure Bluetooth is enabled on your device. Forget "X7" from your device's Bluetooth list and attempt to pair again. Ensure the earbuds are charged and out of the case.

- **No sound or low volume:**

  Check the volume levels on both your device and the earbuds. Ensure the earbuds are properly seated in your ears. Confirm they are connected to the correct device.

- **Charging case not charging:**

  Verify the USB-C cable is securely connected to both the case and the power source. Try a different USB-C cable or power adapter.

- **Earbuds falling out:**

  Ensure the ear hooks are unfolded and adjusted correctly behind your ears, as described in the "Wearing the Earbuds" section.

Specifications

Conyat X7 Open Ear Headphones Specifications

Feature	Detail
Model Name	X7
Connectivity Technology	Wireless (Bluetooth 5.4)
Bluetooth Version	5.4
Bluetooth Range	15 Meters
Audio Driver Type	14.2mm Dynamic Driver
Ear Placement	Open Ear
Form Factor	Over Ear (with ear hooks)
Control Type	Touch Control
Battery Life (Earbuds)	Up to 8 hours on a single charge
Total Playtime (with Charging Case)	Up to 58 hours
Charging Time	Approx. 2 hours (for case)
Charging Port	USB-C
Water Resistance Level	IP7 Waterproof
Item Weight (Earbuds)	Approx. 10g per earbud
Dimensions (Product)	1.97 x 1.57 x 2.36 inches
Manufacturer	Conyat

Warranty and Support

Conyat products are designed for reliability and performance. We offer the following:

- **12-Month Quality Guarantee:** Your Conyat X7 headphones are covered by a 12-month quality guarantee from the date of purchase. This covers manufacturing defects.
- **30-Day Worry-Free Trial:** Enjoy a 30-day trial period to ensure complete satisfaction with your purchase.
- **24-Hour Customer Service:** For any questions, concerns, or support needs, please contact our customer service team. Refer to the product packaging or the official Conyat website for contact details.

24 Hour Customer Service

Assistance available around the clock.

30 Day Worry-Free Trial

Satisfaction guaranteed or your money back.

12 Month Quality Guarantee

Coverage for manufacturing defects.




Image: Conyat's commitment to customer satisfaction, including support, trial period, and warranty.

© 2025 Conyat. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FDKFH949

More documents and user manuals: **https://manuals.plus/**