

[Manuals.plus](#) /

› [Akxomel](#) /

› Akxomel 31.5" W Fluted Shoe Storage Cabinet User Manual

Akxomel 602H

Akxomel 31.5" W Fluted Shoe Storage Cabinet User Manual

Model: 602H

1. INTRODUCTION

Thank you for choosing the Akxomel 31.5" W Fluted Shoe Storage Cabinet. This manual provides essential information for the safe assembly, operation, and maintenance of your new shoe cabinet. Please read these instructions carefully before beginning assembly and retain them for future reference.

2. SAFETY INFORMATION

WARNING: Failure to follow these safety instructions could result in injury or damage to the product.

- Always ensure the cabinet is securely mounted to the wall using the provided anti-tip kit to prevent tipping, especially in households with children or pets.
- Be cautious when assembling the cabinet to avoid injury from tools or heavy components. It is recommended to assemble with two people.
- Always follow the manufacturer's instructions for safe installation and use.
- Do not exceed the weight limit of 11 pounds (5 kg) for the top surface.
- Keep small parts and packaging materials away from children.

3. PACKAGE CONTENTS

Before assembly, verify that all components listed below are present and undamaged. If any parts are missing or damaged, please contact customer support.

- 1 x Akxomel 31.5" W Fluted Shoe Storage Cabinet (disassembled components)

- Assembly Hardware (screws, dowels, connectors)
- Anti-tip kit
- Assembly Instructions Manual



Image: Front view of the assembled Akxomel 31.5" W Fluted Shoe Storage Cabinet in Natural Oak, featuring two flip-down drawers and an open bottom shelf, with black metal legs and side hooks.

4. ASSEMBLY INSTRUCTIONS

Assembly is required for this product. It is recommended to have two people for easier and safer assembly. All necessary hardware is included.

1. **Unpack Components:** Carefully remove all parts from the packaging. Lay them out on a clean, soft surface to prevent scratches.
2. **Identify Parts:** Refer to the included parts list and diagrams to identify each component.
3. **Assemble Frame:** Follow the step-by-step diagrams to connect the main frame pieces using the provided hardware. Ensure all connections are secure.
4. **Install Flip Drawers:** Attach the flip-down drawer mechanisms and drawer fronts. Ensure they open and close smoothly.
5. **Insert Shelves:** Place the adjustable shelves inside the flip drawers. These shelves can be removed or repositioned as needed.
6. **Attach Metal Legs:** Securely fasten the metal legs to the base of the cabinet.
7. **Install Side Hooks:** Attach the hooks to the sides of the cabinet for additional storage.
8. **Secure Anti-Tip Kit:** For safety, attach the anti-tip device to the back of the cabinet and secure it to a wall stud according to the instructions provided with the kit.



Anti-tip kit

Image: Top-down view of the shoe cabinet showing shoes stored in the flip drawers and an inset detail of the anti-tip kit attachment point on the cabinet's top edge.



Image: Close-up detail of the anti-tip bracket, designed to secure the cabinet to a wall for stability.

5. OPERATION

5.1 Storing Shoes

The cabinet features two flip-down drawers for shoe storage. Each drawer contains a removable shelf, allowing for flexible storage options.

- To open a drawer, gently pull the handle forward and down.
- Place shoes on the shelves. For optimal storage, men's shoes up to US size 10.5 and women's shoes up to US size 11.5, with a maximum length of 11.8 inches (30 cm), are recommended. Larger shoes may need to be placed at an angle or on the bottom open shelf.
- To close, push the drawer upwards until it clicks securely into place.



Image: The Akxomel shoe cabinet with its top flip-down drawer open, revealing multiple pairs of shoes neatly stored on the internal shelves. The bottom open shelf also holds shoes.

5.2 Adjusting/Removing Shelves

The internal shelves within the flip drawers are removable, allowing you to customize the storage space for different shoe types, such as boots or flats.

1. Open the desired flip drawer completely.
2. Carefully lift the shelf from its supports.
3. To reinsert, align the shelf with the desired support slots and gently push it down until it is secure.



Image: A diagram illustrating the process of removing an internal shelf from a flip-down drawer, with numbered steps indicating how to lift and detach the shelf for customized storage.

5.3 Using Side Hooks

The integrated hooks on both sides of the cabinet provide convenient storage for items such as bags, keys, or scarves.

6. MAINTENANCE

- **Cleaning:** Wipe the cabinet surfaces with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that could damage the finish.
- **Dusting:** Regularly dust the cabinet to maintain its appearance.
- **Hardware Check:** Periodically check all screws and connections to ensure they remain tight. Tighten if necessary.
- **Avoid Moisture:** Do not expose the cabinet to excessive moisture or direct sunlight, as this can cause warping or fading.

7. TROUBLESHOOTING

- **Drawers not closing properly:** Check for obstructions inside the drawer or ensure the internal shelf is correctly seated. Verify that the drawer mechanism is properly aligned.
- **Cabinet feels unstable:** Ensure the anti-tip kit is correctly installed and secured to a wall stud. Check that all assembly hardware is tightened.
- **Scratches or minor damage:** For minor blemishes, a furniture repair pen or wood filler matching the Natural Oak finish may be used.

8. SPECIFICATIONS

Brand	Akxomel
Model Number	602H
Color	Natural Oak
Product Dimensions (D x W x H)	9.4"D x 31.5"W x 41.3"H (24cm D x 80cm W x 105cm H)
Item Weight	40.9 Pounds (18.55 kg)
Weight Limit (Top Surface)	11 Pounds (5 kg)
Material	Engineered Wood, Metal (legs, handles)
Special Features	Adjustable Shelf, Anti-Tipping, Removable Shelf, Side Hooks
Assembly Required	Yes




Image: A detailed diagram illustrating the dimensions of the Akxomel shoe cabinet, including height, width, and depth, along with the weight limit for the top surface.

9. WARRANTY AND SUPPORT

Akxomel stands behind the quality of its products. For warranty information, replacement parts, or technical assistance, please contact Akxomel customer support through the retailer where the product was purchased or visit the official Akxomel website.

Please have your model number (602H) and purchase date available when contacting support.

