

[Manuals.plus](#) /

› [CS BATTERY](#) /

› CS BATTERY NP-SP70 Replacement Battery User Manual

CS BATTERY NP-SP70

CS BATTERY NP-SP70 Replacement Battery

USER MANUAL

1. Introduction and Overview

This manual provides essential instructions for the safe and effective use of your CS BATTERY NP-SP70 replacement battery. This battery is designed to be compatible with the following camera models:

- Bloggie MHS-TS20/K
- Bloggie MHS-TS20/L
- Bloggie MHS-TS20/S

Please read this manual thoroughly before using the battery to ensure optimal performance and safety.

2. Safety Information

WARNING: Failure to follow these safety instructions may result in fire, electric shock, injury, or damage to the product or property.

- **Do not disassemble:** Attempting to disassemble the battery may cause damage and is dangerous.
- **Avoid short-circuiting:** Do not short-circuit the battery terminals. This can lead to overheating and fire.
- **Proper disposal:** Do not dispose of the battery in fire. Dispose of used batteries according to local regulations.
- **Charging temperature:** Ensure the battery is charged within the recommended temperature range of 4°C to 40°C (40°F to 105°F).
- **Keep away from children:** Store the battery out of reach of children.
- **Avoid extreme conditions:** Do not expose the battery to extreme heat, direct sunlight, or very low temperatures.

Model No.: SP70

Replacement Battery

Li-ion Rechargeable Battery Pack

DC 3.7V 2.96Wh

800mAh

Takoci®



Completely Compatible With The Original Model
Made in China



CAUTION!



**Do not disassemble, short-circuit terminals, or dispose in fire.
Risk of fire and burns. Charging temperature is 40°F-105°F
Manufacturer by: Shenzhen Oubaishi Lighting Technology Co., Ltd.**

Image 1: Front view of the NP-SP70 battery, displaying specifications and critical safety warnings such as 'Do not disassemble, short-circuit terminals, or dispose in fire' and 'Charging temperature is 40°F-105°F'.

3. Setup

3.1 Initial Charging

Upon first use, the battery may be in a protective state. It requires a prolonged initial charge for activation. Please be patient and allow sufficient time for the battery to fully charge before its first use.

3.2 Battery Installation

1. Ensure your device is powered off before installing the battery.
2. Locate the battery compartment on your compatible Bloggie camera.
3. Insert the NP-SP70 battery into the compartment, ensuring the contacts align correctly.
4. Close the battery compartment cover securely.

4. Operating Instructions

4.1 Charging the Battery

Use the original charger or a compatible charger designed for your Bloggie camera to charge the NP-SP70 battery. Connect the charger to a power source and then to your camera with the battery installed. The charging indicator on your

camera will typically show the charging status.

4.2 Battery Usage

The NP-SP70 battery features a high capacity circulation function and no memory effect, allowing for flexible charging without significantly impacting its overall lifespan. Use the battery as you would your original camera battery.



Image 2: Back view of the NP-SP70 battery, showing the 'TAKOCl' branding.

5. Maintenance

- **Storage:** When not in use for extended periods, store the battery in a cool, dry place away from direct sunlight and extreme temperatures.
- **Cleaning:** If necessary, gently wipe the battery contacts with a clean, dry cloth to ensure good connection with your device.
- **Avoid full discharge:** While the battery has no memory effect, avoiding complete discharge before recharging can help prolong its overall life.

6. Troubleshooting

- **Device not powering on:** Ensure the battery is correctly installed and fully charged. Check if the battery contacts are clean.

- **Battery not charging:** Verify that the charger is properly connected to both the power source and the camera. Ensure the charging temperature is within the specified range (4°C to 40°C).
- **Reduced operating time:** If your device's operating time is significantly reduced even after a full charge, it may indicate that the battery has reached the end of its lifespan and requires replacement.

7. Specifications

Model Number	NP-SP70 (Compatible with 4-261-368-01)
Battery Type	Lithium-Ion
Voltage	3.7V
Capacity	800mAh / 2.96Wh
Dimensions (L x W x H)	40.12 x 34.00 x 6.72 mm (1.58 x 1.34 x 0.26 inches)
Weight	43g
Certifications	ROSH, CE, UL
Protection Features	Over-charge, Over-discharge, Over-heat, Over-current, Short-circuit protection

8. Warranty and Support

This CS BATTERY product comes with a one-year quality warranty policy, ensuring quality assurance for your purchase. If you encounter any issues or have questions regarding your battery, please contact the seller directly for support.

Please note that returns may not be applicable for unsatisfactory receipt of goods if the product is not defective. The warranty specifically covers quality-related issues.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0FDKJVP9P>

More documents and user manuals: <https://manuals.plus/>