

## Gaiatop BJ004-G006Pro Max

# Gaiatop Food Warming Mat: User Manual

Model: BJ004-G006Pro Max

## 1. INTRODUCTION

The Gaiatop Food Warming Mat is designed to keep your dishes at an ideal serving temperature. Featuring advanced heating technology, multiple temperature settings, and a convenient timer, this portable silicone mat is suitable for various occasions, from family dinners to outdoor events.



Image 1.1: The Gaiatop Food Warming Mat keeping multiple dishes warm during a family meal.

## 2. SAFETY INFORMATION

Please read all safety instructions carefully before using the Gaiatop Food Warming Mat. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Always place the warming mat on the included heat insulation mat to prevent countertop damage.
- Do not immerse the touch control panel in water. The silicone surface is waterproof, but the

control panel is not.

- Ensure the mat is unplugged and cooled before cleaning.
- Equipped with a child lock feature to prevent accidental changes to settings.
- Features overheat protection for enhanced safety and durability.
- Keep away from children and pets during operation.




Image 2.1: The control panel highlighting the child lock and other safety features.

### 3. PACKAGE CONTENTS

Verify that all items are present in the package:

- Gaiatop Food Warming Mat (1)

- Heat Insulating Pad (1)
- Storage Bag (1)
- Strap (1)
- Power Cable (71 inches / 180cm) (1)
- User Manual (1)

#### **4. SETUP**

1. Unroll the Gaiatop Food Warming Mat and the Heat Insulating Pad on a flat, stable surface.
2. Place the Heat Insulating Pad directly on your countertop or table.
3. Position the Food Warming Mat on top of the Heat Insulating Pad.
4. Connect the power cable to the designated port on the warming mat's control panel.
5. Plug the power cable into a standard 120V AC electrical outlet.



## Always Protect Your Table




Image 4.1: Illustration of the warming mat's raised feet and the protective heat insulating pad.

## 5. OPERATING INSTRUCTIONS

### 5.1 Power On/Off

- Press the 'Power' button on the control panel to turn the mat on or off.

### 5.2 Temperature Settings

The mat offers 7 precise temperature settings, ranging from 104°F (33°C) to 212°F (100°C).

- Use the '+' and '-' buttons to adjust the desired temperature.
- The current temperature will be displayed on the control panel.

# Tap into Max Performance



Image 5.1: Close-up of the control panel showing temperature adjustment buttons and display.

## 5.3 One-Touch Warming

For rapid heating to the maximum temperature (212°F), press the 'Warm Dishes' button. This intelligent heat system quickly brings food to optimal serving temperature.



Image 5.2: Visual representation of the one-touch warming function for quick heating.

#### 5.4 Timer Function

The built-in smart timer supports extended warming up to 8 hours.

- Press the 'Time' button to cycle through the available timer settings (1-8 hours).
- The mat will automatically shut off once the set time has elapsed.

#### 5.5 Child Lock

To prevent accidental changes to settings, activate the child lock:

- Press and hold the 'Lock' button for 2 seconds to engage or disengage the child lock.

#### 5.6 Full-Surface Heating

The mat features an upgraded, high-density heating wire covering the entire bottom surface, ensuring uniform and constant food warming without hot spots.



Image 5.3: Diagram showing the full-surface heating elements for even heat distribution.

#### 5.7 Compatible Tableware

The warming mat is compatible with diverse material tableware, including stainless steel pots, frying pans, porcelain dishes, enamelware, glass, milk bottles, and tin foil boxes.

# Supports Various Containers



- Stainless Steel Pot
- Frying Pan
- Milk Bottle
- Porcelain Dish
- Enamelware
- Glass

Image 5.4: The warming mat accommodating different types of food containers.

## 5.8 Multi-Functional Use

Beyond keeping food warm, the mat can be used for dough fermentation, defrosting, warming milk, and even warming masks.

## Support Various Tableware Containers




Image 5.5: Examples of the warming mat's versatile applications.

## 6. MAINTENANCE

### 6.1 Cleaning

- Ensure the mat is unplugged and completely cooled before cleaning.
- Wipe the food-grade silicone surface with a damp cloth.
- For stubborn stains, use a mild dish detergent.
- Do not immerse the control panel in water.

# Easy to Clean and Store



Image 6.1: Demonstrating the ease of cleaning the silicone surface.

## 6.2 Storage

The mat features a roll-up design for convenient storage.

- Once cooled and cleaned, roll up the mat and secure it with the provided strap.
- Store it in the included storage bag to protect it from dust and damage.



Image 6.2: The warming mat rolled up and ready for storage in its bag.

## 7. TROUBLESHOOTING

If you encounter any issues with your Gaiatop Food Warming Mat, please refer to the following common solutions:

- **Mat not heating:** Ensure the power cable is securely connected to both the mat and a working electrical outlet. Check if the 'Power' button is pressed and the desired temperature is set.
- **Uneven heating:** The mat is designed for full-surface heating. Ensure the mat is laid flat and not obstructed. If the issue persists, contact customer support.
- **Automatic shut-off before timer:** Check if the overheat protection has been triggered. Allow the mat to cool down before restarting.

For further assistance, please contact Gaiatop customer support.

## 8. SPECIFICATIONS

Feature	Detail
Brand	Gaiatop
Model Number	BJ004-G006Pro Max
Color	Blue
Material	Silicone
Product Dimensions	15"D x 23"W x 1"H (38.2 x 58.2 cm)
Wattage	330 watts
Voltage	120 Volts (AC)
Controls Type	Touch
Temperature Settings	7 levels (104°F to 212°F / 33°C to 100°C)
Timer	1-8 hours
Special Features	Innovative One Touch Warming, Heat Insulating Pad, Rapid Full-Surface Heating, Child Lock, Overheat Protection, Rollable Design
Item Weight	3.63 pounds

## 9. OFFICIAL PRODUCT VIDEOS

Watch these official videos from Gaiatop for more information on the Food Warming Mat:

### Gaiatop Food Warmers for Parties Buffet with Trivet

Your browser does not support the video tag.

*Video 9.1: This video demonstrates the Gaiatop Food Warming Mat in a buffet setting, showcasing its use with various dishes and the included trivet.*

### Innowarmer Electric Food Warming Mat for Parties Buffet

Your browser does not support the video tag.

*Video 9.2: This video highlights the features and benefits of the Innowarmer Electric Food Warming Mat, suitable for parties and buffets.*

## Food Warming Mat, Fast-Heating Silicone Electric Warming Tray

Your browser does not support the video tag.

*Video 9.3: A detailed overview of the fast-heating silicone electric warming tray, demonstrating its functionality and design.*

## 10. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the contact details provided in your product packaging or visit the official Gaiatop website. Our professional technical team and customer service support are available 24/7 to assist you with any questions.