

B-Qtech Mbc1080p

B-Qtech Mini Body Camera Mbc1080p User Manual

Model: Mbc1080p

INTRODUCTION

This manual provides detailed instructions for the B-Qtech Mbc1080p Mini Body Camera. Please read this manual carefully before using the device to ensure proper operation and to maximize its performance and lifespan. This compact, wearable camera is designed for hands-free video recording in various scenarios, offering high-definition capture and versatile mounting options.

WHAT'S IN THE BOX

Verify that all items are present in the package:

- B-Qtech Mbc1080p Mini Body Camera
- USB Cable
- User Manual (this document)



Image: The B-Qtech Mbc1080p Mini Body Camera shown with its included USB cable and a clip attachment.

SETUP

1. Charging the Battery

Before first use, fully charge the camera's built-in 350mAh rechargeable battery. A full charge provides approximately 1.5 hours of continuous recording.

1. Connect the camera to a USB power source (e.g., computer USB port, USB wall adapter) using the provided USB cable.
2. The charging indicator light will illuminate.
3. Once fully charged, the indicator light will change or turn off (refer to the camera's LED status for specific behavior).

2. Inserting a Micro SD Card

The camera requires a Micro SD card (not included) for storing recordings. It supports up to 128GB.

1. Locate the Micro SD card slot on the camera.
2. Gently insert the Micro SD card into the slot with the contacts facing the correct direction until it clicks into place.
3. To remove, push the card in slightly until it springs out.

Plug and play, no internet connection and no app download required

TF card support: Maximum support of 128G (TF card not included)



Image: The camera connected via USB to a laptop and phone, highlighting the Micro SD card slot for storage.

OPERATING INSTRUCTIONS

1. Power On/Off

- **Power On:** Press and hold the Power button until the indicator light illuminates.
- **Power Off:** Press and hold the Power button until the indicator light turns off.

2. Recording Video

The camera records high-definition 1080P video with a 150° wide-angle view.

- Ensure the camera is powered on and has a Micro SD card inserted.
- Press the Record button once to start video recording. The indicator light will flash to indicate recording is in progress.
- Press the Record button again to stop recording. The indicator light will return to a steady state.
- The camera supports loop recording, automatically overwriting the oldest files when the memory card is full.



Image: A visual representation of the camera's 150-degree wide-angle lens capturing a broad field of view.

3. Viewing Recordings

The camera features a 0.96-inch high-definition color screen for real-time preview and playback.

- Use the camera's built-in screen for immediate playback of recorded videos and photos.
- Alternatively, connect the camera to a computer or mobile phone using the USB cable. The camera will appear as a removable storage device, allowing you to access and transfer files directly. No special app or internet connection is required for this process.



Photo



Video



Record

Image: The camera connected to a laptop and a smartphone via USB, illustrating the plug-and-play functionality for viewing files.

4. Mounting Options

The camera's compact size and 360° rotating magnetic design allow for versatile mounting.

- Use the included clip to attach the camera to clothing, bags, or other surfaces.
- The magnetic base allows for attachment to metallic surfaces.
- Additional accessories (not included) may allow mounting on helmets, bikes, drones, or boats for dynamic first-person perspectives.

150° HD WIDE-ANGLE VIEW



Image: The camera attached to a shirt, bicycle handlebars, and a helmet, demonstrating its versatile mounting capabilities.

MAINTENANCE

1. Cleaning

- Wipe the camera body with a soft, dry cloth.
- For the lens, use a specialized lens cleaning cloth and solution to avoid scratches.
- Do not use harsh chemicals or abrasive materials.

2. Storage

- Store the camera in a cool, dry place away from direct sunlight and extreme temperatures.
- If storing for extended periods, charge the battery periodically (e.g., every 3-6 months) to maintain battery health.

3. Battery Care

- Avoid fully discharging the battery frequently.

- Do not expose the battery to high temperatures.

TROUBLESHOOTING

- **Camera not turning on:** Ensure the battery is charged. Connect to a power source and try again.
- **Cannot record:** Check if a Micro SD card is inserted and if it has sufficient free space. Format the card if necessary (this will erase all data).
- **Poor video quality:** Ensure the lens is clean. Check lighting conditions.
- **Computer not recognizing camera:** Try a different USB port or cable. Ensure the camera is powered on when connected.

SPECIFICATIONS

Feature	Detail
Brand	B-Qtech
Model Number	Mbc1080p
Item Weight	0.8 ounces
Product Dimensions	1 x 1 x 2 inches
Battery	1 Nonstandard Battery (included), 350mAh
Continuous Recording Time	Approx. 1.5 hours
Color	Black
Special Features	Compact Size, High Definition Recording, Portable, Wearable, 360° Rotating Magnetic Design
Photo Sensor Technology	CMOS
Video Capture Resolution	1080p
Wide-Angle View	150°
Flash Memory Type	Micro SD (up to 128GB, not included)
Video Capture Format	1080p HD
Supported Audio Format	AAC, PCM
Screen Size	0.96 Inches (color screen)
Connectivity Technology	USB

WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the official B-Qtech website or contact their customer service directly. Details are typically provided on the product packaging or through the retailer where the product was purchased.