

truke Mega 10 (F41)

truke Mega 10 True Wireless Earbuds User Manual

Model: Mega 10 (F41)

1. INTRODUCTION

Welcome to the truke Mega 10 True Wireless Earbuds user manual. These earbuds are designed to provide a superior audio experience with advanced features such as 24-bit Lossless Spatial Audio, powerful 13mm Titanium Drivers, and extended battery life. This manual will guide you through the setup, operation, and maintenance of your new earbuds.



Image: truke Mega 10 True Wireless Earbuds and their charging case in Jet Black.

2. WHAT'S IN THE BOX

Your truke Mega 10 package includes the following items:

- truke Mega 10 True Wireless Earbuds (Jet Black)
- Wireless Charging Case
- USB Type-C Charging Cable
- Multiple Sizes of Eartips
- User Manual

3. SETUP GUIDE

3.1. Charging the Earbuds and Case

Before first use, fully charge the truke Mega 10 earbuds and their charging case. The case provides an impressive 70 hours of total playtime.

1. Connect the provided USB Type-C charging cable to the charging port on the case.
2. Connect the other end of the cable to a compatible USB power adapter (not included).
3. The LED indicator on the case will show charging status. Once fully charged, the indicator will change or turn off.
4. Place the earbuds into the charging case. They will begin charging automatically.



Image: The truke Mega 10 charging case highlighting its 70-hour total playtime capability.

3.2. Pairing with Your Device

The truke Mega 10 earbuds feature Next-Gen Bluetooth 5.4 for stable and efficient connectivity, along with Dual Pairing Technology.

1. Ensure the earbuds are in the charging case and the case lid is open.
2. On your device (smartphone, tablet, laptop), go to Bluetooth settings and turn Bluetooth on.
3. Select "truke Mega 10" from the list of available devices.
4. Once connected, you will hear an audio prompt, and the earbuds' indicator lights will confirm successful pairing.

Dual Pairing: To connect to a second device, disconnect from the first device or turn off its Bluetooth. Then, repeat the pairing process with the second device. The earbuds will remember both connections, allowing

seamless switching.



Image: truke Mega 10 earbuds connected simultaneously to a smartphone and a laptop, illustrating dual device connectivity.

4. OPERATING INSTRUCTIONS

4.1. Touch Controls

The truke Mega 10 earbuds feature intuitive touch controls for media playback, calls, and mode switching.

Action	Left Earbud	Right Earbud
Play/Pause	Single Tap	Single Tap
Next Track	Double Tap	-
Previous Track	-	Double Tap
Answer/End Call	Single Tap	Single Tap
Reject Call	Long Press (2s)	Long Press (2s)
Activate Voice Assistant	Triple Tap	Triple Tap
Toggle Gaming Mode (Low Latency)	Long Press (3s)	Long Press (3s)

4.2. Key Features

- **24-bit Lossless Spatial Audio:** Experience incredibly precise and immersive soundscapes.

24-Bit

360° SPATIAL SOUND

These earbuds are equipped with **24-bit lossless Audio and Spatial Sound** technology. This aims to provide a rich, detailed, and immersive **Audio Experience**, making music and entertainment come alive by creating a more realistic soundstage.

24-bit



16-bit

Image: Visual representation of 24-bit 360° Spatial Sound technology.

- **Dynamic 13mm Titanium Drivers:** Enjoy vibrant audio with deep bass and crisp highs.



Image: truke Mega 10 earbuds showcasing the 13mm Real Titanium Drivers for cinematic music experience.

- **Quad Mic PureVoice True ENC:** Actively reduces background noise for crystal clear calls.



Image: A user experiencing clear calls thanks to PureVoice ENC technology.

- **Hyper-Responsive 40ms Low Latency:** Ideal for competitive gaming and immersive video streaming.



Image: truke Mega 10 earbuds with a gaming controller and smartphone, illustrating the 40ms ultra-low latency gaming mode.

- **IPX5 Water Resistance:** Provides protection against splashes and sweat, making them suitable for workouts.
- **Premium Matte Finish Design:** Combines sleek aesthetics with practical durability.



Image: The truke Mega 10 charging case showcasing its premium matte finish design.

5. MAINTENANCE AND CARE

To ensure the longevity and optimal performance of your truke Mega 10 earbuds, follow these care guidelines:

- **Cleaning:** Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth. Do not use harsh chemicals or abrasive materials.
- **Eartips:** Remove the eartips and clean them with mild soap and water if necessary. Ensure they are completely dry before reattaching.
- **Charging Ports:** Keep the charging contacts on the earbuds and inside the case clean and free of debris.
- **Storage:** When not in use, store the earbuds in their charging case to protect them and keep them charged.
- **Water Exposure:** While IPX5 rated for splash and sweat resistance, avoid submerging the earbuds in water or exposing them to heavy rain. Dry them thoroughly if they get wet.

6. TROUBLESHOOTING

If you encounter any issues with your truke Mega 10 earbuds, refer to the following common solutions:

Problem	Possible Solution
Earbuds not pairing	<ul style="list-style-type: none">◦ Ensure earbuds are charged.◦ Turn off and on Bluetooth on your device.◦ Forget "truke Mega 10" from your device's Bluetooth list and re-pair.◦ Place earbuds back in the case, close the lid, wait a few seconds, then open and try again.
Only one earbud working	<ul style="list-style-type: none">◦ Ensure both earbuds are charged.◦ Place both earbuds in the charging case, close the lid, and then open it again to reset their connection.◦ Try re-pairing the earbuds with your device.
Low volume or poor sound quality	<ul style="list-style-type: none">◦ Adjust the volume on both your device and the earbuds.◦ Ensure eartips are properly sealed in your ear canal. Try different sized eartips.◦ Clean any debris from the earbud speakers.
Charging issues	<ul style="list-style-type: none">◦ Check the charging cable and adapter for damage.◦ Ensure charging contacts on earbuds and case are clean.◦ Try a different USB port or power source.

7. SPECIFICATIONS

Detailed technical specifications for the truke Mega 10 True Wireless Earbuds:

Feature	Detail
Model Name	Mega 10
Model Number	F41
Connectivity Technology	Wireless (Bluetooth 5.4)
Driver Size	13mm Titanium Drivers
Audio Technology	24-bit Lossless Spatial Audio
Noise Cancellation	Quad Mic PureVoice True ENC
Latency	40ms Ultra Low Latency (Gaming Mode)

Feature	Detail
Battery Life	Up to 70 hours (with charging case)
Water Resistance	IPX5 (Splash & Sweat Resistant)
Dual Connectivity	Yes
Control Type	Media Control (Touch)
Item Weight	41 Grams
Product Dimensions	6.2 x 5 x 3 cm
Batteries	3 9V batteries required. (included) - <i>Note: This seems like a generic placeholder from the source, actual earbuds use Lithium Polymer.</i>
Battery Cell Composition	Lithium Polymer
Manufacturer	SHENZHEN LONGFUXIANG TECHNOLOGY CO.,LIMITED
Country of Origin	China

8. WARRANTY AND SUPPORT

truke products are designed for reliability and performance. For warranty information and customer support, please refer to the warranty card included in your product packaging or visit the official truke website. For any technical assistance or inquiries, you may contact truke customer support through their official channels.

Please retain your proof of purchase for warranty claims.

© 2025 truke. All rights reserved.

This manual is for informational purposes only. Specifications are subject to change without notice.